

③ ‘LH’ and ‘RH’ on the parts name are described against the moving

direction of the machine or are described on the condition how to install parts on the machines.

- ④ SPC : The following symbol classifies parts to be used for machines.

`\*` means standard parts.

`T` shows that the parts can be installed as optional parts.

`R` shows that the parts can be used as applicable parts to replace originally equipped parts.

- ⑤ Upper column : QTY shows the number of parts to be used for one unit of machine.

`M` is indicated for parts supplied by a meter long.

`l` is indicated for parts supplied by liter.

`AR` is indicated for parts need to be adjusted or regulated.

Lower column : serial number

—229 means serial number up to 229.

230— means serial number 230 and after.

- ⑥ ITC : Interchangeability

`1`...OLD ← NEW

New parts can be used in place of the old parts.

`2`...OLD → NEW

Old parts can be used in place of the new parts.

`3`...OLD →← NEW

Old parts and new parts can not be replaced each other.

- ⑦ COL : Color code

Color is signified with color code number for colored parts.

Please see the color list shown in the next page.

- ⑧ GRP : Parts shown in this column can be replaced by SET parts.

Example : Parts marked ① can be replaced by parts marked ②, and ④ for ③, so the rest follow in the same alphabetical order.

- ⑨ Remarks

* Other maker's part code number is shown in this column.

* When Fig. No. is shown in the Remark column of SET parts or ASSY parts, each of their component parts are listed in said Fig. No.

3. Color :

The following colors are used color parts.

COLOR CODE	COLOR	SPRAY TYPE CODE NUMBER	PAINTS 4K DRUM	PAINTS 16K DRUM
4 L	NEO-BLUE	1300-985-001-10	1300-985-003-00	_____
6 G	SUMMER WHITE	1300-958-001-10	1300-958-003-00	1300-958-004-00
7 F	MIRROR BLACK	1300-954-001-10	1300-954-003-00	1300-954-004-00
8 E	SILVER MIST	1300-968-001-10	1300-968-003-00	1300-968-004-00

NOTE : Color code is signified only for the parts assigned by the maker as color parts.

4. Serial Numbers :

1) For engines serial number is stamped on CYLINDER BLOCK ASSY.

Please see Fig. No. 5—1.

2) For chassies serial number is shown on the LABEL.

Please see



5. Parts Order

1) Parts numbers listed in the parts catalogue are all registered in “ISEKI on-line computer” .

2) When you order parts, please make sure of correct numbers.

3) When substitute parts is available, the part number ordered will be

automatically turned to a new part number.



- 4) Please be sure to use "ISEKI GENUINE PARTS" .

Any other similar parts other than ISEKI parts when used may cause a trouble that makes us unable to repair or guarantee the warrant.

*** Structure Table of Model ***

M O D E L	S G										
	1 E 4 4 4 4 4 4 4 4 4 4 4 4										
	5 2 8 8 8 8 8 8 8 8 8 8										
	3 0 E E E E E E E E E R R										
	H S 2 2 4 4 4 4 5 5 5 E E										
FIG.	0 0 0 0 2 2 0 0 0 4 4										
	S S M M S T 0 0										
	S S										
1		**									
2	*****	*****	*****								
3	*****	*****	*****								
4	*****	*****	*****								
5	*****	*****	*****								
6	*****	**	*****								
7		**									
8	*****	*****	*****								
9	*****	*****	*****								
10	*****	*****	*****								
11	*****	*****	*****								
12	*****	*****	*****								
13	*****	*****	*****								
14	*****	*****	*****								
15	*****	*****	*****								
16	*****	*****	*****								
17	*****	*****	*****								
18	*****	*****	*****								
19	*****	*****	*****								
20	*****	*****	*****								
21	*****	*****	*****								
22	*****	*****	*****								
23	*****	*****	*****								
24	*****	*****	*****								
25	*****	*****	*****								
26	*****	*****	*****								
27	*****	*****	*****								
28	*****	*****	*****								
29	*****	*****	*****								
30		**									
31	*****	**	*****								
32	*****	*****	*****								
33		**									
34	*****	*****	*****								
35	*****	*****	*****								
36	*****	*****	*****								
37	* *	* *	* *								
38	* *	* *	* *								
39	*****	*****	*****								
40	***										
41		**									
42		**	**								
43		**									
44			*								
45	*****	*****	*****								

[illegible]



Contents

SG153 (EXCEPT S-TYPE)

ENGINE(E262G)

CYLINDER HEAD..... Fig. 1

CYLINDER HEAD COVER..... Fig. 2

INLET MANIFOLD..... Fig. 3

EXHAUST MANIFOLD..... Fig. 4

CYLINDER BLOCK..... Fig. 5

BEARING/UNDER SIZE (OPTION)..... Fig. 6

OIL PAN..... Fig. 7

REAR PLATE..... Fig. 8

REAR PLATE..... Fig. 9

TIMING GEAR CASE..... Fig. 10

HANGER..... Fig. 11

VALVE..... Fig. 12

CAM SHAFT..... Fig. 13

PISTON..... Fig. 14

PISTON..... Fig. 15

PISTON/OVER SIZE (OPTION)..... Fig. 16

PISTON/OVER SIZE (OPTION)..... Fig. 17

CRANK SHAFT..... Fig. 18

OIL PUMP..... Fig. 19

WATER PUMP..... Fig. 20

WATER PUMP..... Fig. 21

COOLING FAN..... Fig. 22

INJECTION NOZZLE..... Fig. 23

INJECTION PUMP..... Fig. 24

FUEL PIPE.....	Fig. 25
ADAPTER.....	Fig. 26
ELECTRIC (1).....	Fig. 27
ELECTRIC (2).....	Fig. 28
REPAIR PARTS (OPTION).....	Fig. 29
COMPONENT PARTS	
FOR 6215-300-005-00 ON Fig.23.....	Fig. 30
COMPONENT PARTS	
FOR 6215-300-030-00 ON Fig.23.....	Fig. 31
COMPONENT PARTS	
FOR 6215-300-037-00 ON Fig.23.....	Fig. 32
COMPONENT PARTS	
FOR 6215-600-057-10 ON Fig.24.....	Fig. 33
COMPONENT PARTS	
FOR 6281-100-003-10 ON Fig.27.....	Fig. 34
COMPONENT PARTS	
FOR 6281-200-007-00 ON Fig.27.....	Fig. 35

Contents

SG153 (S-TYPE)

ENGINE(E262G01)

CYLINDER HEAD..... Fig. 1

CYLINDER HEAD COVER..... Fig. 2

INLET MANIFOLD..... Fig. 3

EXHAUST MANIFOLD..... Fig. 4

CYLINDER BLOCK..... Fig. 5

BEARING/UNDER SIZE (OPTION)..... Fig. 6

OIL PAN..... Fig. 7

REAR PLATE..... Fig. 8

TIMING GEAR CASE..... Fig. 9

HANGER..... Fig. 10

VALVE..... Fig. 11

CAM SHAFT..... Fig. 12

PISTON..... Fig. 13

PISTON..... Fig. 14

PISTON/OVER SIZE (OPTION)..... Fig. 15

PISTON/OVER SIZE (OPTION)..... Fig. 16

CRANK SHAFT..... Fig. 17

OIL PUMP..... Fig. 18

WATER PUMP..... Fig. 19

WATER PUMP..... Fig. 20

COOLING FAN..... Fig. 21

INJECTION NOZZLE..... Fig. 22

INJECTION PUMP..... Fig. 23

FUEL PIPE..... Fig. 24

ADAPTER.....	Fig. 25
ELECTRIC (1).....	Fig. 26
ELECTRIC (2).....	Fig. 27
REPAIR PARTS (OPTION).....	Fig. 28
COMPONENT PARTS	
FOR 6215-300-005-00 ON Fig.22.....	Fig. 29
COMPONENT PARTS	
FOR 6215-300-030-00 ON Fig.22.....	Fig. 30
COMPONENT PARTS	
FOR 6215-300-037-00 ON Fig.22.....	Fig. 31
COMPONENT PARTS	
FOR 6215-600-057-10 ON Fig.23.....	Fig. 32
COMPONENT PARTS	
FOR 6281-100-003-10 ON Fig.26.....	Fig. 33
COMPONENT PARTS	
FOR 6281-200-005-00 ON Fig.26.....	Fig. 34
COMPONENT PARTS	
FOR 6281-200-016-00 ON Fig.26.....	Fig. 35

Contents

CHASSIS

ENGINE BRACKET SYSTEM
 (M TYPE-No.301563-)..... Fig. 1

ENGINE BRACKET SYSTEM
 (EXCEPT M TYPE-No.1-/M TYPE-No.1-301562)..... Fig. 2

RADIATOR SYSTEM..... Fig. 3

MUFFLER AND AIR CLEANER SYSTEM..... Fig. 4

FUEL FILTER AND FUEL HOSE SYSTEM..... Fig. 5

BATTERY SYSTEM (EXCEPT M TYPE)..... Fig. 6

BATTERY SYSTEM (M TYPE)..... Fig. 7

ACCELERATOR SYSTEM..... Fig. 8

DRIVE SHAFT SYSTEM..... Fig. 9

TRANSMISSION CASE SYSTEM..... Fig. 10

TRANSMISSION GEAR SYSTEM..... Fig. 11

HST (1) SYSTEM..... Fig. 12

HST (2) SYSTEM..... Fig. 13

HST (3) SYSTEM(1/3)-(3/3)..... Fig. 14

HST (UNLOAD) SYSTEM..... Fig. 15

DIFFERENTIAL GEAR
 AND WHEEL SHAFT SYSTEM..... Fig. 16

BRAKE SYSTEM..... Fig. 17

BRAKE PEDAL AND ARM SYSTEM..... Fig. 18

REAR TIRE SYSTEM..... Fig. 19

PTO CLUTCH SYSTEM..... Fig. 20

PTO SHAFT SYSTEM..... Fig. 21

CHASSIS AND FRONT AXLE SYSTEM..... Fig. 22

KNUCKLE ARM SYSTEM..... Fig. 23

STEERING WHEEL SYSTEM..... Fig. 24

STEERING SYSTEM.....	Fig. 25
FRONT TIRE SYSTEM.....	Fig. 26
LIFT AND LINK SYSTEM.....	Fig. 27
LIFT CAM SYSTEM.....	Fig. 28
PTO COVER SYSTEM (EXCEPT M TYPE).....	Fig. 29
HOOD SYSTEM (M TYPE).....	Fig. 30
HOOD SYSTEM (EXCEPT M TYPE).....	Fig. 31
FENDER SYSTEM (EXCEPT M TYPE).....	Fig. 32
FENDER SYSTEM (M TYPE).....	Fig. 33
SEAT SYSTEM.....	Fig. 34
FUEL TANK AND STEP SYSTEM.....	Fig. 35
PANEL SYSTEM.....	Fig. 36
HARNESS SYSTEM (EXCEPT S TYPE).....	Fig. 37
HARNESS SYSTEM (S TYPE).....	Fig. 38
MARK.....	Fig. 39
LABEL (GERMAN) (E20 TYPE).....	Fig. 40
LABEL (FRENCH) (E50 TYPE EXCEPT T).....	Fig. 41
LABEL (ENGLISH) (E40 TYPE).....	Fig. 42
LABEL (ENGLISH) (E42 TYPE).....	Fig. 43
LABEL (ITALIAN) (E50T TYPE).....	Fig. 44
TOOL.....	Fig. 45

OPTIONAL PARTS

REAR TIRE (FIELD) SYSTEM (OPTION).....	Fig. 46
REAR PTO SYSTEM (OPTION).....	Fig. 47
REAR HITCH SYSTEM (OPTION).....	Fig. 48
HEAD LAMP	
AND HOUR METER SET (OPTION).....	Fig. 49
BUMPER WEIGHT SET (OPTION).....	Fig. 50

COMPONENT PARTS

COMPONENT PARTS

FOR K211-012-000-00 ON Fig.13..... Fig. 51

WIRING DIAGRAM/SG153


WIRING DIAGRAM/SG153/S


REAL WIRING DIAGRAM/SG153

REAL WIRING DIAGRAM/SG153/S

E N G I N E

E262G...SG153(EXCEPT S-TYPE)

[illegible]

[illegible]




[illegible]

FIG. 5 CYLINDER BLOCK

6003-201L-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E262G					
1	6211-210-021-10	CYLINDERBLOCK ASSY	*	1 -161192					
1A	6211-210-021-20	CYLINDERBLOCK ASSY	*	1 161193-		1			
2	6209-000-004-10	BOLT	*	6		1			
3	6209-610-001-00	CAP,SEALING	*	1 -202173					
3A	6209-610-001-10	CUP/SEALING/28	*	1 202174-		1			
4	6911-219-195-00	CAP,SEALING	*	3 -201995					
4A	6209-610-009-00	CUP/SEALING/36	*	3 201996-					
5	6509-605-019-10	PLUG	*	2					
6	6212-531-005-10	PIN/IDLEGEAR	*	1					
7	6911-129-083-00	CAP,SEALING	*	1 -202039					
7A	6209-610-008-00	CUP/SEALING/12	*	1 202040-					
8	6211-258-001-00	SEAL,BEARING CAP	*	4					
9	6211-258-002-00	SEAL,BEARING CAP/7	*	2					
10	6211-510-002-00	METAL,CRANK	*	1					
11	6211-511-003-00	BEARING/CRANK/UPPER	*	3					
12	6211-511-004-00	BEARING/CRANK/LOWER	*	3					
13	6211-599-001-10	BEARING,THRUST CRANK	*	2					
14	6209-625-001-00	SEAL,OIL	*	1 -185627					
14A	6209-625-012-00	OILSEAL	*	1 185628-					
15	6209-749-001-10	PIN,TUBE	*	2 -140551					
15A	6209-749-001-20	PIN/TUBE	*	2 140552-		1			
16	6213-129-006-00	PIN/STRAIGHT	*	2					
17	6213-129-005-00	PIN/STRAIGHT	*	2					
18	6904-110-840-00	STUD/M8X40	*	1					
19	6904-110-818-00	STUD	*	1					
20	6894-453-344-00	DOWEL	*	2 -125999					
20A	6294-453-002-00	DOWEL	*	2 126000-					
21	6909-902-299-00	NIPPLE	*	1					
22	6213-721-001-00	PIPE,WATER DRAIN	*	1					
23	6211-291-001-10	COVER,INJ PUMP	*	1					

FIG. 5 CYLINDER BLOCK



6003-201L-0100


[illegible]



6003-209A-0100

[illegible]


FIG. 7 OIL PAN



6003-210F-0100

[illegible]


FIG. 9 REAR PLATE



6003-220G-0100

[illegible]


FIG. 10 TIMING GEAR CASE



6003-240C-0100,6003-240C-0200

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E262G					
1	6211-310-006-20	GEARCASE ASSY	*	1 -150775					
1A	6211-310-006-30	GEARCASE ASSY	*	1 150776-		1			
2	6213-319-001-00	CONNECTOR,OIL FILTER	*	1					
3	6509-605-019-10	PLUG	*	3					
4	6209-610-002-10	CUP/SEALING/16	*	1					
5	6209-625-002-00	SEAL,OIL	*	1					
6	V231-360-808-50	FLANGEBOLT	*	1					
7	V231-360-807-50	FLANGEBOLT	*	1					
8	V231-360-805-50	FLANGEBOLT	*	2					
9	V231-360-805-00	FLANGEBOLT	*	2					
10	V231-360-804-00	FLANGEBOLT	*	1					
11	V231-360-803-50	FLANGEBOLT	*	1					
12	3817-401-001-00	NUT/M08	*	1					
13	V231-360-801-60	FLANGEBOLT	*	3					
14	V231-360-804-50	FLANGEBOLT	*	1					
15	V231-360-803-00	FLANGEBOLT	*	1					
16	6209-500-003-00	WASHER/08X14X01	*	1					
17	6215-546-001-00	STOPPER,FULL-LOAD	*	1					
18	6209-409-001-00	NUT/M8	*	1					
19	V341-120-008-00	NUT,CAP/M 8	*	1					
20	6209-920-002-00	PACKING	*	2					
21	3625-540-004-00	CAP,BLANK/30	*	1					
22	6215-542-001-10	PIN/ARM	*	1					
23	V710-140-004-00	RING,SNAP/ 4 E	*	2					
24	6909-202-308-00	PLUG	*	1 -205580					
24A	6209-600-004-00	PLUG/SCREW	*	1 205581-					
25	6209-500-003-00	WASHER/08X14X01	*	1					
26	6209-740-001-00	PIN,GROOVE	*	1					
27	6211-312-001-20	GASKET/GEARCASE	*	1 -148221					
27A	6211-312-001-30	GASKET/GEARCASE	*	1 148222-		1			


FIG. 10 TIMING GEAR CASE



6003-240C-0100,6003-240C-0200

[illegible]


FIG. 11 HANGER



6003-290 -0100

[illegible]


FIG. 12 VALVE



6003-301A-0100


KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E262G					
1	6212-551-001-00	VALVE,INTAKE	*	2 -215014					
1A	6212-551-001-10	VALVE/INTAKE	*	2 -240792		1			
1B	6212-551-028-00	VALVE/INTAKE	*	2 240793-					
2	6212-552-001-00	VALVE,EXHAUST	*	2 -162896					
2A	6212-552-001-10	VALVE/EXHAUST	*	2 -215014		1			
2B	6212-552-001-20	VALVE/EXHAUST	*	2 -240792		1			
2C	6212-552-014-00	VALVE/EXHAUST	*	2 240793-					
3	6212-561-001-00	SPRING/VALVE	*	4 -212419					
3A	6212-561-001-10	SPRING/VALVE	*	4 212420-		1			
4	6212-563-001-00	SEAT,VALVE SPRING	*	4					
5	6212-565-001-00	CUTTER,VALVE	*	8					
6	6212-571-001-10	TAPPET	*	4 -140829					
6A	6212-571-003-00	TAPPET	*	4 -212167					
6B	6212-571-006-00	TAPPET	*	4 212168-					
7	6212-575-001-00	ROD,PUSH	*	4					
8	6212-600-003-00	SHAFT,ROCKER	*	1 -188643					
8A	6212-600-003-10	ROCKERSHAFT ASSY	*	1 188644-		1			
9	6212-611-004-10	ROCKERARM	*	4					
10	6212-620-002-10	SHAFT,ROCKER ARM ASSY	*	1 -188643					
10A	6212-620-002-20	SHAFT/ROCKERARM ASSY	*	1 188644-		1			
11	6212-626-002-10	PLUG	*	2					
12	6212-628-004-00	BRACKET ROCKER SHAFT	*	1					
13	6212-628-005-00	BRACKET,ROCKER SHAFT	*	1					
14	6209-940-004-00	SPRING	*	1					
15	V704-140-016-00	RING,SNAP/16 C	*	2					
16	6212-616-002-00	SCREW ADJUST	*	4					
17	6209-409-003-00	NUT	*	4					
18	6209-000-002-00	BOLT	*	1					
19	3817-401-001-00	NUT/M08	*	2					

FIG. 14 PISTON



6003-340D-0100

[illegible]

[illegible]



[illegible]


FIG. 18 CRANK SHAFT



6003-350F-0100

[illegible]


FIG. 19 OIL PUMP



6003-401A-0100

[illegible]


FIG. 20 WATER PUMP



6003-420B-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E262G					
1	6213-610-005-30	WATERPUMP ASSY	*	1 -116762					
2	6213-611-003-20	BODY/WATERPUMP	*	1 -116762					
3	6213-631-002-00	BEARING/WATER PUMP	*	1 -116762					
4	6213-631-005-00	BEARING/WATERPUMP	*	1 -116762					
5	6213-622-002-10	SEAL SET/WATER PUMP	*	1 -116762					
6	6213-621-003-00	ROTOR/WATERPUMP	*	1 -116762					
7	6213-642-002-00	SEAL/WATER PUMPPULLE	*	1 -116762					
8	6213-613-002-10	GASKET	*	1 -116762					
9	6213-612-004-00	PLATE/WATER PUMP	*	1 -116762					
10	6213-619-003-00	SCREW/WATER PUMP	*	3 -116762					
11	6213-619-002-00	PIPE/WATER PUMP	*	2 -116762					
12	6213-614-003-10	GASKET/WATER PUMP	*	1 -116762					
13	V231-360-804-50	FLANGEBOLT	*	1 -116762					
14	3817-401-001-00	NUT/M08	*	2 -116762					
15	6213-619-005-00	SPACER,WATER PUMP	*	1 -116762					
16	6213-614-006-10	GASKET/SPACER	*	1 -116762					
17	6209-300-002-00	STUD	*	2 -116762					
18	V231-360-802-00	FLANGEBOLT	*	1 -116762					
19	3817-401-001-00	NUT/M08	*	1 -116762					
20	6213-729-001-00	HOSE,RUBBER	*	1 -116762					
21	J061-210-015-00	CLAMP/WIRE/10-15	*	2 -116762					
22	6213-716-001-40	HOUSING/THERMOSTAT	*	1 -116762					
23	6213-721-003-00	PIPE,PUMP HOUSING	*	1 -116762					
24	6213-743-002-10	GASKET/HOUSING	*	1 -116762					
25	V231-360-802-00	FLANGEBOLT	*	1 -116762					
26	V231-360-807-50	FLANGEBOLT	*	1 -116762					
27	6513-770-022-10	THERMOSTAT	*	1 -116762					
28	6213-711-003-20	PIPE,WATER OUTLET	*	1 -116762					
29	V723-102-005-50	O-RING	*	1 -116762					
30	V231-360-802-50	FLANGEBOLT	*	2 -116762					


FIG. 21 WATER PUMP



6003-420G-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E262G					
1	6213-610-005-40	WATERPUMP ASSY	*	116763-1					
2	6213-611-003-20	BODY/WATERPUMP	*	116763-1					
3	6213-631-002-00	BEARING/WATER PUMP	*	116763-1					
4	6213-631-005-00	BEARING/WATERPUMP	*	116763-1					
5	6213-622-002-10	SEAL SET/WATER PUMP	*	116763-1					
6	6213-621-003-00	ROTOR/WATERPUMP	*	116763-1					
7	6213-642-002-00	SEAL/WATER PUMPPULLE	*	116763-1					
8	6213-613-002-10	GASKET	*	116763-1					
9	6213-612-004-00	PLATE/WATER PUMP	*	116763-1					
10	6213-619-003-00	SCREW/WATER PUMP	*	116763-3					
11	6213-619-002-00	PIPE/WATER PUMP	*	116763-2					
12	6213-614-003-10	GASKET/WATER PUMP	*	116763-1					
13	V231-360-804-50	FLANGE BOLT	*	116763-2					
14	3817-401-001-00	NUT/M08	*	116763-1					
15	6213-619-005-00	SPACER, WATER PUMP	*	116763-1					
16	6213-614-006-10	GASKET/SPACER	*	116763-1					
17	6209-300-002-00	STUD	*	116763-2					
18	V231-360-802-00	FLANGE BOLT	*	116763-1					
19	3817-401-001-00	NUT/M08	*	116763-1					
20	6213-729-013-10	HOSE/RUBBER	*	116763-1					
21	J061-210-015-00	CLAMP/WIRE/10-15	*	198868-2					
21A	J062-138-148-00	CLIP/HOSE/13.8-14.8	*	198888-2					
21B	J061-210-015-00	CLAMP/WIRE/10-15	*	198889-2					
22	6213-716-001-40	HOUSING/THERMOSTAT	*	207142-1					
22A	6213-716-001-50	HOUSING/THERMOSTAT	*	207143-1		1			
23	6213-721-003-00	PIPE, PUMP HOUSING	*	208007-1					
24	6213-743-002-10	GASKET/HOUSING	*	116763-1					
25	V231-360-802-00	FLANGE BOLT	*	116763-1					
26	V231-360-807-50	FLANGE BOLT	*	116763-1					
27	6513-770-022-10	THERMOSTAT	*	116763-1					

6003-420G-0100



6003-420G-0100



[illegible]


FIG. 24 INJECTION PUMP



6003-510F-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E262G					
1	6215-600-057-00	PUMP,INJ ASSY	*	-211781					FIG 033
1A	6215-600-057-10	INJECTIONPUMP ASSY	*	211782-		1			FIG 033
2	6219-752-011-00	SHIM/INJECTTON P/0.1	*	-243645					
3	6219-752-012-00	SHIM/INJECTION P/0.2	*	-243645					
3A	6219-752-036-00	SHIM/INJECTIONPUMP	*	243646-					
4	6219-752-013-00	SHIM/INJECTION P/0.3	*	-243645					
4A	6219-752-037-00	SHIM/INJECTIONPUMP	*	243646-					
5	6219-752-014-00	SHIM/INJECTION P/0.4	*	-243645					
5A	6219-752-038-00	SHIM/INJECTIONPUMP	*	243646-					
6	6219-752-015-00	SHIM/INJECTION P/0.5	*	-229905					
6A	6219-752-039-00	SHIM/INJECTIONPUMP	*	243646-					
7	6209-056-001-00	BOLT/M6X18	*	4					
8	6215-621-004-10	SHAFT,CAM/INJ.PUMP	*	-206838					
8A	6215-621-004-20	CAMSHAFT/INJPUMP	*	206839-		1			
9	6212-524-002-00	GEAR,INJ PUMP	*	-207994					
9A	6212-524-002-10	GEAR/INJECTIONPUMP	*	-208021		1			
9B	6212-524-002-20	GEAR/INJECTIONPUMP	*	208022-		1			
10	6908-000-716-00	KEY	*	-205580					
10A	6209-730-005-00	KEY/07X05X09	*	205581-					
11	V600-110-620-30	BEARING,RB/6203	*	1					
12	V600-110-600-40	BEARING,RB/6004	*	1					
13	6212-535-002-00	PLATE,THRUST INJPUMP	*	1					
14	6901-910-612-00	BOLT,SEMS/M6X12	*	1					
15	6215-520-001-00	FLYWEIGHT	*	1					
16	6209-030-043-00	BOLT/M6X10	*	3					
17	6215-526-001-10	PIECE,THRUST	*	-211721					
17A	6215-526-004-00	THRUSTPIECE	*	211722-					
18	6215-541-001-00	ARM,FLOATING	*	-156998					
18A	6215-541-001-10	ARM/FLOATING COMP	*	156999-		1			
19	6215-543-003-20	LINK/CONTROL	*	1					



FIG. 24 INJECTION PUMP




6003-510F-0100

[illegible]

FIG. 25 FUEL PIPE



(NO.1~121249)




(NO.121250~)

6003-550F-0100


[illegible]

FIG. 26 ADAPTER



6003-560J-0100

[illegible]

[illegible]




[illegible]


FIG. 29 REPAIR PARTS (OPTION)




6003-999B-0100

[illegible]

[illegible]

[illegible]

**FIG. 33 COMPONENT PARTS
FOR 6215-600-057-10 ON Fig.24**




6215-600-057-1H

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E262G					
1	6215-611-003-00	HOUSING PUMP	*	1					
2	6215-631-004-00	PLUNGER ASSY	*	2					
3	6215-641-002-00	VALVE,DELIVERY	*	2					
4	6215-643-003-00	SPRING,DELIVERYVALVE	*	2					
5	6215-649-003-00	GASKET	*	2					
6	6215-644-003-00	HOLDER,DELIVERYVALVE	*	2					
7	6215-649-004-00	O-RING	*	2					
7A	6215-649-004-10	ORING	*	2		1			
8	6215-635-002-00	SLEEVE,FRANGE	*	2					
9	6215-649-005-00	PIN	*	2					
10	6215-649-006-00	O-RING	*	4					
10A	6215-649-006-10	ORING	*	4		1			
11	6215-649-007-00	SCREW	*	4					
12	6215-622-002-00	TAPPET	*	2					
13	6215-629-017-00	PIN	*	2					
14	6215-629-019-00	RING SNAP	*	1					
15	6215-634-002-00	SPRING,PLUNGER	*	2					
16	6215-639-006-00	SEAT,SPRING	*	2					
17	6215-639-007-00	SEAT,SPRING	*	2					
18	6215-629-020-00	PLATE/T=1.80	*	1					
19	6215-629-021-00	PLATE/T=1.85	*	1					
20	6215-629-022-00	PLATE/T=1.90	*	1					
21	6215-629-023-00	PLATE/T=1.95	*	1					
22	6215-629-024-00	PLATE/T=2.00	*	1					
23	6215-629-025-00	PLATE/T=2.05	*	1					
24	6215-629-026-00	PLATE/T=2.10	*	1					
25	6215-629-027-00	PLATE/T=2.15	*	1					
26	6215-629-028-00	PLATE/T=2.20	*	1					
27	6215-629-029-00	PLATE/T=2.25	*	1					
28	6215-629-030-00	PLATE/T=2.30	*	1					

[illegible]


[illegible]


[illegible]

ENGINE

E262G01...SG153(S-TYPE)

ENGINE

[illegible]

[illegible]



[illegible]

FIG. 5 CYLINDER BLOCK

6003-201S-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E262G01					
1	6211-210-021-10	CYLINDERBLOCK ASSY	*	1 -161192					
1A	6211-210-021-20	CYLINDERBLOCK ASSY	*	1 161193-		1			
2	6209-000-004-10	BOLT	*	6		1			
3	6209-610-001-00	CAP,SEALING	*	1 -202173					
3A	6209-610-001-10	CUP/SEALING/28	*	1 202174-		1			
4	6911-219-195-00	CAP,SEALING	*	3 -201995					
4A	6209-610-009-00	CUP/SEALING/36	*	3 201996-					
5	6509-605-019-10	PLUG	*	2					
6	6212-531-005-10	PIN/IDLEGEAR	*	1					
7	6911-129-083-00	CAP,SEALING	*	1 -202039					
7A	6209-610-008-00	CUP/SEALING/12	*	1 202040-					
8	6211-258-001-00	SEAL,BEARING CAP	*	4					
9	6211-258-002-00	SEAL,BEARING CAP/7	*	2					
10	6211-510-002-00	METAL,CRANK	*	1					
11	6211-511-003-00	BEARING/CRANK/UPPER	*	3					
12	6211-511-004-00	BEARING/CRANK/LOWER	*	3					
13	6211-599-001-10	BEARING,THRUST CRANK	*	2					
14	6209-625-001-00	SEAL,OIL	*	1 -185645					
14A	6209-625-012-00	OILSEAL	*	1 185646-					
15	6209-749-001-10	PIN,TUBE	*	2 -140551					
15A	6209-749-001-20	PIN/TUBE	*	2 140552-		1			
16	6213-129-006-00	PIN/STRAIGHT	*	2					
17	6213-129-005-00	PIN/STRAIGHT	*	2					
18	6904-110-840-00	STUD/M8X40	*	1					
19	6904-110-818-00	STUD	*	1					
20	6894-453-344-00	DOWEL	*	2 -127844					
20A	6294-453-002-00	DOWEL	*	2 127845-					
21	6909-902-299-00	NIPPLE	*	1					
22	6213-721-001-00	PIPE,WATER DRAIN	*	1					
23	6211-291-001-10	COVER,INJ PUMP	*	1					


[illegible]




FIG. 17

6003-209A-0100

[illegible]


FIG. 7 OIL PAN



6003-210F-0100

[illegible]


FIG. 9 TIMING GEAR CASE



6003-240C-0100,6003-240C-0200

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E262G01					
1	6211-310-006-20	GEARCASE ASSY	*	1 -150775					
1A	6211-310-006-30	GEARCASE ASSY	*	1 150776-		1			
2	6213-319-001-00	CONNECTOR,OIL FILTER	*	1					
3	6509-605-019-10	PLUG	*	3					
4	6209-610-002-10	CUP/SEALING/16	*	1					
5	6209-625-002-00	SEAL,OIL	*	1					
6	V231-360-808-50	FLANGEBOLT	*	1					
7	V231-360-807-50	FLANGEBOLT	*	1					
8	V231-360-805-50	FLANGEBOLT	*	2					
9	V231-360-805-00	FLANGEBOLT	*	2					
10	V231-360-804-00	FLANGEBOLT	*	1					
11	V231-360-803-50	FLANGEBOLT	*	1					
12	3817-401-001-00	NUT/M08	*	1					
13	V231-360-801-60	FLANGEBOLT	*	3					
14	V231-360-804-50	FLANGEBOLT	*	1					
15	V231-360-803-00	FLANGEBOLT	*	1					
16	6209-500-003-00	WASHER/08X14X01	*	1					
17	6215-546-001-00	STOPPER,FULL-LOAD	*	1					
18	6209-409-001-00	NUT/M8	*	1					
19	V341-120-008-00	NUT,CAP/M 8	*	1					
20	6209-920-002-00	PACKING	*	2					
21	3625-540-004-00	CAP,BLANK/30	*	1					
22	6215-542-001-10	PIN/ARM	*	1					
23	V710-140-004-00	RING,SNAP/ 4 E	*	2					
24	6909-202-308-00	PLUG	*	1 -205580					
24A	6209-600-004-00	PLUG/SCREW	*	1 205581-					
25	6209-500-003-00	WASHER/08X14X01	*	1					
26	6209-740-001-00	PIN,GROOVE	*	1					
27	6211-312-001-20	GASKET/GEARCASE	*	1 -148221					
27A	6211-312-001-30	GASKET/GEARCASE	*	1 148222-		1			


FIG. 10 HANGER



6003-290 -0100

[illegible]


FIG. 11 VALVE



6003-301A-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E262G01					
1	6212-551-001-00	VALVE,INTAKE	*	2 -215014					
1A	6212-551-001-10	VALVE/INTAKE	*	2 -240792		1			
1B	6212-551-028-00	VALVE/INTAKE	*	2 240793-					
2	6212-552-001-00	VALVE,EXHAUST	*	2 -162896					
2A	6212-552-001-10	VALVE/EXHAUST	*	2 -215014		1			
2B	6212-552-001-20	VALVE/EXHAUST	*	2 -240792		1			
2C	6212-552-014-00	VALVE/EXHAUST	*	2 240793-					
3	6212-561-001-00	SPRING/VALVE	*	4 -212419					
3A	6212-561-001-10	SPRING/VALVE	*	4 212420-		1			
4	6212-563-001-00	SEAT,VALVE SPRING	*	4					
5	6212-565-001-00	CUTTER,VALVE	*	8					
6	6212-571-001-10	TAPPET	*	4 -140829					
6A	6212-571-003-00	TAPPET	*	4 -212167					
6B	6212-571-006-00	TAPPET	*	4 212168-					
7	6212-575-001-00	ROD,PUSH	*	4					
8	6212-600-003-00	SHAFT,ROCKER	*	1 -188643					
8A	6212-600-003-10	ROCKERSHAFT ASSY	*	1 188644-		1			
9	6212-611-004-10	ROCKERARM	*	4					
10	6212-620-002-10	SHAFT,ROCKER ARM ASSY	*	1 -188643					
10A	6212-620-002-20	SHAFT/ROCKERARM ASSY	*	1 188644-		1			
11	6212-626-002-10	PLUG	*	2					
12	6212-628-004-00	BRACKET ROCKER SHAFT	*	1					
13	6212-628-005-00	BRACKET,ROCKER SHAFT	*	1					
14	6209-940-004-00	SPRING	*	1					
15	V704-140-016-00	RING,SNAP/16 C	*	2					
16	6212-616-002-00	SCREW ADJUST	*	4					
17	6209-409-003-00	NUT	*	4					
18	6209-000-002-00	BOLT	*	1					
19	3817-401-001-00	NUT/M08	*	2					


FIG. 12 CAM SHAFT



6003-310A-0100


[illegible]

FIG. 14 PISTON




6003-340I-0100

[illegible]




6003-349D-0100

[illegible]

[illegible]

[illegible]


FIG. 18 OIL PUMP



6003-401A-0100

[illegible]


FIG. 19 WATER PUMP



6003-420B-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E262G01					
1	6213-610-005-30	WATERPUMP ASSY	*	-116762	1				
2	6213-611-003-20	BODY/WATERPUMP	*	-116762	1				
3	6213-631-002-00	BEARING/WATER PUMP	*	-116762	1				
4	6213-631-005-00	BEARING/WATERPUMP	*	-116762	1				
5	6213-622-002-10	SEAL SET/WATER PUMP	*	-116762	1				
6	6213-621-003-00	ROTOR/WATERPUMP	*	-116762	1				
7	6213-642-002-00	SEAL/WATER PUMPPULLE	*	-116762	1				
8	6213-613-002-10	GASKET	*	-116762	1				
9	6213-612-004-00	PLATE/WATER PUMP	*	-116762	1				
10	6213-619-003-00	SCREW/WATER PUMP	*	-116762	3				
11	6213-619-002-00	PIPE/WATER PUMP	*	-116762	2				
12	6213-614-003-10	GASKET/WATER PUMP	*	-116762	1				
13	V231-360-804-50	FLANGE BOLT	*	-116762	1				
14	3817-401-001-00	NUT/M08	*	-116762	2				
15	6213-619-005-00	SPACER, WATER PUMP	*	-116762	1				
16	6213-614-006-10	GASKET/SPACER	*	-116762	1				
17	6209-300-002-00	STUD	*	-116762	2				
18	V231-360-802-00	FLANGE BOLT	*	-116762	1				
19	3817-401-001-00	NUT/M08	*	-116762	1				
20	6213-729-001-00	HOSE, RUBBER	*	-116762	1				
21	J061-210-015-00	CLAMP/WIRE/10-15	*	-116762	2				
22	6213-716-001-40	HOUSING/THERMOSTAT	*	-116762	1				
23	6213-721-003-00	PIPE, PUMP HOUSING	*	-116762	1				
24	6213-743-002-10	GASKET/HOUSING	*	-116762	1				
25	V231-360-802-00	FLANGE BOLT	*	-116762	1				
26	V231-360-807-50	FLANGE BOLT	*	-116762	1				
27	6513-770-022-10	THERMOSTAT	*	-116762	1				
28	6213-711-003-20	PIPE, WATER OUTLET	*	-116762	1				
29	V723-102-005-50	O-RING	*	-116762	1				
30	V231-360-802-50	FLANGE BOLT	*	-116762	2				


FIG. 20 WATER PUMP



6003-420G-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E262G01					
1	6213-610-005-40	WATERPUMP ASSY	*	116763-1					
2	6213-611-003-20	BODY/WATERPUMP	*	116763-1					
3	6213-631-002-00	BEARING/WATER PUMP	*	116763-1					
4	6213-631-005-00	BEARING/WATERPUMP	*	116763-1					
5	6213-622-002-10	SEAL SET/WATER PUMP	*	116763-1					
6	6213-621-003-00	ROTOR/WATERPUMP	*	116763-1					
7	6213-642-002-00	SEAL/WATER PUMPPULLE	*	116763-1					
8	6213-613-002-10	GASKET	*	116763-1					
9	6213-612-004-00	PLATE/WATER PUMP	*	116763-1					
10	6213-619-003-00	SCREW/WATER PUMP	*	116763-3					
11	6213-619-002-00	PIPE/WATER PUMP	*	116763-2					
12	6213-614-003-10	GASKET/WATER PUMP	*	116763-1					
13	V231-360-804-50	FLANGE BOLT	*	116763-1					
14	3817-401-001-00	NUT/M08	*	116763-2					
15	6213-619-005-00	SPACER, WATER PUMP	*	116763-1					
16	6213-614-006-10	GASKET/SPACER	*	116763-1					
17	6209-300-002-00	STUD	*	116763-2					
18	V231-360-802-00	FLANGE BOLT	*	116763-1					
19	3817-401-001-00	NUT/M08	*	116763-1					
20	6213-729-013-10	HOSE/RUBBER	*	116763-1					
21	J061-210-015-00	CLAMP/WIRE/10-15	*	198868-2					
21A	J062-138-148-00	CLIP/HOSE/13.8-14.8	*	198888-2					
21B	J061-210-015-00	CLAMP/WIRE/10-15	*	198889-2					
22	6213-716-001-40	HOUSING/THERMOSTAT	*	207142-1					
22A	6213-716-001-50	HOUSING/THERMOSTAT	*	207143-1		1			
23	6213-721-003-00	PIPE, PUMP HOUSING	*	208007-1					
24	6213-743-002-10	GASKET/HOUSING	*	116763-1					
25	V231-360-802-00	FLANGE BOLT	*	116763-1					
26	V231-360-807-50	FLANGE BOLT	*	116763-1					
27	6513-770-022-10	THERMOSTAT	*	116763-1					


FIG. 21 COOLING FAN



6003-480C-0100


[illegible]

FIG. 22 INJECTION NOZZLE






6003-501C-0100

[illegible]



KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E262601					
1	6215-600-057-00	PUMP,INJ ASSY	*	1 -211781					FIG 032
1A	6215-600-057-10	INJECTIONPUMP ASSY	*	1 211782-		1			FIG 032
2	6219-752-011-00	SHIM/INJECTTON P/0.1	*	1 -243645					
3	6219-752-012-00	SHIM/INJECTION P/0.2	*	1 -243645					
3A	6219-752-036-00	SHIM/INJECTIONPUMP	*	1 243646-					
4	6219-752-013-00	SHIM/INJECTION P/0.3	*	1 -243645					
4A	6219-752-037-00	SHIM/INJECTIONPUMP	*	1 243646-					
5	6219-752-014-00	SHIM/INJECTION P/0.4	*	1 -243645					
5A	6219-752-038-00	SHIM/INJECTIONPUMP	*	1 243646-					
6	6219-752-015-00	SHIM/INJECTION P/0.5	*	1 -229905					
6A	6219-752-039-00	SHIM/INJECTIONPUMP	*	1 243646-					
7	6209-056-001-00	BOLT/M6X18	*	4					
8	6215-621-004-10	SHAFT,CAM/INJ.PUMP	*	1 -206838					
8A	6215-621-004-20	CAMSHAFT/INJPUMP	*	1 206839-		1			
9	6212-524-002-00	GEAR,INJ PUMP	*	1 -207994					
9A	6212-524-002-10	GEAR/INJECTIONPUMP	*	1 -208021		1			
9B	6212-524-002-20	GEAR/INJECTIONPUMP	*	1 208022-		1			
10	6908-000-716-00	KEY	*	1 -205580					
10A	6209-730-005-00	KEY/07X05X09	*	1 205581-					
11	V600-110-620-30	BEARING,RB/6203	*	1					
12	V600-110-600-40	BEARING,RB/6004	*	1					
13	6212-535-002-00	PLATE,THRUST INJPUMP	*	1					
14	6901-910-612-00	BOLT,SEMS/M6X12	*	1					
15	6215-520-001-00	FLYWEIGHT	*	1					
16	6209-030-043-00	BOLT/M6X10	*	3					
17	6215-526-001-10	PIECE,THRUST	*	1 -211721					
17A	6215-526-004-00	THRUSTPIECE	*	1 211722-					
18	6215-541-001-00	ARM,FLOATING	*	1 -156998					
18A	6215-541-001-10	ARM/FLOATING COMP	*	1 156999-		1			
19	6215-543-003-20	LINK/CONTROL	*	1					


FIG. 24 FUEL PIPE



6003-550F-0100

[illegible]


FIG. 25 ADAPTER



6003-560J-0100

[illegible]

FIG. 26 ELECTRIC (1)



6003-801G-0100,6003-801G-0200

[illegible]






FIG. 28 REPAIR PARTS (OPTION)




6003-999B-0100

[illegible]

[illegible]

[illegible]


**FIG. 31 COMPONENT PARTS
FOR 6215-300-037-00 ON Fig.22**



6215-300-037-0E

[illegible]

FIG. 32 COMPONENT PARTS
FOR 6215-600-057-10 ON Fig.23




6215-600-057-1H

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E262G01					
1	6215-611-003-00	HOUSING PUMP	*	1					
2	6215-631-004-00	PLUNGER ASSY	*	2					
3	6215-641-002-00	VALVE,DELIVERY	*	2					
4	6215-643-003-00	SPRING,DELIVERYVALVE	*	2					
5	6215-649-003-00	GASKET	*	2					
6	6215-644-003-00	HOLDER,DELIVERYVALVE	*	2					
7	6215-649-004-00	O-RING	*	2					
7A	6215-649-004-10	ORING	*	2		1			
8	6215-635-002-00	SLEEVE,FRANGE	*	2					
9	6215-649-005-00	PIN	*	2					
10	6215-649-006-00	O-RING	*	4					
10A	6215-649-006-10	ORING	*	4		1			
11	6215-649-007-00	SCREW	*	4					
12	6215-622-002-00	TAPPET	*	2					
13	6215-629-017-00	PIN	*	2					
14	6215-629-019-00	RING SNAP	*	1					
15	6215-634-002-00	SPRING,PLUNGER	*	2					
16	6215-639-006-00	SEAT,SPRING	*	2					
17	6215-639-007-00	SEAT,SPRING	*	2					
18	6215-629-020-00	PLATE/T=1.80	*	1					
19	6215-629-021-00	PLATE/T=1.85	*	1					
20	6215-629-022-00	PLATE/T=1.90	*	1					
21	6215-629-023-00	PLATE/T=1.95	*	1					
22	6215-629-024-00	PLATE/T=2.00	*	1					
23	6215-629-025-00	PLATE/T=2.05	*	1					
24	6215-629-026-00	PLATE/T=2.10	*	1					
25	6215-629-027-00	PLATE/T=2.15	*	1					
26	6215-629-028-00	PLATE/T=2.20	*	1					
27	6215-629-029-00	PLATE/T=2.25	*	1					
28	6215-629-030-00	PLATE/T=2.30	*	1					


[illegible]


**FIG. 34 COMPONENT PARTS
FOR 6281-200-005-00 ON Fig.26**



6281-200-005-0B

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				E262G01					
1	6281-222-004-00	PULLEY	*	1 130377-					
2	6281-229-002-00	NUT	*	1 130377-					
3	6281-229-003-00	COLLOR	*	1 130377-					
4	6281-221-001-00	ROTOR ASSY	*	1 -186338					
4A	6281-221-007-00	ROTOR ASSY	*	1 186339-					
5	6281-229-005-00	BEARING	*	1 -186338					
5A	6281-229-004-00	COVER,BEARING	*	1 130377-					
6	6281-229-032-00	BEARING/BALL	*	1 186339-					
7	6281-213-006-00	FRAME ASSY	*	1 -186338					
7A	6281-213-018-00	FRAME/DRIVEEND ASSY	*	1 186339-					
8	6281-229-006-00	PLATE	*	1 130377-					
9	6281-229-007-00	BOLT	*	4 130377-					
10	6281-229-008-00	BOLT	*	2 130377-					
11	6281-229-009-00	BEARING	*	1 -186338					
11A	6281-229-033-00	BEARING/BALL	*	1 186339-					
12	6281-214-003-00	FRAME	*	1 130377-					
13	6281-214-004-00	COVER	*	1 130377-					
14	6281-229-029-00	HOLDER ASSY	*	1 130377-					
15	6281-229-011-00	BUSH	*	1 130377-					
16	6281-217-001-00	HOLDER,BRUSH ASSY	*	1 -186338					
16A	6281-217-002-00	HOLDER/BRUSH ASSY	*	1 186339-					
17	6281-215-001-00	BRUSH	*	2 130377-					
18	6281-216-001-00	SPRING	*	2 130377-					
19	6281-229-012-00	BOLT	*	2 130377-					
20	6281-229-013-00	BOLT	*	6 130377-					
21	6281-229-014-00	BOLT	*	1 130377-					
22	6281-229-015-00	BOLT	*	3 130377-					
23	6281-229-016-00	NUT	*	2 130377-					
24	6281-229-017-00	BOLT	*	2 130377-					
25	6281-229-018-00	NUT	*	1 130377-					

[illegible]



6281-200-016-0C

[illegible]

CHASSIS

CHASSIS




[illegible]


FIG. 3 RADIATOR SYSTEM



1593-102A-0100

[illegible]


[illegible]



1608-105 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SG153H					
1	6213-200-002-10	FILTER,FUEL	*	1					
2	1608-105-230-00	PLATE/I/19X85 COMP	*	1					
3	6219-755-001-00	HOLDER(FUEL FILTER)	*	1					
4	V211-260-801-60	BOLT,SEMS (S) M8X16	*	1					
5	1588-105-210-00	PUMP,FUEL	*	1					
6	V210-360-601-60	BOLT(SP)/M6X16	*	2					
7	V360-260-006-00	NUT/M6	*	2					
8	1608-105-221-00	HOSE 1300	*	1					
9	1608-105-222-10	HOSE/1970	*	1					
10	1593-105-213-10	PROTECTOR	*	2					
11	1608-105-223-00	PROTECTOR	*	2					
12	J061-210-012-00	CLAMP/WIRE/10-12	*	3					
13	J061-211-013-00	CLAMP/WIRE/11-13	*	1					
14	1608-105-001-40	HOSE/225	*	1					
15	1608-105-223-00	PROTECTOR	*	1					
16	J061-210-012-00	CLAMP/WIRE/10-12	*	1					
17	J061-211-013-00	CLAMP/WIRE/11-13	*	1					
18	1608-105-240-20	HOSE/06X10X365	*	1					
19	J061-210-012-00	CLAMP/WIRE/10-12	*	1					
20	J061-209-011-00	CLAMP/WIRE/09-11	*	1					
21	1608-105-003-30	HOSE/06X12X115	*	1					
22	J061-210-012-00	CLAMP/WIRE/10-12	*	1					
23	J061-211-013-00	CLAMP/WIRE/11-13	*	1					
24	1608-105-211-00	PLATE/FUELPUMP	*	1					
25	V211-261-002-00	BOLT,SEMS	*	2					
26	3659-310-004-00	HOSE/07X13X120	*	1					
27	3643-586-001-00	JOINTT-TYPE	*	1					
28	J061-210-012-00	CLAMP/WIRE/10-12	*	2					
29	J062-081-087-00	CLIP/HOSE/8.1-8.7	*	1					


FIG. 6 BATTERY SYSTEM (EXCEPT M TYPE)



1593-112 -0100

[illegible]


FIG. 8 ACCELERATOR SYSTEM



1593-117A-0100

[illegible]

FIG. 10 TRANSMISSION CASE SYSTEM




1608-201 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SG153H					
1	1608-201-001-40	CASE/TRANSMISSION LH	*	1					
2	V653-430-403-00	BEARING,NR/TA3030Z	*	1					
3	V705-140-042-00	RING,SNAP/42 C	*	1					
4	V744-130-420-80	SEAL,OIL/TC30428	*	1					
5	V740-130-420-80	SEAL,OIL	*	1					
6	3737-113-005-00	PIN,KNOCK	*	2					
7	V251-261-004-5D	BOLT/STUD/SEAL	*	1					
8	1608-201-002-30	CASE/TRANSMISSION RH	*	1					
8A	1608-201-002-40	CASE/TRANSMISSION/RH	*	-301514		1			
9	V653-430-403-00	BEARING,NR/TA3030Z	*	1					
10	V705-140-042-00	RING,SNAP/42 C	*	1					
11	V744-130-420-80	SEAL,OIL/TC30428	*	1					
12	V740-130-420-80	SEAL,OIL	*	1					
13	1608-201-004-20	METAL,BRAKE	*	1					
14	V744-120-350-70	SEAL,OIL/TC20357	*	1					
15	V721-103-104-50	O-RING/G45	*	1					
16	V211-260-801-60	BOLT,SEMS (S) M8X16	*	4					
17	1608-201-005-10	SHIM(BRAKE METAL)	*	2					
17A	1608-201-005-10	SHIM(BRAKE METAL)	*	-301848					
18	V201-260-809-50	BOLT/M 8X95	*	4					
18A	V201-260-809-50	BOLT/M 8X95	*	301849-					
19	V211-260-803-00	BOLT,SEMS	*	6					
20	V211-260-804-00	BOLT,SEMS	*	-301394					
21	V401-160-008-00	WASHER,SP/M 8	*	5					
22	V201-260-810-50	BOLT/M 8X105	*	301395-					
22A	V201-260-810-00	BOLT/M 8X100	*	6					
23	2137-223-004-00	ADAPTER(STRAIGHT)	*	1					
24	7955-201-026-00	PLUG,DRAIN (1/4)	*	-302197					
25	1608-201-200-20	PLATE,FILLER COMP	*	1					
26	V211-260-802-00	BOLT/S	*	302198-					


[illegible]

FIG. 11 TRANSMISSION GEAR SYSTEM



1608-203 -0100


[illegible]



1608-205 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SG153H					
1	1608-205-200-10	HST ASSY	*	1					
2	1608-205-260-00	CYLINDERBLOCK ASSY	*	2					
3	1608-205-263-00	RETAINERPLATE	*	2					
4	1608-205-264-00	RETAINERHOLDER	*	2					
5	1608-205-265-00	PIN	*	6					
6	1608-205-266-00	SPRING	*	2					
7	1608-205-267-00	SPRINGHOLDER	*	2					
8	1608-205-268-00	WASHER	*	2					
9	1608-205-269-00	SNAPRING	*	2					
10	1608-205-280-00	CHARGE PUMP ASSY	*	1					
11	1608-205-283-00	PIN	*	1					
12	1608-205-284-00	SEAL,OIL	*	1					
13	1608-205-285-00	O-RING	*	1					
14	V705-140-030-00	RING,SNAP/30 C	*	1					
15	1608-205-201-00	CASE	*	1					
16	1608-205-202-00	PORTBLOCK	*	1					
17	1608-205-203-00	SLANTBOARD/P	*	1					
18	1608-205-204-00	VALVEPLATE	*	1					
19	1608-205-205-00	VALVEPLATE	*	1					
20	1608-205-206-10	SHAFT/P	*	1					
21	1608-205-207-00	SHAFT/M	*	1					
22	1608-205-208-00	THRUST PLATE	*	2					
23	1608-205-209-00	TRUNNIONPIN	*	1					
24	1608-205-211-00	TRUNNIONPIN	*	1					
25	1608-205-212-00	COLLAR	*	1					
26	1608-205-213-00	BALLBEARING	*	1					
27	1608-205-214-00	BALLBEARING	*	1					
28	1608-205-215-00	NEEDLEBEARING	*	2					
29	1608-205-216-00	PIN	*	2					
30	1608-205-217-00	BUSH	*	2					

FIG. 12 HST (1) SYSTEM




1608-205 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SG153H					
31	1608-205-218-00	PLUG	*	2					
32	1608-205-219-00	STEELBALL	*	2					
33	1608-205-221-00	UNLOADINGVALVE	*	1					
34	1608-205-222-00	VALVE RELIEF	*	1					
35	1608-205-223-00	SPRING	*	2					
36	1608-205-224-00	SPRING	*	1					
37	1608-205-225-00	SPRINGPIN	*	2					
38	1608-205-226-00	COVER	*	1					
39	1608-205-234-00	SOCKET-HEADBOLT	*	8					
40	1608-205-235-00	PLUG	*	2					
41	1608-205-236-00	DRIVESCREW	*	2					
42	1608-205-237-00	PIN	*	2					
43	1608-205-238-00	PLUG	*	2					
44	1608-205-239-00	VALVE	*	2					
45	1608-205-241-00	PLUG	*	2					
46	1608-205-242-00	ORIFICE	*	2					
47	1608-205-243-00	SPRING	*	2					
48	1608-205-244-00	SPRINGHOLDER	*	2					
49	1608-205-245-00	PLUG	*	1					
50	1608-205-246-00	SPRING	*	1					
51	1608-205-247-00	PLATE	*	1					
52	V705-140-052-00	RING,SNAP/52 C	*	1					
53	V705-140-040-00	RING,SNAP/40 C	*	1					
54	V704-140-020-00	RING,SNAP/20C	*	1					
55	V580-140-401-00	PIN/SPRING	*	2					
56	V705-140-030-00	RING,SNAP/30 C	*	1					
57	1608-205-290-00	SEALKIT	*	1	301511-				
58	1608-205-284-00	SEAL,OIL	*	1	301511-				
59	1608-205-227-00	OILSEAL	*	1					
60	1608-205-228-00	OILSEAL	*	2					

[illegible]

FIG. 13 HST (2) SYSTEM




1608-206 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SG153H					
1	1608-206-200-30	PIPE/SUCTION	*	1					
2	V720-102-401-80	O-RING/P18	*	1					
3	V720-102-402-20	O-RING/P22	*	2					
4	1608-206-001-00	BOLT(CONNECTER/PF1/2	*	1					
5	V211-260-802-00	BOLT/S	*	2					
6	1435-201-220-00	FILTER,SUCTION(HST)	*	1					
7	V720-103-502-40	O-RING/P24	*	1					
8	V720-103-502-60	O-RING/P26	*	1					
9	V211-360-801-60	BOLT,SEMS (SP)	*	1					
10	1608-206-210-20	PIPE/BOOST	*	1					
11	V720-102-401-80	O-RING/P18	*	2					
12	V211-260-802-00	BOLT/S	*	2					
13	V210-260-602-00	BOLT/S	*	2					
14	K211-012-000-00	VALVE,COUNTROL	*	1					FIG 051
15	V201-260-806-00	BOLT/M 8X60	*	2					
16	V363-260-008-00	NUT/WASHER	*	2					
17	3664-351-006-00	HOSE ASSY	*	1	-300856				
17A	2161-439-220-10	HOSE(620)	*	1	-301993				
17B	1705-408-350-00	HOSE/HYDRO/610 ASSY	*	1	301994-				
18	1608-206-240-00	ADAPTER(90B)ORIFICE	*	1					
19	1608-206-241-00	ORIFICEBOLT/2.2	*	1					
20	3768-185-022-10	ADAPTER(90B/PUMP)	*	1					
21	K182-032-000-00	CYLINDER ASSY	*	1					
22	K182-032-001-00	PISTON	*	1					
23	K182-002-002-00	STOPPER,PISTON	*	1					
24	K182-032-002-00	ROD PACKING	*	1					
25	K182-032-003-00	DUST/SEAL	*	1					
26	1608-206-002-00	PIN (14X54)	*	1					
27	V411-260-014-00	WASHER,PL/M14	*	2					
28	V500-163-002-50	PIN,SPLIT/3 X25	*	1					


FIG. 14 HST (3) SYSTEM(1/3)

24
30
5 — PLEASE SEE NEXT PAGE



1608-207 -0100


KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SG153H					
1	1608-207-200-30	PLATE,TRANON	*	1					
2	V580-140-602-50	PIN,SPRING/6 X25 W	*	1					
3		WIRE	*	1					
4	V201-260-803-50	BOLT/M 8X35	*	2					
5	V304-260-008-00	NUT	*	2					
6	1608-207-210-20	PIN(NEUTRAL)	*	1					
7	1608-207-011-00	ROD(NEUTRAL)	*	1					
8	V411-260-010-00	WASHER/M10	*	1					
9	V500-163-002-00	PIN,SPLIT/3 X20	*	2					
10	V411-260-012-00	WASHER /M12	*	1					
11	V304-260-010-00	NUT	*	2					
12	1608-207-220-20	LOCK(NEUTRAL)	*	1					
13	V411-260-012-00	WASHER /M12	*	1					
14	V500-163-002-00	PIN,SPLIT/3 X20	*	1					
15	3656-115-001-00	SPRING(HE085)	*	1					
16	1608-207-230-00	PLATE(HOOK) COMP	*	1					
17	1608-207-012-00	COLLAR(12X16X12)	*	1					
18	V411-260-012-00	WASHER /M12	*	2					
19	V500-163-002-00	PIN,SPLIT/3 X20	*	1					
20	3631-671-003-00	SPRING,ROD COVER	*	1					
21	1608-207-280-10	PLSTE(I/22X134)COMP	*	1					
22	V411-260-008-00	WASHER,PL/M 8	*	1					
23	V500-163-001-50	PIN,SPLIT/3 X15	*	1					
24	1608-207-240-20	ARM(HST/F) COMP	*	1					
25	V762-150-000-00	NIPPLE,GREASE/B-M6F	*	1					
26	V401-160-006-00	WASHER,SP/M 6	*	1					
27	1608-207-310-00	ROD(HST/F)COMP	*	1					
28	1608-207-004-10	PLATE(L/22X100)	*	1					
29	V411-260-008-00	WASHER,PL/M 8	*	2					
30	V500-163-001-50	PIN,SPLIT/3 X15	*	2					

FIG. 14 HST (3) SYSTEM(2/3)

1608-207 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SG153H					
31	V 304-260-010-00	NUT	*	2					
32	1608-207-250-20	ARM(HST/REVERSE)	*	1					
33	V 762-150-000-00	NIPPLE,GREASE/B-M6F	*	1					
34	V 401-160-006-00	WASHER,SP/M 6	*	1					
35	V 411-260-020-00	WASHER/M20	*	1					
36	V 500-163-003-00	PIN,SPLIT/3X30	*	1					
37	1608-207-003-20	ROD(HST/REVERSE)	*	1					
38	1608-207-004-10	PLATE(L/22X100)	*	1					
39	V 411-260-008-00	WASHER,PL/M 8	*	2					
40	V 500-163-001-50	PIN,SPLIT/3 X15	*	2					
41	V 304-260-010-00	NUT	*	2					
42	1608-207-260-20	PEDAL (HST)	*	2					
43	V 211-260-802-00	BOLT/S	*	2					
44	1608-207-014-00	PAD (HST)	*	2					
45	1608-207-270-10	SHAFT(HOOK)	*	1					
46	V 411-260-014-00	WASHER,PL/M14	*	1					
47	V 500-163-002-50	PIN,SPLIT/3 X25	*	1					
48	1608-207-290-00	ARM(HOOK)	*	1					
49	1593-101-012-00	STOPPER	*	1					
50	V 201-260-805-00	BOLT/M 8X50	*	1					
51	V 411-260-008-00	WASHER,PL/M 8	*	2					
52	V 304-260-008-00	NUT	*	2					
53	1608-207-006-10	ROD(M10X85)	*	1					
54	1608-207-007-10	PLATE(L/32X178)	*	1					
55	V 304-260-010-00	NUT	*	2					
56	V 411-260-008-00	WASHER,PL/M 8	*	1					
57	V 500-163-001-50	PIN,SPLIT/3 X15	*	1					
58	V 411-260-010-00	WASHER/M10	*	1					
59	V 500-163-002-00	PIN,SPLIT/3 X20	*	1					
60	1608-207-008-00	PIN (10X70)	*	1					

[illegible]

[illegible]



[illegible]


FIG. 17 BRAKE SYSTEM



1608-310A-0100

[illegible]

FIG. 18 BRAKE PEDAL AND ARM SYSTEM



1608-312 -0100,1608-313 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SG153H					
1	1608-312-200-40	ARM/BRAKE COMP	*	1					
2	V760-150-000-00	NIPPLE,GREASE	*	1					
3	V401-160-006-00	WASHER,SP/M 6	*	1					
4	1608-312-005-00	SPRING(HT035)	*	1					
5	1608-312-210-20	ARM(PEDAL)	*	1					
6	1524-122-001-00	PAD	*	1					
6A	1636-313-011-10	PAD/BRAKE	*	301366					
7	V211-261-002-50	BOLT(S) M10X25	*	301367-2					
8	1608-312-007-00	ROD/M08X140	*	1					
9	V411-260-008-00	WASHER,PL/M 8	*	1					
10	V500-163-001-50	PIN,SPLIT/3 X15	*	1					
11	1608-312-003-40	ROD/M08X250	*	1					
12	1444-122-002-00	TURNBUCKLE/M8	*	1					
13	V304-260-008-00	NUT	*	1					
14	1560-132-007-30	NUT/M8	*	1					
15	1337-401-006-00	SPRING	*	1					
16	1415-120-006-00	SPRING,TENSION/86	*	1					
17	1608-312-220-00	PLATE(BRAKE LOCK)	*	1					
18	1593-312-056-20	SPRING/HT013	*	1					
19	1608-312-006-20	PLATE,LOCK	*	1					
20	V211-260-802-00	BOLT/S	*	2					
21	V411-260-010-00	WASHER/M10	*	1					
22	V500-163-002-00	PIN,SPLIT/3 X20	*	1					
23	1608-313-200-10	PLATE(PARKING) COMP	*	1					
24	3600-201-013-00	GRIP,BRAKE	*	1					
24A	2171-213-002-00	GRIP/04X12X50	*	301366					
25	V411-260-010-00	WASHER/M10	*	301367-1					
26	V500-163-002-00	PIN,SPLIT/3 X20	*	1					
27	1593-312-056-20	SPRING/HT013	*	1					




[illegible]

FIG. 20 PTO CLUTCH SYSTEM



1593-332A-0100, 1593-333A-0100


[illegible]

FIG. 21 PTO SHAFT SYSTEM

1593-334B-0100,1593-335 -0100


KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SG153H					
1	1593-334-056-50	PULLY/V2B173	*	1					
2	1593-334-054-30	BELT/VB038	*	2					
3	1593-334-052-00	SHAFT/PTO/MID	*	1					
4	1593-334-055-00	COLLAR/26X32X41	*	1					
5	V600-150-600-50	BEARING,RB/6005SS	*	2					
6	V704-140-025-00	RING,SNAP/25 C	*	1					
7	V705-140-047-00	RING,SNAP/47 C	*	1					
8	3746-111-011-00	WASHER	*	1					
9	V401-160-016-00	WASHER,SP/M16	*	1					
10	V304-460-016-00	NUT/M16	*	2					
11	1593-334-300-20	BAR/PTO	*	1 -300959					
11A	1593-334-300-30	BAR/PTO	*	1 -301119		1			
11B	1593-334-300-40	BAR/PTO	*	1 301120-		1			
12	V210-360-601-60	BOLT(SP)/M6X16	*	2 -300959					
12A	V210-360-602-00	BOLT/SP	*	2 300960-					
13	1701-509-007-00	GROMMET/10X18X50	*	1					
14	1593-334-310-20	BRACKET,PTO/F	*	1					
15	V211-261-002-50	BOLT(S) M10X25	*	2					
16	1593-335-500-50	COVER,F/PTO COMP	*	1 -301690					
16A	1593-335-500-60	COVER/FRONT/PTO COMP	*	1 301691-		3			
17	V210-360-602-00	BOLT/SP	*	4 -301684					
17A	V210-660-602-00	BOLT/SP	*	4 301685-					
18	1427-130-260-00	CAP,SHAFT(A)COMP	*	1 -301690					
18A	1593-411-053-20	CAP/WHEEL	*	1 301691-					
19	V210-260-601-20	BOLT/S	*	2 -301690					
20	1593-335-058-00	PULLEY,V/2B105	*	1					
21	V203-461-002-50	BOLT/M10X25	*	4					
22	V401-160-010-00	WASHER,SP/M10	*	4					

FIG. 22 CHASSIS AND FRONT AXLE SYSTEM



1608-401 -0100,1593-402A-0100


[illegible]

FIG. 23 KNUCKLE ARM SYSTEM

1593-403A-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SG153H					
1	1593-403-500-80	ARM/KNUCKLE/LH COMP	*	1					
2	1593-403-510-80	ARM/KNUCKLE/RH COMP	*	1					
3	1593-403-004-10	COVER/44X10	*	2					
4	1593-403-009-00	THRUST	*	2					
5	V411-260-018-00	WASHER,PL/M18	*	2					
6	V580-140-503-20	PIN,SPRING/5 X32 W	*	2					
7	3621-702-003-00	WASHER,PULLEY	*	2					
7A	3805-701-018-00	WASHER(13X34X05)	*	2					
8	V328-262-112-00	NUT/M12X1.25	*	2					
9	V500-163-002-50	PIN,SPLIT/3 X25	*	2					
10	1593-403-003-10	JOINT,BALL/LH	*	2					
11	1593-403-001-10	JOINT,BALL/RH	*	2					
12	V328-262-110-00	NUT	*	4					
13	V500-162-502-00	PIN,SPLIT/2.5X20	*	4					
14	1593-403-052-30	ROD/D=8.90-8.94	*	1					
15	1593-403-056-40	ROD/TIE/M10X193	*	1					
16	3625-212-007-00	NUT/M10	*	2					
17	V334-260-010-00	NUT/M10	*	2					
18	1593-403-530-60	ARM,PITMAN	*	1					
19	V600-150-620-30	BEARING,RB/6203SS	*	2					
20	V705-140-040-00	RING,SNAP/40 C	*	1					
21	1593-403-007-20	COLLAR/31X38X06	*	1					
22	V328-262-110-00	NUT	*	1					
23	1376-121-001-00	WASHER/11X22X3	*	1					
24	V500-162-502-00	PIN,SPLIT/2.5X20	*	1					
25	1593-403-058-30	ROD/D=8.90-8.94	*	1					
26	V335-260-012-00	NUT	*	2					
27	1593-403-005-00	JOINT,BALL	*	2					
28	V328-262-112-00	NUT/M12X1.25	*	2					
29	V401-160-012-00	WASHER,SP/M12	*	2					


FIG. 23 KNUCKLE ARM SYSTEM



1593-403A-0100

[illegible]


FIG. 25 STEERING SYSTEM



1593-407A-0100

[illegible]

FIG. 27 LIFT AND LINK SYSTEM



1608-553 -0100,1593-553A-0100

[illegible]



[illegible]

FIG. 30 HOOD SYSTEM (M TYPE)



1608-601 -0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SG153H					
1	1593-601-500-52	HOOD/A COMP	*	1					
2	1593-601-062-20	SEAL/20X10X690	*	1					
3	1593-601-067-30	TRIM/1X06X570	*	1					
4	1593-601-071-00	SEAL(20X10X130)	*	1					
5	1593-601-072-00	TRIM/1X6X360	*	2					
6	3661-212-001-00	LINING/50	*	2					
7	V210-360-601-60	BOLT(SP)/M6X16	*	6					
8	3610-631-002-00	HANGER,SUPPORT	*	2					
9	V211-260-801-60	BOLT,SEMS (S) M8X16	*	2					
10	1593-601-009-00	NET/100X388	*	1					
11	4301-210-002-00	BOLT (S/N6X16)	*	2					
12	1593-601-072-00	TRIM/1X6X360	*	2					
13	1593-601-015-00	INSULATOR/HOOD	*	3					
14	1593-601-002-40	COVER/FRONT/MESH	*	1			7F		
15	V350-160-006-00	NUT,SPEED/P6	*	3					
16	1608-601-001-00	COVER/FRONT/LH	*	1-301908					
16A	1608-601-001-10	COVER/FRONT/LH	*	1-301909		1			
17	V120-376-001-60	SCREW/SP	*	3					
18	1527-604-002-00	CLIP(B)	*	1-301909					
19	V411-260-008-00	WASHER,PL/M 8	*	1-301909					
20	1608-601-003-00	COVER/FRONT/C	*	1					
21	1608-601-002-00	COVER/FRONT/RH	*	1-301907					
21A	1608-601-002-10	COVER/FRONT/RH	*	1-301908		1			
22	V120-376-001-60	SCREW/SP	*	3					
23	1527-604-002-00	CLIP(B)	*	1-301908					
24	V411-260-008-00	WASHER,PL/M 8	*	1-301908					
25	1593-601-300-00	COVER/LOWER ASSY	*	1					
26	1593-601-524-10	NET,LOWER COVER/LH	*	1					
27	1593-601-525-10	NET,LOWER COVER/RH	*	1					
28	V350-160-004-00	NUT,SPEED/P4	*	33					




[illegible]

FIG. 31 HOOD SYSTEM (EXCEPT M TYPE)



1593-601B-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SG153H					
1	1593-601-500-51	HOOD/A COMP	*	1			4G		
2	1593-601-062-20	SEAL/20X10X690	*	1					
3	1593-601-067-30	TRIM/1X06X570	*	1					
4	1593-601-071-00	SEAL(20X10X130)	*	1					
5	1593-601-072-00	TRIM/1X6X360	*	2					
6	3661-212-001-00	LINING/50	*	2					
7	V210-360-601-60	BOLT(SP)/M6X16	*	6					
8	3610-631-002-00	HANGER,SUPPORT	*	2					
9	V211-260-801-60	BOLT,SEMS (S) M8X16	*	2					
10	1593-601-009-00	NET/100X388	*	1					
11	4301-210-002-00	BOLT (S/N6X16)	*	2					
12	1593-601-072-00	TRIM/1X6X360	*	2					
13	1593-601-015-00	INSULATOR/HOOD	*	3					
14	1593-601-002-41	COVER/FRONT/MESH	*	1			8E		
15	V350-160-006-00	NUT,SPEED/P6	*	3					
16	1593-601-011-10	COVER/FRONT/LH	*	1		1			
17	V120-366-001-60	SCREW	*	3					
18	1527-604-002-00	CLIP(B)	*	1					
19	V411-260-008-00	WASHER,PL/M 8	*	1					
20	1593-601-012-00	COVER/FRONT/C	*	1					
21	1593-601-013-10	COVER/FRONT/RH	*	1		1			
22	V120-366-001-60	SCREW	*	3					
23	1527-604-002-00	CLIP(B)	*	1					
24	V411-260-008-00	WASHER,PL/M 8	*	1					
25	1593-601-300-00	COVER/LOWER ASSY	*	1					
26	1593-601-524-10	NET,LOWER COVER/LH	*	1					
27	1593-601-525-10	NET,LOWER COVER/RH	*	1					
28	V350-160-004-00	NUT,SPEED/P4	*	33					
29	V361-260-006-00	NUT	*	4					
30	1593-601-064-20	SEAL/15X20X170	*	2					

[illegible]





[illegible]



[illegible]


FIG. 37 HARNESS SYSTEM (EXCEPT S TYPE)



1608-623B-0100

[illegible]


FIG. 38 HARNESS SYSTEM (S TYPE)



1608-623C-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SG153H					
1	1608-623-210-00	HARNESS/MAIN/S ASSY	*	1 -301505					
1A	1608-623-210-10	HARNESS/MAIN/S ASSY	*	1 301506-		1			
2	1575-623-009-00	FUSE/32V03A	*	1					
3	1575-623-010-00	FUSE/32V10A	*	3					
4	1593-623-503-00	CAP,FUSE BOX	*	1					
5	3650-262-202-00	DIODE/3.0A	*	1					
6	1593-623-504-00	SHORT COUPLER/REAR/P	*	1					
7	1593-623-610-00	HARNESS/GENERATOR	*	1					
8	3650-261-261-00	LINK,FUSIBLE	*	1					
9	V301-260-006-00	NUT/M 6	*	1					
10	V411-260-006-00	WASHER / M6	*	1					
11	V401-160-006-00	WASHER,SP/M 6	*	1					
12	1593-623-002-00	GROMMET/150	*	2					
13	1593-623-001-00	GROMMET	*	1					
14	1593-623-003-00	BAND	*	3					
15	3737-172-010-00	BAND/202	*	15					
16	3746-185-014-00	BAND,HOSE	*	3					
17	1581-621-290-00	RELAY/4P	*	1					
18	V120-366-001-60	SCREW	*	1					
19	1560-664-250-00	SWITCH/PUSH SET	*	1					
20	1560-664-252-00	NUT	*	1					
21	1560-664-253-00	BOOT	*	1					
22	1593-623-520-00	SWITCH,MERIT	*	1					
23	V111-163-002-00	SCREW M3X20	*	2					
24	V401-160-003-00	WASHER,SP/M 3	*	2					
25	V411-260-003-00	WASHER/M3	*	2					
26	3664-276-001-00	PLATE/IRX13X35	*	1 -302216					
26A	3642-496-007-10	PLATE,SWITCH	*	1 302217-					

FIG. 39 MARK




(KEY8~13 FOR EXCEPT M TYPE)

1608-901D-0100,1608-901F-0100

[illegible]

FIG. 41 LABEL (FRENCH) (E50 TYPE EXCEPT T)



1608-905A-0100

[illegible]



[illegible]

FIG. 45 TOOL



1593-930 -0100,1608-930 -0100

[illegible]



[illegible]


FIG. 47 REAR PTO SYSTEM (OPTION)



1608-341B-0101


KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SG153H					
1	1608-341-300-40	PTO/REAR SET	T	1					
2	1608-341-210-30	SHAFT,JOINT/PTO	T	1					
3	V720-102-401-50	O-RING/P15	T	1					
4	V760-150-000-00	NIPPLE,GREASE	T	1					
5	1608-341-001-20	METAL/PTO	T	1					
6	1608-341-026-00	PLATE(L/16X101)	T	1					
7	V210-260-601-20	BOLT/S	T	2					
8	V211-561-002-00	BOLT/M10X20	T	2					
9	V600-150-620-20	BEARING,RB/6202SS	T	2					
10	V705-140-035-00	RING,CIRCLIP	T	2					
11	1608-341-003-20	PULLEY/VC100	T	1					
12	V334-460-010-00	NUT/M10 7T P=1.25	T	2					
13	V401-160-010-00	WASHER,SP/M10	T	1					
14	1608-341-220-20	ARM,TENTION COMP	T	1					
15	V704-140-012-00	RING,SNAP/12 C	T	1					
16	3737-122-001-00	PULLEY,TENSION	T	1					
17	V704-140-015-00	RING,SNAP/15 C	T	1					
18	1608-341-006-10	PULLEY(VC135)	T	1					
19	V334-460-010-00	NUT/M10 7T P=1.25	T	2					
20	V401-160-010-00	WASHER,SP/M10	T	1					
21	1608-341-330-00	COVER (BELT)	T	1					
22	V210-360-601-20	BOLT,SEMS	T	4					
23	1608-341-008-00	BELT/VC-31	T	1					
24	1608-341-230-20	LEVER (PTO)	T	1					
25	3517-205-007-00	WASHER	T	1					
26	V500-163-002-50	PIN,SPLIT/3 X25	T	1					
27	1608-341-270-00	STAY/LEVER ASSY	T	1					
28	1608-341-240-30	STAY/LEVER COMP	T	1					
29	1593-623-520-00	SWITCH,MERIT	T	1					
30	3664-276-001-00	PLATE/IRX13X35	T	1	-302216				

FIG. 47 REAR PTO SYSTEM (OPTION)




1608-341B-0101


KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SG153H					
30A	3642-496-007-10	PLATE,SWITCH	T	1					
31	V111-163-002-00	SCREW M3X20	T	2					
32	V401-160-003-00	WASHER,SP/M 3	T	2					
33	V411-260-003-00	WASHER/M3	T	2					
34	4106-105-303-00	KNOB	T	1					
35	V363-260-008-00	NUT/WASHER	T	2					
36	1608-341-023-00	ROD(REAR PTO)	T	1					
37	V411-260-008-00	WASHER,PL/M 8	T	2					
38	V500-162-501-50	PIN,SPLIT/2.5X15	T	2					
39	1608-341-260-30	SHAFT COMP	T	1					
40	V704-140-015-00	RING,SNAP/15 C	T	1					
41	1608-341-021-10	ARM (40)	T	1					
42	V201-260-805-00	BOLT/M 8X50	T	1					
43	V411-260-008-00	WASHER,PL/M 8	T	2					
44	V304-260-008-00	NUT	T	2					
45	3728-552-008-00	TRIGGER,TENSION	T	1					
46	V304-260-008-00	NUT	T	2					
47	1337-401-006-00	SPRING	T	1					
48	1608-341-025-10	PLATE(RETURN)	T	1					
49	1415-125-021-00	SPRING,TENSION/46	T	1					
50	V211-561-002-00	BOLT/M10X20	T	2					
51	1593-342-001-00	PLATE/170X215	T	1					
52	V211-261-002-50	BOLT(S) M10X25	T	4					
53	1608-341-200-00	CASE(PTO/FRONT)	T	1					
54	1608-341-027-00	BUSH(12X14X20)	T	1					
55	V744-120-350-70	SEAL,OIL/TC20357	T	1					
56	V211-260-802-00	BOLT/S	T	5					
57	V211-260-803-00	BOLT,SEMS	T	1					
58	1608-341-012-00	CASE(PTO/RAER)	T	1					
59	V744-135-550-80	SEAL,OIL/TC35558	T	1					




[illegible]

[illegible]

[illegible]

[illegible]




Switch	connection
SWse:On	: Sit on the seat
SWrp:On	: Disengage the front PTO
SWrp:On	: Disengage the rear PTO
SWb :On	: Depress the brake pedal
SWc :On	: Fill the collector with grass
SWt :On	: At the over heated
SWo :On	: At the low oil pressure
SWhl:On	: The lever turns up

Optional parts

ST	: Starter (0.8kW)
G	: Generator (8.5A)
H	: Hour meter
P	: Pump
BZ	: Buzzer
Rst	: Starter relay
Rfs	: Fuel shut-off relay
Rswt	: Starter switch
SWse	: Seat switch
SWfp	: Front PTO switch
SWrp	: Rear PTO switch
SWb	: Brake switch
SWc	: Collector switch
SWt	: Temperature switch
SWo	: Oil pressure switch
SWhl	: Head lights switch
FSS	: Fuel shut-off solenoid
CHG	: Charge lamp (3.4W)
TEMP	: Temperature lamp (3.4W)
OIL	: Oil pressure lamp (3.4W)

REAL WIRING DIAGRAM/SG153/S



Numerical Index

6003-097-120-10

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
6211-110-018-20	1 1	6209-587-001-00	15 4	6211-292-001-20	29 11
1373-121-001-00	10 41	6209-600-002-00	7 2	6211-310-006-20	10 1
	27 5	6209-600-004-00	10 24-A	6211-310-006-30	10 1-A
3625-540-004-00	10 21	6209-605-004-00	1 3	6211-311-005-10	10 35
3747-172-012-00	21 31	6209-605-004-10	1 3-A	6211-311-005-20	10 35-A
3748-172-007-00	28 8	6209-610-001-00	5 3	6211-311-005-30	10 35-B
3817-401-001-00	10 12	6209-610-001-10	5 3-A	6211-312-001-20	10 27
	10 40	6209-610-002-10	10 4	6211-312-001-30	10 27-A
	12 19	6209-610-008-00	5 7-A		29 14
	20 14	6209-610-009-00	5 4-A	6211-312-002-20	10 36
	20 19	6209-623-001-00	7 3	6211-312-002-30	10 36-A
	21 14	6209-625-001-00	5 14		29 15
	21 19		29 10	6211-340-001-30	8 1
6209-000-002-00	12 18	6209-625-002-00	10 5	6211-340-002-30	9 1
6209-000-003-00	1 7		29 12	6211-342-001-30	8 2
6209-000-004-10	5 2	6209-625-012-00	5 14-A		9 2
6209-000-013-00	18 7		29 10-A	6211-361-019-10	7 1
6209-000-043-00	18 10-A	6209-630-002-10	28 6	6211-510-002-00	5 10
6209-000-044-00	1 7-A		29 21	6211-511-003-00	5 11
6209-030-041-00	22 4	6209-730-005-00	13 3-A	6211-511-004-00	5 12
6209-030-043-00	24 16		24 10-A	6211-540-002-00	6 1
6209-044-001-00	24 25	6209-730-006-00	18 4-A	6211-560-002-00	6 3
6209-046-015-00	18 7-A	6209-740-001-00	10 26	6211-599-001-10	5 13
6209-050-001-00	10 32	6209-749-001-10	5 15		6 2
6209-050-002-00	10 33	6209-749-001-20	5 15-A		6 4
6209-056-001-00	24 7	6209-788-001-00	5 27	6211-751-001-10	2 2
6209-300-002-00	20 17	6209-920-002-00	10 20	6211-760-003-10	5 29
	21 17		19 14-A	6211-777-007-30	11 1
6209-300-014-00	1 8-A		29 13	6212-111-015-00	14 1
6209-360-010-00	25 2	6209-940-004-00	12 14	6212-111-015-10	14 1-A
6209-360-028-10	2 6	6211-110-061-10	1 1-A	6212-111-080-10	15 1
6209-409-001-00	10 18	6211-110-061-20	1 1-B	6212-114-015-00	16 1
6209-409-003-00	12 17	6211-141-018-10	1 6	6212-114-015-10	16 1-A
6209-440-003-00	14 7-A		29 3	6212-114-080-10	17 1
6209-490-002-00	2 4	6211-170-006-10	2 1	6212-116-015-00	16 3
6209-490-002-10	2 4-A	6211-173-004-00	2 3	6212-116-015-10	16 3-A
6209-500-003-00	10 16		29 4	6212-116-080-10	17 3
	10 25	6211-210-021-10	5 1	6212-121-008-00	14 2
	29 22	6211-210-021-20	5 1-A	6212-121-008-10	14 2-A
6209-572-002-00	2 5-A	6211-258-001-00	5 8	6212-121-008-20	14 2-B
	29 5-A		29 8		15 2
6209-572-003-00	2 5-B	6211-258-002-00	5 9	6212-124-008-00	16 2
	29 5-B		29 9	6212-124-008-10	16 2-A
6209-580-002-10	24 28	6211-291-001-10	5 23		17 2
6209-587-001-00	14 4	6211-292-001-20	5 24	6212-126-008-00	16 4

Numerical Index

6003-097-120-10

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
6212-126-008-10	16	4-A	6212-552-001-20	12	2-B	6213-319-001-00	10	2
	17	4	6212-552-014-00	12	2-C	6213-610-005-30	20	1
6212-211-001-10	14	3	6212-561-001-00	12	3	6213-610-005-40	21	1
	15	3	6212-561-001-10	12	3-A	6213-611-003-20	20	2
6212-230-003-00	14	5	6212-563-001-00	12	4		21	2
6212-230-003-10	14	5-A	6212-565-001-00	12	5	6213-612-004-00	20	9
	15	5	6212-569-002-00	1	4		21	9
6212-235-001-00	14	6		29	2	6213-613-002-10	20	8
6212-235-001-10	14	6-A	6212-571-001-10	12	6		21	8
6212-235-005-00	14	6-B	6212-571-003-00	12	6-A	6213-614-003-10	20	12
6212-261-006-00	15	6	6212-571-006-00	12	6-B		21	12
	14	8	6212-575-001-00	12	7		29	17
6212-271-006-00	14	8-A	6212-600-003-00	12	8	6213-614-006-10	20	16
	15	7	6212-600-003-10	12	8-A		21	16
6212-271-016-00	15	7-A	6212-611-004-10	12	9		29	18
6212-274-016-00	6	5	6212-616-002-00	12	16	6213-619-002-00	20	11
6212-276-016-00	6	6	6212-620-002-10	12	10		21	11
6212-310-010-00	18	1	6212-620-002-20	12	10-A	6213-619-003-00	20	10
6212-310-010-10	18	1-A	6212-626-002-10	12	11		21	10
6212-310-010-20	18	1-B	6212-628-004-00	12	12	6213-619-005-00	20	15
6212-310-010-30	18	1-C	6212-628-005-00	12	13		21	15
6212-310-010-50	18	1-D	6213-100-003-20	19	1	6213-621-003-00	20	6
6212-330-013-30	18	5	6213-100-003-30	19	1-A		21	6
6212-333-001-00	18	6	6213-111-001-20	19	2	6213-622-002-10	20	5
6212-333-003-00	18	6-A	6213-111-001-30	19	2-A		21	5
6212-371-014-20	18	8	6213-119-001-00	19	6	6213-631-002-00	20	3
6212-379-001-00	18	9	6213-120-003-00	19	3		21	3
6212-511-004-00	13	1	6213-120-003-20	19	3-A	6213-631-005-00	20	4
6212-521-002-00	18	3	6213-125-001-00	19	4		21	4
6212-521-008-00	18	3-A	6213-129-003-00	19	5-A	6213-641-004-00	22	2
6212-522-003-00	13	2	6213-129-005-00	5	17	6213-641-004-10	22	2-A
6212-522-010-00	13	2-A	6213-129-006-00	5	16	6213-642-002-00	20	7
6212-523-003-00	13	6	6213-140-004-10	19	8		21	7
6212-523-023-00	13	6-A	6213-140-004-20	19	8-A	6213-660-006-00	22	1
6212-524-002-00	24	9	6213-149-001-00	19	10	6213-669-002-00	22	3
6212-524-002-10	24	9-A	6213-160-002-00	10	28	6213-671-012-00	22	5
6212-524-002-20	24	9-B	6213-160-002-10	10	28-A	6213-674-004-10	27	3
6212-531-005-10	5	6	6213-160-002-20	10	28-B	6213-674-004-20	27	3-A
6212-535-001-00	13	4	6213-161-001-00	10	29	6213-711-003-20	20	28
6212-535-002-00	24	13	6213-161-001-10	10	29-A		21	28
6212-551-001-00	12	1	6213-161-001-20	10	29-B	6213-716-001-40	20	22
6212-551-001-10	12	1-A	6213-164-001-00	10	30		21	22
6212-551-028-00	12	1-B	6213-240-002-00	19	15	6213-716-001-50	21	22-A
6212-552-001-00	12	2	6213-240-002-10	19	15-A	6213-721-001-00	5	22
6212-552-001-10	12	2-A	6213-311-003-10	19	12	6213-721-003-00	20	23

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
6213-721-003-00	21 23	6215-345-047-00	32 5	6215-549-003-00	24 22
6213-729-001-00	20 20	6215-345-048-00	30 9	6215-549-007-00	24 30
6213-729-013-10	21 20		31 8	6215-549-007-10	24 30-A
6213-743-002-10	20 24		32 6	6215-549-008-00	24 34
	21 24	6215-345-049-00	30 10	6215-549-008-10	24 34-A
	29 19		31 9	6215-549-021-00	24 29
6214-111-014-00	3 1		32 7	6215-549-021-10	24 29-A
6214-115-002-20	3 2	6215-345-050-00	30 11	6215-549-029-00	26 2
	29 6		31 10	6215-600-057-00	24 1
6214-141-015-00	4 1		32 8	6215-600-057-10	24 1-A
6214-145-006-10	4 2	6215-345-051-00	30 12	6215-611-003-00	33 1
	29 7		31 11	6215-612-003-00	33 34
6215-300-005-00	23 1		32 9	6215-619-012-00	33 35
6215-300-030-00	23 1-A	6215-345-052-00	30 13	6215-619-013-00	33 37
6215-300-037-00	23 1-B		31 12	6215-619-014-00	33 38
6215-311-005-00	30 1		32 10	6215-619-015-00	33 39
	31 18	6215-345-053-00	30 14	6215-619-016-00	33 40
	32 16		31 13	6215-621-004-10	24 8
6215-315-002-00	23 2		32 11	6215-621-004-20	24 8-A
6215-330-007-00	30 2	6215-355-003-00	30 18	6215-622-002-00	33 12
6215-330-021-00	31 1	6215-359-003-00	30 17	6215-629-017-00	33 13
6215-330-022-00	32 1		31 16	6215-629-019-00	33 14
6215-332-002-00	30 16		32 17	6215-629-020-00	33 18
	31 15	6215-359-004-00	30 19	6215-629-021-00	33 19
6215-332-006-00	32 15		31 17	6215-629-022-00	33 20
6215-339-002-00	30 15		32 18	6215-629-023-00	33 21
	31 14	6215-410-035-10	23 3	6215-629-024-00	33 22
6215-339-004-00	32 14	6215-410-036-10	23 4	6215-629-025-00	33 23
6215-342-002-00	30 3	6215-411-079-10	25 2-A	6215-629-026-00	33 24
	31 2	6215-411-111-00	23 3-A	6215-629-027-00	33 25
	32 13	6215-411-112-00	23 4-A	6215-629-028-00	33 26
6215-343-002-00	30 4	6215-412-001-20	25 1	6215-629-029-00	33 27
	31 3	6215-520-001-00	24 15	6215-629-030-00	33 28
	32 12	6215-526-001-10	24 17	6215-629-031-00	33 29
6215-345-044-00	30 5	6215-526-004-00	24 17-A	6215-629-032-00	33 30
	31 4	6215-531-005-00	24 23	6215-629-033-00	33 31
	32 2	6215-541-001-00	24 18	6215-629-034-00	33 32
6215-345-045-00	30 6	6215-541-001-10	24 18-A	6215-631-004-00	33 2
	31 5	6215-541-002-10	26 1	6215-634-002-00	33 15
	32 3	6215-541-003-10	24 24	6215-635-002-00	33 8
6215-345-046-00	30 7	6215-542-001-10	10 22	6215-635-003-00	33 36
	31 6	6215-542-002-00	24 20	6215-635-008-00	33 36-A
	32 4	6215-543-003-20	24 19	6215-637-003-00	33 33
6215-345-047-00	30 8	6215-546-001-00	10 17	6215-639-006-00	33 16
	31 7	6215-549-001-10	5 26	6215-639-007-00	33 17

Numerical Index

6003-097-120-10

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
6215-641-002-00	33	3	6281-229-022-00	35	6	6904-110-818-00	5	19
6215-643-003-00	33	4	6281-229-023-00	35	7	6904-110-840-00	5	18
6215-644-003-00	33	6	6281-229-024-00	35	8	6908-000-716-00	13	3
6215-649-003-00	33	5	6281-229-025-00	35	9		24	10
6215-649-004-00	33	7	6281-229-025-10	35	9-A		18	4
6215-649-004-10	33	7-A	6281-229-026-00	35	10	6908-160-408-00	19	5
6215-649-005-00	33	9	6281-229-027-00	35	11	6908-161-018-00	18	2
6215-649-006-00	33	10	6281-229-028-00	35	12	6909-110-406-00	5	28
6215-649-006-10	33	10-A	6281-229-031-00	35	4		10	34
6215-649-007-00	33	11	6281-270-001-00	27	2		24	31
6219-732-003-00	28	4	6281-270-001-10	27	2-A	6909-110-408-00	34	23
6219-752-011-00	24	2	6281-270-001-20	27	2-B	6909-110-410-00	27	7
6219-752-012-00	24	3	6281-410-002-20	28	3	6909-111-406-00	24	26
6219-752-013-00	24	4	6281-410-010-00	28	3-A	6909-111-508-00	34	20
6219-752-014-00	24	5	6281-410-023-00	28	3-B	6909-150-508-00	34	22
6219-752-015-00	24	6	6281-910-001-00	28	5	6909-202-308-00	10	24
6219-752-036-00	24	3-A	6281-920-001-00	28	9	6909-572-008-00	2	5
6219-752-037-00	24	4-A	6281-971-001-10	28	1		29	5
6219-752-038-00	24	5-A	6287-810-006-20	29	1		1	8
6219-752-039-00	24	6-A	6294-453-002-00	5	20-A	6909-902-299-00	5	21
6281-100-003-00	27	8	6509-360-912-10	25	3	6909-906-105-10	19	13
6281-100-003-10	27	8-A	6509-605-019-10	5	5	6909-920-843-00	19	14
6281-111-002-00	34	1	6513-770-022-10	10	3	6911-129-006-00	1	2
6281-115-004-00	34	11		20	27	6911-129-083-00	5	7
6281-116-002-00	34	2		21	27	6911-219-195-00	5	4
6281-118-001-00	34	9	6515-419-014-00	25	4	J061-210-015-00	20	21
6281-121-003-00	34	3	6581-117-007-00	34	10		21	21
6281-124-001-00	34	6	6581-123-011-00	34	12		21	21-B
6281-129-006-00	34	17	6581-129-092-00	34	15	J062-062-067-00	25	6
6281-129-007-00	34	7	6581-129-096-00	34	16	J062-076-082-00	25	5
6281-129-008-00	34	18	6581-129-099-00	34	13	J062-138-148-00	21	21-A
6281-129-009-00	34	19	6581-129-100-00	34	14	V211-560-802-50	4	3
6281-129-010-00	34	4	6582-450-014-00	28	2	V230-360-601-00	7	4
6281-129-011-00	34	5	6894-240-902-00	14	7	V230-360-601-20	5	25
6281-129-019-00	34	21	6894-453-344-00	5	20		28	7
6281-151-004-00	34	8	6901-066-645-00	18	10	V231-360-801-60	10	13
6281-151-004-10	34	8-A	6901-910-612-00	13	5		19	11
6281-200-007-00	27	1	6901-910-625-00	24	14	V231-360-802-00	3	3
6281-211-004-00	35	2		19	7		20	18
6281-213-008-00	35	1		8	4		20	25
6281-213-016-10	35	1-A	6901-911-020-00	9	4	V231-360-802-50	21	18
6281-214-006-00	35	13		8	3		21	25
6281-222-007-00	35	3		9	3		27	4
6281-222-010-10	35	3-A	6901-911-025-00	27	9		10	39
6281-229-021-00	35	5	6902-050-816-00	10	37		20	30

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
V231-360-802-50	21 30				
V231-360-803-00	10 15				
V231-360-803-50	10 11				
V231-360-804-00	10 10				
	10 38				
V231-360-804-50	10 14				
	20 13				
	21 13				
V231-360-805-00	10 9				
V231-360-805-50	10 8				
V231-360-807-50	10 7				
	20 26				
	21 26				
V231-360-808-50	10 6				
V233-361-002-00	11 2				
V233-361-006-00	27 6				
V341-120-008-00	10 19				
V401-160-006-00	24 33				
V411-260-006-00	24 32				
V523-101-001-80	18 2-A				
V600-110-600-40	24 12				
V600-110-620-30	24 11				
V682-200-000-60	1 5				
V704-140-016-00	12 15				
V705-140-012-00	10 31				
V710-140-004-00	10 23				
	24 21				
	26 3				
V720-101-900-80	24 27				
V720-102-401-50	19 9				
V723-102-005-50	29 16				
	20 29				
	21 29				
	29 20				

Numerical Index

6003-097-130-10

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
6211-110-018-20	1 1	6209-587-001-00	14 4	6211-292-001-20	28 11
1373-121-001-00	9 41	6209-600-002-00	7 2	6211-310-006-20	9 1
	26 4	6209-600-004-00	9 24-A	6211-310-006-30	9 1-A
3625-540-004-00	9 21	6209-605-004-00	1 3	6211-311-005-10	9 35
3747-172-012-00	20 31	6209-605-004-10	1 3-A	6211-311-005-20	9 35-A
3748-172-007-00	27 8	6209-610-001-00	5 3	6211-311-005-30	9 35-B
3817-401-001-00	9 12	6209-610-001-10	5 3-A	6211-312-001-20	9 27
	9 40	6209-610-002-10	9 4	6211-312-001-30	9 27-A
	11 19	6209-610-008-00	5 7-A		28 14
	19 14	6209-610-009-00	5 4-A	6211-312-002-20	9 36
	19 19	6209-623-001-00	7 3	6211-312-002-30	9 36-A
	20 14	6209-625-001-00	5 14		28 15
	20 19		28 10	6211-340-002-20	8 1
6209-000-002-00	11 18	6209-625-002-00	9 5	6211-340-002-30	8 1-A
6209-000-003-00	1 7		28 12	6211-342-001-30	8 2
6209-000-004-10	5 2	6209-625-012-00	5 14-A	6211-361-019-10	7 1
6209-000-013-00	17 7		28 10-A	6211-510-002-00	5 10
6209-000-043-00	17 10-A	6209-630-002-10	27 6	6211-511-003-00	5 11
6209-000-044-00	1 7-A		28 21	6211-511-004-00	5 12
6209-030-041-00	21 4	6209-730-005-00	12 3-A	6211-540-002-00	6 1
6209-030-043-00	23 16		23 10-A	6211-560-002-00	6 3
6209-044-001-00	23 25	6209-730-006-00	17 4-A	6211-599-001-10	5 13
6209-046-015-00	17 7-A	6209-740-001-00	9 26		6 2
6209-050-001-00	9 32	6209-749-001-10	5 15		6 4
6209-050-002-00	9 33	6209-749-001-20	5 15-A	6211-751-001-10	2 2
6209-056-001-00	23 7	6209-788-001-00	5 27	6211-760-012-20	5 29
6209-300-002-00	19 17	6209-920-002-00	9 20	6211-777-007-20	10 1
	20 17		18 14-A	6211-777-007-30	10 1-A
6209-300-014-00	1 8-A		28 13	6212-111-015-00	13 1
6209-360-010-00	24 2	6209-940-004-00	11 14	6212-111-015-10	13 1-A
6209-360-028-10	2 6	6211-110-061-10	1 1-A	6212-111-080-10	14 1
6209-409-001-00	9 18	6211-110-061-20	1 1-B	6212-114-015-00	15 1
6209-409-003-00	11 17	6211-141-018-10	1 6	6212-114-015-10	15 1-A
6209-440-003-00	13 7-A		28 3	6212-114-080-10	16 1
6209-490-002-00	2 4	6211-170-006-10	2 1	6212-116-015-00	15 3
6209-490-002-10	2 4-A	6211-173-004-00	2 3	6212-116-015-10	15 3-A
6209-500-003-00	9 16		28 4	6212-116-080-10	16 3
	9 25	6211-210-021-10	5 1	6212-121-008-00	13 2
	28 22	6211-210-021-20	5 1-A	6212-121-008-10	13 2-A
6209-572-002-00	2 5-A	6211-258-001-00	5 8	6212-121-008-20	13 2-B
	28 5-A		28 8		14 2
6209-572-003-00	2 5-B	6211-258-002-00	5 9	6212-124-008-00	15 2
	28 5-B		28 9	6212-124-008-10	15 2-A
6209-580-002-10	23 28	6211-291-001-10	5 23		16 2
6209-587-001-00	13 4	6211-292-001-20	5 24	6212-126-008-00	15 4

Numerical Index

6003-097-130-10

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
6212-126-008-10	15	4-A	6212-552-001-20	11	2-B	6213-319-001-00	9	2
	16	4	6212-552-014-00	11	2-C	6213-610-005-30	19	1
	13	3	6212-561-001-00	11	3	6213-610-005-40	20	1
	14	3	6212-561-001-10	11	3-A	6213-611-003-20	19	2
6212-230-003-00	13	5	6212-563-001-00	11	4		20	2
6212-230-003-10	13	5-A	6212-565-001-00	11	5	6213-612-004-00	19	9
	14	5	6212-569-002-00	1	4		20	9
6212-235-001-00	13	6		28	2	6213-613-002-10	19	8
6212-235-001-10	13	6-A	6212-571-001-10	11	6		20	8
6212-235-005-00	13	6-B	6212-571-003-00	11	6-A	6213-614-003-10	19	12
6212-261-006-00	14	6	6212-571-006-00	11	6-B		20	12
	13	8	6212-575-001-00	11	7		28	17
	13	8-A	6212-600-003-00	11	8	6213-614-006-10	19	16
	14	7	6212-600-003-10	11	8-A		20	16
6212-271-016-00	14	7-A	6212-611-004-10	11	9		28	18
6212-274-016-00	6	5	6212-616-002-00	11	16	6213-619-002-00	19	11
6212-276-016-00	6	6	6212-620-002-10	11	10		20	11
6212-310-010-00	17	1	6212-620-002-20	11	10-A	6213-619-003-00	19	10
6212-310-010-10	17	1-A	6212-626-002-10	11	11		20	10
6212-310-010-20	17	1-B	6212-628-004-00	11	12	6213-619-005-00	19	15
6212-310-010-30	17	1-C	6212-628-005-00	11	13		20	15
6212-310-010-50	17	1-D	6213-100-003-20	18	1	6213-621-003-00	19	6
6212-330-013-30	17	5	6213-100-003-30	18	1-A		20	6
6212-333-001-00	17	6	6213-111-001-20	18	2	6213-622-002-10	19	5
6212-333-003-00	17	6-A	6213-111-001-30	18	2-A		20	5
6212-371-014-20	17	8	6213-119-001-00	18	6	6213-631-002-00	19	3
6212-379-001-00	17	9	6213-120-003-00	18	3		20	3
6212-511-004-00	12	1	6213-120-003-20	18	3-A	6213-631-005-00	19	4
6212-521-002-00	17	3	6213-125-001-00	18	4		20	4
6212-521-008-00	17	3-A	6213-129-003-00	18	5-A	6213-641-004-00	21	2
6212-522-003-00	12	2	6213-129-005-00	5	17	6213-641-004-10	21	2-A
6212-522-010-00	12	2-A	6213-129-006-00	5	16	6213-642-002-00	19	7
6212-523-003-00	12	6	6213-140-004-10	18	8		20	7
6212-523-023-00	12	6-A	6213-140-004-20	18	8-A	6213-660-006-00	21	1
6212-524-002-00	23	9	6213-149-001-00	18	10	6213-669-002-00	21	3
6212-524-002-10	23	9-A	6213-160-002-00	9	28	6213-671-003-00	21	5
6212-524-002-20	23	9-B	6213-160-002-10	9	28-A	6213-674-006-10	26	2
6212-531-005-10	5	6	6213-160-002-20	9	28-B	6213-674-006-20	26	2-A
6212-535-001-00	12	4	6213-161-001-00	9	29	6213-711-003-20	19	28
6212-535-002-00	23	13	6213-161-001-10	9	29-A		20	28
6212-551-001-00	11	1	6213-161-001-20	9	29-B	6213-716-001-40	19	22
6212-551-001-10	11	1-A	6213-164-001-00	9	30		20	22
6212-551-028-00	11	1-B	6213-240-002-00	18	15	6213-716-001-50	20	22-A
6212-552-001-00	11	2	6213-240-002-10	18	15-A	6213-721-001-00	5	22
6212-552-001-10	11	2-A	6213-311-003-10	18	12	6213-721-003-00	19	23

Numerical Index

6003-097-130-10

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
6213-721-003-00	20	23	6215-345-047-00	31	5	6215-549-003-00	23	22
6213-729-001-00	19	20	6215-345-048-00	29	9	6215-549-007-00	23	30
6213-729-013-10	20	20		30	8	6215-549-007-10	23	30-A
6213-743-002-10	19	24		31	6	6215-549-008-00	23	34
	20	24	6215-345-049-00	29	10	6215-549-008-10	23	34-A
	28	19		30	9	6215-549-021-00	23	29
6214-111-014-00	3	1		31	7	6215-549-021-10	23	29-A
6214-115-002-20	3	2	6215-345-050-00	29	11	6215-549-029-00	25	2
	28	6		30	10	6215-600-057-00	23	1
6214-141-015-00	4	1		31	8	6215-600-057-10	23	1-A
6214-145-006-10	4	2	6215-345-051-00	29	12	6215-611-003-00	32	1
	28	7		30	11	6215-612-003-00	32	34
6215-300-005-00	22	1		31	9	6215-619-012-00	32	35
6215-300-030-00	22	1-A	6215-345-052-00	29	13	6215-619-013-00	32	37
6215-300-037-00	22	1-B		30	12	6215-619-014-00	32	38
6215-311-005-00	29	1		31	10	6215-619-015-00	32	39
	30	18	6215-345-053-00	29	14	6215-619-016-00	32	40
	31	16		30	13	6215-621-004-10	23	8
6215-315-002-00	22	2		31	11	6215-621-004-20	23	8-A
6215-330-007-00	29	2	6215-355-003-00	29	18	6215-622-002-00	32	12
6215-330-021-00	30	1	6215-359-003-00	29	17	6215-629-017-00	32	13
6215-330-022-00	31	1		30	16	6215-629-019-00	32	14
6215-332-002-00	29	16		31	17	6215-629-020-00	32	18
	30	15	6215-359-004-00	29	19	6215-629-021-00	32	19
6215-332-006-00	31	15		30	17	6215-629-022-00	32	20
6215-339-002-00	29	15		31	18	6215-629-023-00	32	21
	30	14	6215-410-035-10	22	3	6215-629-024-00	32	22
6215-339-004-00	31	14	6215-410-036-10	22	4	6215-629-025-00	32	23
6215-342-002-00	29	3	6215-411-079-10	24	2-A	6215-629-026-00	32	24
	30	2	6215-411-111-00	22	3-A	6215-629-027-00	32	25
	31	13	6215-411-112-00	22	4-A	6215-629-028-00	32	26
6215-343-002-00	29	4	6215-412-001-20	24	1	6215-629-029-00	32	27
	30	3	6215-520-001-00	23	15	6215-629-030-00	32	28
	31	12	6215-526-001-10	23	17	6215-629-031-00	32	29
6215-345-044-00	29	5	6215-526-004-00	23	17-A	6215-629-032-00	32	30
	30	4	6215-531-005-00	23	23	6215-629-033-00	32	31
	31	2	6215-541-001-00	23	18	6215-629-034-00	32	32
6215-345-045-00	29	6	6215-541-001-10	23	18-A	6215-631-004-00	32	2
	30	5	6215-541-002-10	25	1	6215-634-002-00	32	15
	31	3	6215-541-003-10	23	24	6215-635-002-00	32	8
6215-345-046-00	29	7	6215-542-001-10	9	22	6215-635-003-00	32	36
	30	6	6215-542-002-00	23	20	6215-635-008-00	32	36-A
	31	4	6215-543-003-20	23	19	6215-637-003-00	32	33
6215-345-047-00	29	8	6215-546-001-00	9	17	6215-639-006-00	32	16
	30	7	6215-549-001-10	5	26	6215-639-007-00	32	17

Numerical Index

6003-097-130-10

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
6215-641-002-00	32 3	6281-214-004-00	35 13	6281-229-018-00	35 25
6215-643-003-00	32 4	6281-215-001-00	34 17	6281-229-029-00	34 14
6215-644-003-00	32 6		35 17	6281-229-032-00	34 6
6215-649-003-00	32 5	6281-216-001-00	34 18	6281-229-033-00	34 11-A
6215-649-004-00	32 7		35 18	6281-271-002-00	34 26
6215-649-004-10	32 7-A	6281-217-001-00	34 16		35 26
6215-649-005-00	32 9		35 16	6281-410-002-20	27 3
6215-649-006-00	32 10	6281-217-002-00	34 16-A	6281-410-010-00	27 3-A
6215-649-006-10	32 10-A	6281-221-001-00	34 4	6281-410-023-00	27 3-B
6215-649-007-00	32 11		35 4	6281-910-001-00	27 5
6219-732-003-00	27 4	6281-221-007-00	34 4-A	6281-920-001-00	27 9
6219-752-011-00	23 2	6281-222-004-00	34 1	6281-971-001-10	27 1
6219-752-012-00	23 3		35 1	6287-810-006-20	28 1
6219-752-013-00	23 4	6281-229-002-00	34 2	6294-453-002-00	5 20-A
6219-752-014-00	23 5		35 2	6509-360-912-10	24 3
6219-752-015-00	23 6	6281-229-003-00	34 3	6509-605-019-10	5 5
6219-752-036-00	23 3-A		35 3		9 3
6219-752-037-00	23 4-A	6281-229-004-00	34 5-A	6513-770-022-10	19 27
6219-752-038-00	23 5-A		35 6		20 27
6219-752-039-00	23 6-A	6281-229-005-00	34 5	6515-419-014-00	24 4
6281-100-003-00	26 7		35 5	6581-117-007-00	33 10
6281-100-003-10	26 7-A	6281-229-006-00	34 8	6581-123-011-00	33 12
6281-111-002-00	33 1		35 8	6581-129-092-00	33 15
6281-115-004-00	33 11	6281-229-007-00	34 9	6581-129-096-00	33 16
6281-116-002-00	33 2		35 9	6581-129-099-00	33 13
6281-118-001-00	33 9	6281-229-008-00	34 10	6581-129-100-00	33 14
6281-121-003-00	33 3		35 11	6582-450-014-00	27 2
6281-124-001-00	33 6	6281-229-009-00	34 11	6894-240-902-00	13 7
6281-129-006-00	33 17		35 10	6894-453-344-00	5 20
6281-129-007-00	33 7	6281-229-010-00	35 14	6901-066-645-00	17 10
6281-129-008-00	33 18	6281-229-011-00	34 15	6901-910-612-00	12 5
6281-129-009-00	33 19		35 15		23 14
6281-129-010-00	33 4	6281-229-012-00	34 19	6901-910-625-00	18 7
6281-129-011-00	33 5		35 19	6901-910-816-00	8 4
6281-129-019-00	33 21	6281-229-013-00	34 20	6901-911-020-00	8 3
6281-151-004-00	33 8		35 20	6901-911-025-00	26 8
6281-151-004-10	33 8-A	6281-229-014-00	34 21	6902-050-816-00	9 37
6281-200-005-00	26 1-A		35 21	6904-110-818-00	5 19
6281-200-016-00	26 1	6281-229-015-00	34 22	6904-110-840-00	5 18
6281-213-003-00	35 7		35 22	6908-000-716-00	12 3
6281-213-006-00	34 7	6281-229-016-00	34 23		23 10
6281-213-018-00	34 7-A		35 23	6908-000-750-00	17 4
6281-214-003-00	34 12	6281-229-017-00	34 24	6908-160-408-00	18 5
	35 12		35 24	6908-161-018-00	17 2
6281-214-004-00	34 13	6281-229-018-00	34 25	6909-110-406-00	5 28

Numerical Index

6003-097-130-10

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
6909-110-406-00	9 34	V231-360-805-00	9 9		
	23 31	V231-360-805-50	9 8		
6909-110-408-00	33 23	V231-360-807-50	9 7		
6909-110-410-00	26 6		19 26		
6909-111-406-00	23 26		20 26		
6909-111-508-00	33 20	V231-360-808-50	9 6		
6909-150-508-00	33 22	V233-361-002-00	10 2		
6909-202-308-00	9 24	V233-361-007-00	26 5		
6909-572-008-00	2 5	V341-120-008-00	9 19		
	28 5	V401-160-006-00	23 33		
6909-830-212-00	1 8	V411-260-006-00	23 32		
6909-902-299-00	5 21	V523-101-001-80	17 2-A		
6909-906-105-10	18 13	V600-110-600-40	23 12		
6909-920-843-00	18 14	V600-110-620-30	23 11		
6911-129-006-00	1 2	V682-200-000-60	1 5		
6911-129-083-00	5 7	V704-140-016-00	11 15		
6911-219-195-00	5 4	V705-140-012-00	9 31		
J061-210-015-00	19 21	V710-140-004-00	9 23		
	20 21		23 21		
	20 21-B		25 3		
J062-062-067-00	24 6	V720-101-900-80	23 27		
J062-076-082-00	24 5	V720-102-401-50	18 9		
J062-138-148-00	20 21-A		28 16		
V211-560-802-50	4 3	V723-102-005-50	19 29		
V230-360-601-00	7 4		20 29		
V230-360-601-20	5 25		28 20		
	27 7				
V231-360-801-60	9 13				
	18 11				
V231-360-802-00	3 3				
	19 18				
	19 25				
	20 18				
	20 25				
	26 3				
V231-360-802-50	9 39				
	19 30				
	20 30				
V231-360-803-00	9 15				
V231-360-803-50	9 11				
V231-360-804-00	9 10				
	9 38				
V231-360-804-50	9 14				
	19 13				
	20 13				

Numerical Index

1608-097-100-10

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
1323-220-012-00	17 10	1560-104-010-40	3 16	1593-103-054-00	4 2
1337-401-006-00	18 15	1560-132-007-30	18 14	1593-103-500-10	4 1
	47 47	1560-664-250-00	37 13	1593-104-001-40	4 12
1376-121-001-00	23 23		38 19	1593-104-004-00	4 13
1376-606-005-00	34 16	1560-664-252-00	37 14	1593-104-500-00	4 6
1386-241-002-00	19 4		38 20	1593-104-502-00	4 7
	26 4	1560-664-253-00	37 15	1593-105-213-10	5 10
	46 4		38 21	1593-112-002-50	6 5
1415-120-006-00	15 4	1564-512-001-00	24 2		7 4
	18 16	1564-654-213-00	49 4	1593-112-003-20	6 8
1415-125-021-00	47 49	1575-623-009-00	37 2		7 7
1416-209-005-00	9 18		38 2	1593-112-051-30	6 4
1416-600-057-00	32 9	1575-623-010-00	37 3		7 3
	33 9		38 3	1593-112-200-10	6 1
1416-600-057-10	32 9-A	1581-621-290-00	37 11	1593-112-222-00	6 9
	33 9-A		38 17		7 8
1424-101-203-00	3 17	1588-105-210-00	5 5	1593-112-510-30	6 3
1424-101-204-00	3 18	1593-101-003-20	1 6		7 2
1425-621-004-00	3 9		2 6	1593-112-520-10	6 12
	4 4	1593-101-009-10	1 12		7 11
1427-130-260-00	21 18		2 12	1593-117-001-40	8 3
1427-601-003-00	20 4	1593-101-011-10	1 13	1593-117-003-10	8 6
1427-621-002-10	6 2		2 13	1593-117-200-20	8 1
1427-621-012-00	24 7	1593-101-012-00	1 14	1593-117-510-20	8 2
	32 2		2 14	1593-122-051-00	9 1
	33 2		14 49	1593-203-058-20	11 2
	36 12	1593-101-210-40	2 1	1593-304-008-00	16 3
1427-934-013-00	41 5	1593-101-210-50	2 1-A	1593-304-051-20	16 1
1427-941-016-00	42 5	1593-101-220-40	2 2	1593-304-053-10	16 6
1432-242-004-00	28 13	1593-101-220-50	1 2	1593-304-054-10	16 4
1435-201-220-00	13 6		2 2-A	1593-304-055-10	16 7
1444-122-002-00	18 12	1593-102-001-10	3 10	1593-304-057-10	16 8
1444-601-015-00	36 15	1593-102-002-10	3 11	1593-307-051-20	16 12
1444-621-008-00	34 18	1593-102-003-20	3 14		16 16
1444-621-311-00	36 6	1593-102-004-20	3 15	1593-307-052-10	16 13
1444-621-312-00	36 7	1593-102-005-30	3 6		16 17
1488-611-001-00	34 9	1593-102-006-50	3 21	1593-307-053-10	16 14
1524-122-001-00	18 6	1593-102-009-10	3 23		16 18
1527-604-002-00	30 18	1593-102-011-00	3 7	1593-310-054-20	17 6
	30 23	1593-102-012-00	3 22	1593-310-520-20	17 4
	31 18	1593-102-500-10	3 1	1593-310-540-00	17 9
	31 23	1593-102-502-00	3 2	1593-312-056-20	18 18
	35 17	1593-102-503-00	3 3		18 27
1544-104-204-00	4 9	1593-102-504-00	3 4	1593-317-201-00	19 2
1544-104-205-00	4 10	1593-102-505-00	3 5	1593-317-210-00	19 1

Numerical Index

1608-097-100-10

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
1593-332-051-30	20	9	1593-406-500-30	24	1	1593-601-067-30	30	3
1593-332-052-10	20	7	1593-407-002-00	25	6		31	3
1593-332-053-00	20	8	1593-407-004-40	25	3	1593-601-069-00	24	3
1593-332-520-30	20	1	1593-407-006-00	25	7	1593-601-071-00	30	4
1593-333-500-30	20	12	1593-407-007-20	25	14		31	4
1593-334-052-00	21	3	1593-407-051-70	25	1	1593-601-072-00	30	5
1593-334-054-30	21	2	1593-407-200-60	25	5		30	12
1593-334-055-00	21	4	1593-407-510-50	25	10		31	5
1593-334-056-50	21	1	1593-407-520-40	25	15		31	12
1593-334-300-20	21	11	1593-407-530-40	25	17	1593-601-073-00	30	33
1593-334-300-30	21	11-A	1593-411-001-10	26	6		30	33-A
1593-334-300-40	21	11-B	1593-411-052-20	26	7		31	33
1593-334-310-20	21	14	1593-411-053-20	21	18-A	1593-601-074-00	31	32
1593-335-058-00	21	20		26	8	1593-601-300-00	30	25
1593-335-500-50	21	16	1593-411-201-00	26	1		31	25
1593-335-500-60	21	16-A	1593-411-610-10	26	2	1593-601-500-51	31	1
1593-341-008-00	47	73	1593-553-003-20	27	7	1593-601-500-52	30	1
1593-341-009-00	47	74	1593-553-007-20	27	12	1593-601-524-10	30	26
1593-341-012-10	47	75	1593-553-280-00	27	6		31	26
1593-342-001-00	47	51	1593-553-280-10	27	6-A	1593-601-525-10	30	27
	48	2	1593-553-550-10	27	11		31	27
1593-342-200-00	48	1	1593-553-670-30	27	2	1593-606-006-10	32	5
1593-401-007-20	22	2	1593-555-011-00	29	1		33	5
1593-401-071-50	22	3	1593-555-012-00	29	2		35	14
1593-402-051-10	22	10	1593-555-013-00	29	3	1593-611-001-00	34	13
1593-402-210-00	22	9	1593-601-002-40	30	14	1593-611-011-20	34	2
1593-402-510-40	22	13	1593-601-002-41	31	14	1593-611-011-30	34	2-A
1593-403-001-10	23	11	1593-601-009-00	30	10	1593-611-013-00	34	10
1593-403-003-10	23	10		31	10	1593-611-014-00	34	15
1593-403-004-10	23	3	1593-601-011-10	31	16	1593-611-058-00	34	12
1593-403-005-00	23	27	1593-601-012-00	31	20	1593-611-200-51	34	8
1593-403-007-20	23	21	1593-601-013-10	31	21	1593-611-200-52	34	8
1593-403-009-00	23	4	1593-601-014-00	30	35	1593-612-004-00	35	1
1593-403-052-30	23	14		31	35	1593-612-005-00	35	2
1593-403-056-40	23	15	1593-601-015-00	30	13	1593-612-220-10	35	6
1593-403-058-30	23	25		31	13	1593-612-230-00	35	9
1593-403-500-80	23	1	1593-601-054-00	30	38	1593-616-004-20	32	3
1593-403-510-80	23	2		31	38		33	3
1593-403-530-60	23	18	1593-601-061-40	30	37		35	11
1593-406-004-00	24	10		31	37	1593-621-005-00	36	9
1593-406-005-10	24	9	1593-601-062-20	30	2	1593-621-250-10	36	4
1593-406-006-00	24	13		31	2	1593-621-252-00	36	5
1593-406-008-00	24	5	1593-601-064-20	30	30	1593-621-510-30	36	2
1593-406-240-10	24	12		31	30	1593-622-004-00	49	11
1593-406-250-00	24	8	1593-601-065-10	24	4	1593-622-211-10	36	13

Numerical Index

1608-097-100-10

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
1593-622-240-00	49 3	1600-112-232-00	7 14	1608-205-207-00	12 21
1593-622-250-00	49 2	1600-505-007-00	8 9	1608-205-208-00	12 22
1593-622-270-00	49 5	1600-902-023-00	40 5	1608-205-209-00	12 23
1593-622-272-00	49 7	1608-105-001-40	5 14	1608-205-211-00	12 24
1593-622-273-00	49 8	1608-105-003-30	5 21	1608-205-212-00	12 25
1593-622-274-00	49 9	1608-105-211-00	5 24	1608-205-213-00	12 26
1593-622-275-00	49 10	1608-105-221-00	5 8	1608-205-214-00	12 27
1593-622-280-00	49 1	1608-105-222-10	5 9	1608-205-215-00	12 28
1593-623-001-00	6 16	1608-105-223-00	5 11	1608-205-216-00	12 29
	7 17		5 15	1608-205-217-00	12 30
	37 7	1608-105-230-00	5 2	1608-205-218-00	12 31
	38 13	1608-105-240-20	5 18	1608-205-219-00	12 32
1593-623-002-00	37 6	1608-122-002-10	9 15	1608-205-221-00	12 33
	38 12	1608-122-003-00	9 5	1608-205-222-00	12 34
1593-623-003-00	37 8	1608-122-004-00	9 2	1608-205-223-00	12 35
	38 14	1608-122-200-50	9 6	1608-205-224-00	12 36
1593-623-272-00	34 4	1608-122-200-60	9 6-A	1608-205-225-00	12 37
1593-623-273-00	34 5	1608-122-206-00	9 7-A	1608-205-226-00	12 38
1593-623-280-00	34 3	1608-122-206-10	9 7-B	1608-205-227-00	12 59
1593-623-503-00	37 4	1608-122-207-00	9 8-A	1608-205-228-00	12 60
	38 4	1608-122-210-20	9 7	1608-205-229-00	12 61
1593-623-504-00	37 5	1608-122-220-20	9 8	1608-205-231-00	12 62
	38 6	1608-122-230-10	9 17	1608-205-232-00	12 64
1593-623-520-00	37 16	1608-201-001-40	10 1	1608-205-233-00	12 66
	38 22	1608-201-002-30	10 8	1608-205-234-00	12 39
	47 29	1608-201-002-40	10 8-A	1608-205-235-00	12 40
1593-623-610-00	38 7	1608-201-004-20	10 13	1608-205-236-00	12 41
1593-630-210-00	49 14	1608-201-005-10	10 17	1608-205-237-00	12 42
1593-630-211-00	49 15		10 17-A	1608-205-238-00	12 43
1593-630-230-00	49 13	1608-201-006-20	10 27	1608-205-239-00	12 44
1593-901-015-00	39 9	1608-201-008-10	10 30	1608-205-241-00	12 45
1593-901-016-00	39 1	1608-201-011-20	10 36	1608-205-242-00	12 46
1593-901-017-00	39 2	1608-201-013-00	10 28	1608-205-243-00	12 47
1593-901-019-00	39 4	1608-201-200-20	10 25	1608-205-244-00	12 48
1593-904-001-00	40 1	1608-203-002-30	11 4	1608-205-245-00	12 49
1593-904-012-00	40 3	1608-203-003-20	11 8	1608-205-246-00	12 50
1593-905-001-00	41 1	1608-203-200-00	11 1	1608-205-247-00	12 51
1593-905-012-00	41 3	1608-203-210-00	11 11	1608-205-260-00	12 2
1593-906-001-00	42 1	1608-205-200-10	12 1	1608-205-263-00	12 3
1593-906-012-00	42 3	1608-205-201-00	12 15	1608-205-264-00	12 4
1600-112-231-00	6 14	1608-205-202-00	12 16	1608-205-265-00	12 5
	7 13	1608-205-203-00	12 17	1608-205-266-00	12 6
1600-112-232-00	6 10	1608-205-204-00	12 18	1608-205-267-00	12 7
	6 15	1608-205-205-00	12 19	1608-205-268-00	12 8
	7 9	1608-205-206-10	12 20	1608-205-269-00	12 9

Numerical Index

1608-097-100-10

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
1608-205-280-00	12	10	1608-310-200-10	17	1	1608-601-001-10	30	16-A
1608-205-283-00	12	11	1608-310-210-00	17	7	1608-601-002-00	30	21
1608-205-284-00	12	12	1608-312-003-40	18	11	1608-601-002-10	30	21-A
	12	58	1608-312-005-00	18	4	1608-601-003-00	30	20
1608-205-285-00	12	13	1608-312-006-20	18	19	1608-606-200-41	32	1
	12	63	1608-312-007-00	18	8	1608-606-200-42	33	1
1608-205-290-00	12	57	1608-312-200-40	18	1	1608-616-001-10	35	15
1608-206-001-00	13	4	1608-312-210-20	18	5	1608-616-002-20	35	16
1608-206-002-00	13	26	1608-312-220-00	18	17	1608-616-200-31	35	10
1608-206-004-00	13	30	1608-313-200-10	18	23	1608-616-200-32	35	10
1608-206-005-00	13	33	1608-341-001-20	47	5	1608-621-200-00	36	1
1608-206-200-30	13	1	1608-341-003-20	47	11	1608-623-200-00	37	1
1608-206-210-20	13	10	1608-341-006-10	47	18	1608-623-200-10	37	1-A
1608-206-240-00	13	18	1608-341-008-00	47	23	1608-623-210-00	38	1
1608-206-241-00	13	19	1608-341-012-00	47	58	1608-623-210-10	38	1-A
1608-206-250-00	13	34-A	1608-341-013-00	47	64	1608-901-003-10	39	8
1608-206-260-00	13	35-A	1608-341-014-10	47	65	1608-901-008-00	39	5
1608-207-003-20	14	37	1608-341-015-00	47	66	1608-901-009-00	39	3
1608-207-004-10	14	28	1608-341-016-00	47	68	1608-901-011-00	39	14
	14	38	1608-341-021-10	47	41	1608-901-012-00	39	15
1608-207-006-10	14	53	1608-341-023-00	47	36	1608-904-002-00	40	2
1608-207-007-10	14	54	1608-341-025-10	47	48	1608-904-006-00	40	4
1608-207-008-00	14	60	1608-341-026-00	47	6	1608-905-002-00	41	2
1608-207-009-20	14	61	1608-341-027-00	47	54	1608-905-006-00	41	4
1608-207-011-00	14	7	1608-341-200-00	47	53	1608-906-002-00	42	2
1608-207-012-00	14	17	1608-341-210-30	47	2	1608-906-006-00	42	4
1608-207-014-00	14	44	1608-341-220-20	47	14		43	8
1608-207-200-30	14	1	1608-341-230-20	47	24	1608-930-001-00	45	2
1608-207-210-20	14	6	1608-341-240-30	47	28	1614-922-200-20	50	1
1608-207-220-20	14	12	1608-341-260-30	47	39	1631-101-210-10	1	1
1608-207-230-00	14	16	1608-341-270-00	47	27	1631-401-300-00	22	5
1608-207-240-20	14	24	1608-341-300-40	47	1	1631-401-310-00	22	7
1608-207-250-20	14	32	1608-341-310-30	47	62	1631-611-210-20	34	1
1608-207-260-20	14	42	1608-341-320-10	47	70	1631-901-021-00	39	16
1608-207-270-10	14	45	1608-341-330-00	47	21	1631-910-002-00	44	2
1608-207-280-10	14	21	1608-401-250-00	22	1	1631-910-004-00	44	4
1608-207-290-00	14	48	1608-401-250-20	22	1-A	1631-910-006-00	44	6
1608-207-310-00	14	27	1608-553-200-40	27	1	1631-910-008-00	44	1
1608-208-200-10	15	1	1608-553-210-00	27	4	1631-910-009-00	44	3
1608-304-001-00	16	2	1608-554-001-00	28	11	1636-313-011-10	18	6-A
1608-307-200-20	16	11	1608-554-002-00	28	14	1636-901-009-00	39	7
1608-307-200-30	16	11-A	1608-554-200-10	28	1	1636-901-015-00	39	10
1608-307-210-20	16	15	1608-554-210-10	28	4	1636-901-022-00	39	13
1608-307-210-30	16	15-A	1608-554-600-20	28	7	1640-903-006-00	41	8
1608-310-002-00	17	2	1608-601-001-00	30	16	1640-903-006-10	41	8-A

Numerical Index

1608-097-100-10

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
1640-903-013-00	41	6	2500-901-027-00	39	6	3737-113-005-00	10	6
1640-903-013-10	41	6-A	2502-407-001-10	20	2	3737-122-001-00	47	16
1640-903-015-00	41	9	2706-501-003-00	35	7	3737-172-009-00	30	34
1640-903-015-10	41	9-A	2706-501-004-00	35	8		31	34
1640-903-015-20	41	9-B	3517-205-007-00	47	25	3737-172-010-00	37	9
1640-903-016-00	41	7	3560-201-015-00	35	4		38	15
1640-903-016-10	41	7-A	3600-201-013-00	18	24		49	12
1640-903-026-00	40	8	3610-631-002-00	30	8	3737-172-011-00	1	5
1640-903-033-00	40	6		31	8		2	5
1640-903-035-00	40	9	3614-261-002-00	36	8		24	18
1640-903-036-00	40	7	3621-702-003-00	23	7	3746-111-011-00	21	8
1640-904-006-00	42	8	3623-820-013-00	22	4	3746-185-014-00	37	10
1640-904-006-10	42	8-A	3625-212-007-00	23	16		38	16
1640-904-013-00	42	6	3626-276-003-00	6	17	3768-185-022-10	13	20
1640-904-013-10	42	6-A		7	18	3805-701-018-00	23	7-A
1640-904-016-10	42	7	3631-221-001-00	1	9	3908-170-020-00	32	6
1640-904-019-00	42	9		2	9		33	6
1640-904-019-10	42	9-A	3631-270-003-00	49	6	4106-105-303-00	8	5
1640-905-006-00	44	8	3631-353-001-10	10	33		20	13
1640-905-013-00	44	5	3631-353-002-10	13	31		47	34
1640-905-015-00	44	9	3631-671-003-00	14	20	4301-210-002-00	30	11
1640-905-016-00	44	7	3642-496-007-10	37	20-A		31	11
1646-116-051-00	8	5-A		38	26-A		36	14
1646-116-051-10	8	5-B		47	30-A	4319-911-001-00	45	1
1674-904-008-00	43	1-A	3643-586-001-00	5	27	6213-200-002-10	5	1
1689-440-230-00	26	2-A	3648-703-001-00	20	5	6219-755-001-00	5	3
1689-502-250-00	13	31-B	3650-261-261-00	38	8	7955-201-026-00	10	24
1701-509-007-00	21	13	3650-262-202-00	38	5	8523-202-241-00	46	1
1705-333-001-00	20	13-A	3650-270-214-00	36	3	8523-202-242-00	46	2
1705-408-350-00	13	17-B	3652-261-202-00	6	13	8592-011-204-00	9	9
1705-902-006-00	43	4		7	12	8595-901-006-00	39	11
1705-902-007-00	43	6	3656-115-001-00	14	15		43	1
1705-902-008-00	43	7	3656-221-001-10	28	8		43	5
1705-904-001-00	43	9	3659-310-004-00	5	26	8595-901-007-00	39	12
1705-904-002-00	43	10	3660-260-210-30	7	1		43	3
1705-904-002-10	43	10-A	3661-212-001-00	15	5	8654-101-230-00	9	9-A
1705-904-004-00	43	11		30	6	8654-101-232-00	9	10
1705-904-011-00	39	7-A		31	6	8654-101-233-00	9	11
	43	2	3664-276-001-00	37	20	J061-114-024-00	10	29
1725-604-052-00	30	31-A		38	26	J061-209-011-00	5	20
2111-101-011-00	10	32		47	30	J061-210-012-00	5	12
2137-223-004-00	10	23	3664-351-006-00	13	17		5	16
2144-117-002-00	34	17	3667-354-220-10	13	34		5	19
2161-439-220-10	13	17-A	3667-354-240-00	13	35		5	22
2171-213-002-00	18	24-A	3728-552-008-00	47	45		5	28

Numerical Index

1608-097-100-10

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
J061-210-015-00	3 20	V201-260-809-50	10 18-A	V211-260-802-00	13 5
J061-211-013-00	5 13	V201-260-810-00	10 22-A		13 12
	5 17	V201-260-810-50	10 22		14 43
	5 23	V201-460-802-00	9 13		18 20
J061-232-040-00	3 12	V201-460-802-50	9 13-A		47 56
J061-236-044-00	3 13-A	V201-460-804-50	9 3		47 61
J061-238-046-00	3 13	V201-461-003-00	10 34	V211-260-802-50	29 4
J061-247-055-00	4 14	V203-461-002-00	1 3	V211-260-803-00	10 19
J062-081-087-00	5 29		2 3		47 57
J062-104-111-00	10 31		6 19	V211-260-804-00	10 20
K182-002-002-00	13 23		7 20	V211-260-804-50	51 12
K182-032-000-00	13 21	V203-461-002-50	21 21	V211-261-002-00	5 25
K182-032-001-00	13 22	V210-260-601-20	9 16		22 14
K182-032-002-00	13 24		21 19		25 2
K182-032-003-00	13 25		25 4	V211-261-002-50	18 7
K211-004-007-00	51 7		31 36		21 15
K211-012-000-00	13 14		47 7		47 52
K211-012-003-00	51 2	V210-260-601-60	36 10		48 3
K211-012-005-00	51 4		49 16	V211-261-004-50	12 68
K211-012-006-00	51 5	V210-260-602-00	13 13	V211-360-801-60	13 9
K211-012-007-00	51 6		36 11		14 62
K211-012-008-00	51 10	V210-360-601-20	30 36		24 19
K211-012-009-00	51 3		47 22		32 8
K211-012-011-00	51 13	V210-360-601-60	5 6		33 8
K211-012-100-00	51 1		8 4	V211-360-802-00	3 8
P117-501-250-00	13 31-A		21 12		3 19
V111-163-002-00	37 17		30 7		4 11
	38 23		31 7		6 7
	47 31		36 10-A		7 6
V120-266-001-20	51 14	V210-360-602-00	21 12-A		22 6
V120-266-002-50	51 8		21 17		25 16
V120-366-001-60	31 17		24 11	V211-360-802-50	1 15
	31 22		24 17		2 15
	37 12		36 11-A	V211-361-002-00	6 18
	38 18	V210-360-602-50	24 11-A		7 19
V120-376-001-60	30 17	V210-660-602-00	21 17-A	V211-561-001-60	10 38
	30 22	V211-260-801-60	5 4	V211-561-002-00	4 3
V120-376-002-00	30 31		6 11		10 37
	31 31		7 10		47 8
V120-376-002-50	30 32		10 16		47 50
V201-260-803-50	14 4		17 3	V211-561-002-50	24 6
V201-260-805-00	14 50		22 8		27 3
	47 42		30 9		27 5
V201-260-806-00	13 15		31 9	V211-660-802-00	4 5
V201-260-809-50	10 18	V211-260-802-00	10 26	V251-261-004-5D	10 7

Numerical Index

1608-097-100-10

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
V271-160-602-50	4 8	V360-260-005-00	32 10-A	V401-160-010-00	47 20
V301-260-005-00	32 10		33 10-A	V401-160-012-00	23 29
	33 10	V360-260-006-00	5 7		25 20
V301-260-006-00	1 10		49 17	V401-160-016-00	21 9
	2 10	V361-260-006-00	30 29	V411-260-003-00	37 19
	6 6		31 29		38 25
	7 5	V362-260-008-00	28 12		47 33
	34 6	V363-260-008-00	6 22	V411-260-006-00	8 10
	38 9		13 16		38 10
V304-260-008-00	1 7		17 8	V411-260-008-00	14 22
	2 7		24 20		14 29
	7 15		30 39		14 39
	14 5		31 39		14 51
	14 52		32 7		14 56
	18 13		33 7		18 9
	47 44		47 35		20 10
V304-260-010-00	47 46	V363-260-010-00	3 24		28 15
	3 25		27 8		30 19
	8 7	V401-160-003-00	37 18		30 24
	12 70		38 24		31 19
	14 11		47 32		31 24
	14 31	V401-160-005-00	32 11		32 4
	14 41	V401-160-006-00	1 11		33 4
	14 55		2 11		35 3
V304-260-020-00	27 13-A		14 26		35 12
V304-460-008-00	9 14		14 34		47 37
V304-460-010-00	19 5		18 3		47 43
V304-460-016-00	21 10		34 7	V411-260-010-00	3 26
V305-260-010-00	34 14		38 11		6 21
V305-260-012-00	50 3	V401-160-008-00	1 8		7 22
V305-260-020-00	27 13		2 8		8 8
V328-262-110-00	23 12		7 16		14 8
	23 22		9 4		14 58
	24 14		9 19		15 2
V328-262-112-00	23 8		10 21		18 21
	23 28	V401-160-010-00	1 4		18 25
	25 18		2 4		20 14
V334-260-010-00	23 17		6 20		24 15
V334-460-010-00	47 12		7 21	V411-260-012-00	14 10
	47 19		10 35		14 13
V335-260-012-00	23 26		12 69		14 18
V350-160-004-00	30 28		16 5		25 19
	31 28		19 6		28 5
V350-160-006-00	30 15		21 22	V411-260-014-00	13 27
	31 15		47 13		14 46

Numerical Index

1608-097-100-10

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
V411-260-014-00	27 9	V580-140-602-50	14 2	V720-102-402-20	13 3
	27 14	V600-110-600-40	25 11	V720-103-502-40	13 7
	28 9		47 63	V720-103-502-60	13 8
V411-260-018-00	23 5		47 71	V720-111-900-80	12 65
V411-260-020-00	14 35	V600-110-600-50	11 7	V720-112-401-10	12 67
V500-162-501-50	28 2	V600-110-600-70	47 72	V720-112-401-40	13 32
	8 11	V600-110-620-40	11 9	V721-103-103-00	11 5
	35 5	V600-110-620-50	11 10	V721-103-104-50	10 15
	47 38	V600-110-620-70	16 10		11 6
V500-162-502-00	23 13	V600-110-630-40	11 13	V721-103-105-50	51 11
V500-163-001-50	23 24	V600-110-630-50	11 12	V740-130-420-80	10 5
	24 16	V600-140-600-40	25 12		10 12
	14 23	V600-150-600-50	21 5	V742-120-420-60	25 9
	14 30	V600-150-620-20	47 9	V744-120-350-70	10 14
	14 40	V600-150-620-30	23 19		47 55
V500-163-002-00	14 57	V600-150-620-50	26 5	V744-130-420-80	10 4
	18 10	V653-430-403-00	10 2		10 11
	20 11		10 9	V744-135-550-80	47 59
	28 16	V654-418-221-60	47 67	V760-150-000-00	18 2
	14 9	V704-140-012-00	47 15		22 11
	14 14	V704-140-015-00	20 3	V762-150-000-00	47 4
	14 19		20 6		14 25
	14 59		47 17		14 33
	15 3		47 40		22 12
	18 22	V704-140-016-00	16 9	V781-160-000-40	47 60
V500-163-002-50	18 26	V704-140-017-00	17 5	V999-200-003-00	19 3
	28 6	V704-140-020-00	12 54		26 3
	34 11	V704-140-025-00	11 3		46 3
	13 28		21 6	W201-261-206-00	50 2
	14 47	V705-140-020-00	9 12		
	20 15	V705-140-030-00	12 14		
	23 9		12 56		
	23 30	V705-140-035-00	47 10		
	25 21	V705-140-040-00	12 53		
	27 10		23 20		
V500-163-003-00	27 15	V705-140-042-00	10 3		
	28 10		10 10		
	47 26		25 8		
	14 36		25 13		
	28 3	V705-140-047-00	21 7		
V500-164-003-00	13 29	V705-140-052-00	12 52		
V560-160-008-00	35 13	V720-101-900-60	51 9		
V580-140-401-00	12 55	V720-102-401-50	47 3		
V580-140-502-50	47 69	V720-102-401-80	13 2		
V580-140-503-20	23 6		13 11		

Alphabetical Index

6003-097-120-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
SYLINDER HEAD ASSY	1 1	BOLT, CONN ROD	14 6	CLIP/HOSE/13. 8-14. 8	21 21-A
ARM, CONTROL	24 30	BOLT, EYE	33 37	CLIP/HOSE/6. 2-6. 7	25 6
ARM, FLOATING	24 18	BOLT, JOINT	19 13	CLIP/HOSE/7. 6-8. 2	25 5
ARM, TENSION	26 1	BOLT, SEMS/M10X20	8 3	COLLAR	35 5
ARM/CONTROL	24 30-A		9 3	CONNECTINGROD ASSY	14 5-A
ARM/FLOATING COMP	24 18-A	BOLT, SEMS/M6X12	13 5		15 5
ARMATURE	34 3		24 14	CONNECTOR, GLOW PLUG	28 4
BALL	1 5	BOLT, SEMS/M8X16	8 4	CONNECTOR, OIL FILTER	10 2
	34 15		9 4	CONNECTOR/FUEL	25 1
BEARING, BALL	34 4	BOLT, SEMS/M8X25 7T	4 3	CONTROLSLEEVE	33 36-A
	34 5	BOLT/CONNECTINGROD	14 6-A	COUPLER	35 10
	35 4		14 6-B	COVER, INJ PUMP	5 23
BEARING, RB/6004	24 12		15 6	COVER/CYLINDER/HEAD	2 1
BEARING, RB/6203	24 11	BOLT/CRANK	18 10-A	CRANKSHAFT ASSY	18 1-A
BEARING, THRUST CRANK	5 13	BOLT/FLANGE	18 7-A		18 1-B
	6 2	BOLT/M10X1. 25X82	1 7		18 1-C
	6 4	BOLT/M6	10 32		18 1-D
BEARING/CONN ROD	14 8		10 33	CUP/SEALING/12	5 7-A
BEARING/CONNECTING R	6 5	BOLT/M6X10	24 16	CUP/SEALING/16	10 4
	6 6	BOLT/M6X18	24 7	CUP/SEALING/28	5 3-A
	14 8-A		24 25	CUP/SEALING/36	5 4-A
	15 7	BOLT/WS	19 6	CUTTER, VALVE	12 5
	15 7-A		34 18	CYLINDERBLOCK ASSY	5 1
BEARING/CRANK/LOWER	5 12	BRACKET ROCKER SHAFT	12 12		5 1-A
BEARING/CRANK/UPPER	5 11	BRACKET, ROCKER SHAFT	12 13	CYLINDERHEAD ASSY	1 1-A
BEARING/WATER PUMP	20 3	CAMSHAFT/INJPUMP	24 8-A		1 1-B
	21 3	CAP	25 4	DOWEL	5 20
BEARING/WATERPUMP	20 4		35 13		5 20-A
	21 4	CAP, BLANK/30	10 21	EYE	30 18
BELT/VHM34. 5/FAN	22 5	CAP, OIL FILLER	2 2	FAN, COOLING	22 1
BODY/OILPUMP	19 2	CAP, SEALING	1 2	FLANGEBOLT	3 3
	19 2-A		5 3		5 25
BODY/WATERPUMP	20 2		5 4		7 4
	21 2		5 7		10 6
BOLT	1 7-A	CAP/RABBER	34 21		10 7
	5 2	CARTRIDGE, OIL FILTER	19 15		10 8
	10 37	CARTRIDGE/OILFILTER	19 15-A		10 9
	12 18	CLAMP	35 9		10 10
	18 7		35 9-A		10 11
	18 10	CLAMP, 7	28 8		10 13
	19 7	CLAMP, HARNESS D	21 31		10 14
	22 4	CLAMP, STRAINER	19 10		10 15
	27 9	CLAMP/WIRE/10-15	20 21		10 38
	33 39		21 21		10 39
BOLT, ADJUST	5 27		21 21-B		11 2

Alphabetical Index

6003-097-120-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
FLANGEBOLT	19 11	GASKET/HOUSING	29 19	INJECTIONPUMP ASSY	24 1-A
	20 13	GASKET/PLATE	10 36	KEY	13 3
	20 18		10 36-A		18 4
	20 25		29 15		24 10
	20 26	GASKET/SPACER	20 16	KEY/07X05X09	13 3-A
	20 30		21 16		24 10-A
	21 13		29 18	KEY/07X05X43	18 4-A
	21 18	GASKET/WATER PUMP	20 12	LEVELGAGE	5 29
	21 25		21 12	LEVER, CONTROL	24 24
	21 26		29 17	LINK/CONTROL	24 19
FLYWEIGHT	21 30	GEAR, CAMSHAFT	13 2	MANIFOLD ASSY	3 1
	27 4	GEAR, CRANK SHAFT	18 3	MANIFOLD, EXHAUST	4 1
	27 6	GEAR, IDLE	13 6	METAL, CRANK	5 10
	28 7	GEAR, INJ PUMP	24 9		6 1
	24 15	GEAR, RING	18 6		6 3
FLYWHEEL	18 5	GEAR/CAMSHAFT	13 2-A	NIPPLE	5 21
FRAME/STARTER END	34 11	GEAR/CRANK	18 3-A	NOZZLE	30 1
GASKET	2 5-A	GEAR/IDLE ASSY	13 6-A		31 18
	2 5-B	GEAR/INJECTIONPUMP	24 9-A		32 16
	3 2		24 9-B	NOZZLE, INJ. ASSY	23 1
	20 8	GEAR/OILPUMP ASSY	19 3	NUT	5 28
	21 8		19 3-A		10 34
	28 6	GEARCASE ASSY	10 1		12 17
	29 5-A		10 1-A		24 26
	29 5-B	GENERATOR/12V-8. 5A	27 1		24 31
	29 6	GLOWPLUG	28 3-A		30 19
	29 21		28 3-B		31 17
	30 17	HANGER	11 1		32 18
	31 16	HOLDER ASSY	34 9		34 20
	32 17	HOLDER, DELIVERYVALVE	33 6		35 8
GASKET EXHAUST MANIF	33 5	HOLDER, NOZZLE ASSY	30 2	NUT, CAP	2 4
	33 38	HOLDER/NOZZLE ASSY	31 1	NUT, CAP/M 8	10 19
	33 40		32 1	NUT, FLANGE	14 7
	4 2	HOSE, RUBBER	20 20	NUT, RETAINING	30 16
	29 7		25 2		31 15
GASKET, CYL HEAD	1 6		25 3	NUT/CAP	2 4-A
	29 3	HOSE/RABBER	2 6	NUT/FLANGE	14 7-A
GASKET, NOZZLE	23 2	HOSE/RUBBER	21 20	NUT/M08	10 12
GASKET/COVER	5 24	HOUSING PUMP	33 1		10 40
	29 11	HOUSING/STARTER ASSY	34 7		12 19
GASKET/GEARCASE	10 27	HOUSING/THERMOSTAT	20 22		20 14
	10 27-A		21 22		20 19
	29 14		21 22-A		21 14
GASKET/HOUSING	20 24	INJECTIONNOZZLE ASSY	23 1-A		21 19
	21 24		23 1-B	NUT/M10	27 7

Alphabetical Index

6003-097-120-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
NUT/M8	10 18	PIPE, OIL	19 12	PLATE/T=2. 20	33 26
	34 23	PIPE, PUMP HOUSING	20 23	PLATE/T=2. 25	33 27
NUT/NOZZLERETAINING	32 15		21 23	PLATE/T=2. 30	33 28
OILPUMP ASSY	19 1-A	PIPE, WATER DRAIN	5 22	PLATE/T=2. 35	33 29
OILSEAL	5 14-A	PIPE, WATER OUTLET	20 28	PLATE/T=2. 40	33 30
O-RING	29 10-A		21 28	PLATE/T=2. 45	33 31
	20 29	PIPE/FUEL	25 2-A	PLATE/T=2. 50	33 32
	21 29	PIPE/INJECTION ASSY	23 3-A	PLATE/WATER PUMP	20 9
	29 20		23 4-A		21 9
	33 7	PIPE/WATER PUMP	20 11	PLUG	5 5
ORING	33 10		21 11		10 3
	33 7-A	PISTON	14 1		10 24
	33 10-A		14 1-A		12 11
O-RING/P 8	24 27		15 1	PLUG, GLOW	28 3
O-RING/P15	19 9	PISTON(OV/100)	16 3	PLUG/20	7 2
PACKING	29 16	PISTON/OV	16 1-A	PLUG/PT1/2	1 3
	2 5		16 3-A		1 3-A
	10 20		17 1	PLUG/SCREW	10 24-A
	19 14		17 3	PLUNGER ASSY	33 2
	19 14-A	PISTON/OV0. 50	16 1	POINTER	8 2
PAN, OIL COMP PIECE, THRUST PIN	29 5	PISTON/RELIEF VALVE	10 29		9 2
	29 13	PISTON/VALVE/RELIEF	10 29-A	PULLEY	18 8
	7 1		10 29-B		35 3
	24 17	PLATE	33 34	PULLEY COMP	35 3-A
	18 2		35 1	PULLEY, WATER PUMP	22 2
PIN, ADAPTER PIN, CONTROL LINK	18 2-A	PLATE COMP	35 1-A		22 2-A
	33 9	PLATE (CONTROLLEVER)	24 29-A	PUMP, INJ ASSY	24 1
	33 13	PLATE, ADJUST	27 3	PUMP, OIL ASSY	19 1
	26 2	PLATE, CONTROL VALVE	24 29	REGULATOR	27 2
	24 20	PLATE, FRONT	10 35		27 2-A
PIN, GROOVE	10 26	PLATE, THRUST	13 4		27 2-B
PIN, PISTON	14 3	PLATE, THRUST INJPUMP	24 13	RELAY, SOLENOID	28 9
	15 3	PLATE/ADJUST	27 3-A	REPAIR/ENGINE SET	29 1
PIN, STARTING SPRING	5 26	PLATE/FRONT	10 35-A	RETAINER	34 14
PIN, TUBE	5 15		10 35-B	RING SNAP	33 14
PIN/ARM	10 22	PLATE/REAR COMP	8 1	RING (PISTON) SET	14 2
PIN/IDLEGEAR	5 6		9 1	RING (PISTON/OV) SET	16 4
PIN/STRAIGHT	5 16	PLATE/T=1. 80	33 18	RING (PISTON/OV50) SET	16 2
	5 17	PLATE/T=1. 85	33 19	RING, O/G25	7 3
	19 5	PLATE/T=1. 90	33 20	RING, SNAP	14 4
PIN/TUBE PINION, STARTER PIPE, INJ	19 5-A	PLATE/T=1. 95	33 21		15 4
	5 15-A	PLATE/T=2. 00	33 22	RING, SNAP/ 4 E	10 23
	34 12	PLATE/T=2. 05	33 23		24 21
	23 3	PLATE/T=2. 10	33 24		26 3
	23 4	PLATE/T=2. 15	33 25	RING, SNAP/12 C	10 31

Alphabetical Index

6003-097-120-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
RING, SNAP/16 C	12 15	SEAT, VALVE SPRING	12 4	SHIM/INJECTON P/0. 1	24 2
RING/PISTON SET	14 2-A	SHAFT, CAM	13 1	SLEEVE, CONTROL	33 36
	14 2-B	SHAFT, CAM/INJ. PUMP	24 8	SLEEVE, FRANGE	33 8
	15 2	SHAFT, CRANK	18 1	SOLENOID	28 5
RING/PISTON/OV SET	16 2-A	SHAFT, ROCKER	12 8	SPACER	30 15
	16 4-A	SHAFT, ROCKER ARM ASSY	12 10		31 14
	17 2	SHAFT/ROCKERARM ASSY	12 10-A		32 14
	17 4	SHIM/0. 10	30 5	SPACER, FAN/39	22 3
RINGGEAR	18 6-A		31 4	SPACER, WATER PUMP	20 15
ROCKERARM	12 9		32 2		21 15
ROCKERSHAFT ASSY	12 8-A	SHIM/0. 20	30 6	SPRING	12 14
ROD CONTROL	33 33		31 5		34 16
ROD, CONNECTING	14 5		32 3	SPRING, BRUSH	34 10
ROD, PUSH	12 7	SHIM/0. 30	30 7	SPRING, DELIVERY VALVE	33 4
RORA	34 13		31 6	SPRING, GOVERNOR	24 23
ROTOR/OUTER	19 4		32 4	SPRING, NOZZLE	30 4
ROTOR/WATERPUMP	20 6	SHIM/0. 40	30 8		31 3
	21 6		31 7		32 12
SCREW	33 11		32 5	SPRING, PLUNGER	33 15
	33 35	SHIM/0. 50	30 9	SPRING, RETURN	24 28
	34 17		31 8	SPRING, SETTING	24 22
	35 11		32 6	SPRING, STARTING	24 34
	35 12	SHIM/0. 52	30 10	SPRING/RELIEF VALVE	10 30
SCREW ADJUST	12 16		31 9	SPRING/STARTING	24 34-A
SCREW/WATER PUMP	20 10		32 7	SPRING/VALVE	12 3
	21 10	SHIM/0. 54	30 11		12 3-A
SCREW/WS	34 19		31 10	SPRINGSEAT	30 3
SEAL SET/WATER PUMP	20 5		32 8		31 2
	21 5	SHIM/0. 56	30 12		32 13
SEAL, BEARING CAP	5 8		31 11	STARTER	35 2
	29 8		32 9	STARTER ASSY	27 8-A
SEAL, BEARING CAP/7	5 9	SHIM/0. 58	30 13	STARTER ASSY	27 8
	29 9		31 12	STARTER KIT	34 2
SEAL, CYL COVER	2 3		32 10		34 6
	29 4	SHIM/0. 80	30 14	STOPPER, FULL-LOAD	10 17
SEAL, OIL	1 4		31 13	STRAINER	19 8
	5 14		32 11	STRAINER COMP	19 8-A
	10 5	SHIM/INJECTION P/0. 2	24 3	STUD	1 8-A
	29 2	SHIM/INJECTION P/0. 3	24 4		5 19
	29 10	SHIM/INJECTION P/0. 4	24 5		20 17
	29 12	SHIM/INJECTION P/0. 5	24 6		21 17
SEAL/WATER PUMPPULLE	20 7	SHIM/INJECTIONPUMP	24 3-A	STUD, HEAD COVER	1 8
	21 7		24 4-A	STUD/M8X40	5 18
SEAT, SPRING	33 16		24 5-A	SWITCH, THERMETER	28 2
	33 17		24 6-A	SWITCH/OILPRESSURE	28 1

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
SWITCH/STARTER ASSY	34 8-A				
SWITCH/STARTER ASSY	34 8				
TAPPET	12 6				
	12 6-A				
	12 6-B				
THERMOSTAT	33 12				
	20 27				
	21 27				
THRUSTPIECE	24 17-A				
VALVE, DELIVERY	33 3				
VALVE, EXHAUST	12 2				
VALVE, INTAKE	12 1				
VALVE/EXHAUST	12 2-A				
	12 2-B				
	12 2-C				
VALVE/INTAKE	12 1-A				
	12 1-B				
VALVE/RELIEF ASSY	10 28				
	10 28-A				
	10 28-B				
WASHER	18 9				
	34 22				
	35 6				
	35 7				
WASHER / M6	24 32				
WASHER, SP/M 6	24 33				
WASHER/08X14X01	10 16				
	10 25				
	29 22				
WASHER/9X22X2	10 41				
WATERPUMP ASSY	27 5				
	20 1				
	21 1				
YOKE/STARTER	34 1				

Alphabetical Index

6003-097-130-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
SYLINDER HEAD ASSY	1 1	BOLT	18 7	BUSH	35 15
ARM, CONTROL	23 30		21 4	CAMSHAFT/INJPUMP	23 8-A
ARM, FLOATING	23 18		26 8	CAP	24 4
ARM, TENSION	25 1		32 39	CAP, BLANK/30	9 21
ARM/CONTROL	23 30-A		34 9	CAP, OIL FILLER	2 2
ARM/FLOATING COMP	23 18-A		34 10	CAP, SEALING	1 2
ARMATURE	33 3		34 19		5 3
BALL	1 5		34 20		5 4
	33 15		34 21		5 7
BEARING	34 5		34 22	CAP/RABBER	33 21
	34 11		34 24	CARTRIDGE, OIL FILTER	18 15
	35 5		35 9	CARTRIDGE/OILFILTER	18 15-A
	35 10		35 11	CLAMP, 7	27 8
BEARING, BALL	33 4		35 19	CLAMP, HARNESS D	20 31
	33 5		35 20	CLAMP, STRAINER	18 10
BEARING, RB/6004	23 12		35 21	CLAMP/WIRE/10-15	19 21
BEARING, RB/6203	23 11		35 22		20 21
BEARING, THRUST CRANK	5 13		35 24		20 21-B
	6 2	BOLT, ADJUST	5 27	CLIP/HOSE/13. 8-14. 8	20 21-A
	6 4	BOLT, CONN ROD	13 6	CLIP/HOSE/6. 2-6. 7	24 6
BEARING/BALL	34 6	BOLT, EYE	32 37	CLIP/HOSE/7. 6-8. 2	24 5
	34 11-A	BOLT, JOINT	18 13	COLLOR	34 3
BEARING/CONN ROD	13 8	BOLT, SEMS/M10X20	8 3		35 3
BEARING/CONNECTING R	6 5	BOLT, SEMS/M6X12	12 5	CONNECTINGROD ASSY	13 5-A
	6 6		23 14		14 5
	13 8-A	BOLT, SEMS/M8X16	8 4	CONNECTOR, GLOW PLUG	27 4
	14 7	BOLT, SEMS/M8X25 7T	4 3	CONNECTOR, OIL FILTER	9 2
	14 7-A	BOLT/CONNECTINGROD	13 6-A	CONNECTOR/FUEL	24 1
BEARING/CRANK/LOWER	5 12		13 6-B	CONTROLSLEEVE	32 36-A
BEARING/CRANK/UPPER	5 11		14 6	COVER	34 13
BEARING/WATER PUMP	19 3	BOLT/CRANK	17 10-A		35 13
	20 3	BOLT/FLANGE	17 7-A	COVER, BEARING	34 5-A
BEARING/WATERPUMP	19 4	BOLT/M10X1. 25X82	1 7		35 6
	20 4	BOLT/M6	9 32	COVER, INJ PUMP	5 23
BELT VHM034	21 5		9 33	COVER/CYLINDER/HEAD	2 1
BODY/OILPUMP	18 2	BOLT/M6X10	23 16	CRANKSHAFT ASSY	17 1-A
	18 2-A	BOLT/M6X18	23 7		17 1-B
BODY/WATERPUMP	19 2		23 25		17 1-C
	20 2	BOLT/WS	18 6		17 1-D
BOLT	1 7-A		33 18	CUP/SEALING/12	5 7-A
	5 2	BRACKET ROCKER SHAFT	11 12	CUP/SEALING/16	9 4
	9 37	BRACKET, ROCKER SHAFT	11 13	CUP/SEALING/28	5 3-A
	11 18	BRUSH	34 17	CUP/SEALING/36	5 4-A
	17 7		35 17	CUTTER, VALVE	11 5
	17 10	BUSH	34 15	CYLINDERBLOCK ASSY	5 1

Alphabetical Index

6003-097-130-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
CYLINDERBLOCK ASSY	5 1-A	GASKET	2 5-B	GEAR/INJECTIONPUMP	23 9-A
CYLINDERHEAD ASSY	1 1-A		3 2		23 9-B
	1 1-B		19 8	GEAR/OILPUMP ASSY	18 3
DOWEL	5 20		20 8		18 3-A
	5 20-A		27 6	GEARCASE ASSY	9 1
EYE	29 18		28 5-A		9 1-A
FAN, COOLING	21 1		28 5-B	GENERATOR ASSY	26 1
FLANGE BOLT	3 3		28 6	GENERATOR ASSY	26 1-A
	5 25		28 21	GLOWPLUG	27 3-A
	7 4		29 17		27 3-B
	9 6		30 16	HANGER	10 1
	9 7		31 17		10 1-A
	9 8		32 5	HOLDER ASSY	35 14
	9 9		32 38	HOLDER ASSY	33 9
	9 10		32 40		34 14
	9 11	GASKET EXHAUST MANIF	4 2	HOLDER, BRUSH ASSY	34 16
	9 13		28 7		35 16
	9 14	GASKET, CYL HEAD	1 6	HOLDER, DELIVERY VALVE	32 6
	9 15		28 3	HOLDER, NOZZLE ASSY	29 2
	9 38	GASKET, NOZZLE	22 2	HOLDER/BRUSH ASSY	34 16-A
	9 39	GASKET/COVER	5 24	HOLDER/NOZZLE ASSY	30 1
	10 2		28 11		31 1
	18 11	GASKET/GEARCASE	9 27	HOSE, RUBBER	19 20
	19 13		9 27-A		24 2
	19 18		28 14		24 3
	19 25	GASKET/HOUSING	19 24	HOSE/RABBER	2 6
	19 26		20 24	HOSE/RUBBER	20 20
	19 30		28 19	HOUSING PUMP	32 1
	20 13	GASKET/PLATE	9 36	HOUSING/STARTER ASSY	33 7
	20 18		9 36-A	HOUSING/THERMOSTAT	19 22
	20 25		28 15		20 22
	20 26	GASKET/SPACER	19 16		20 22-A
	20 30		20 16	INJECTIONNOZZLE ASSY	22 1-A
	26 3		28 18		22 1-B
	26 5	GASKET/WATER PUMP	19 12	INJECTIONPUMP ASSY	23 1-A
FLYWEIGHT	27 7		20 12	KEY	12 3
FLYWHEEL	23 15		28 17		17 4
FRAME	17 5	GEAR, CAMSHAFT	12 2		23 10
	34 12	GEAR, CRANK SHAFT	17 3	KEY/07X05X09	12 3-A
	35 12	GEAR, IDLE	12 6		23 10-A
FRAME ASSY	34 7	GEAR, INJ PUMP	23 9	KEY/07X05X43	17 4-A
FRAME, DRIVE END ASSY	35 7	GEAR, RING	17 6	LEVELGAGE	5 29
FRAME/DRIVEEND ASSY	34 7-A	GEAR/CAMSHAFT	12 2-A	LEVER, CONTROL	23 24
FRAME/STARTER END	33 11	GEAR/CRANK	17 3-A	LINK/CONTROL	23 19
GASKET	2 5-A	GEAR/IDLE ASSY	12 6-A	MANIFOLD ASSY	3 1

Alphabetical Index

6003-097-130-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
MANIFOLD, EXHAUST METAL, CRANK	4 1 5 10 6 1 6 3	O-RING	19 29 20 29 28 20 32 7	PIPE/FUEL PIPE/INJECTION ASSY PIPE/WATER PUMP	24 2-A 22 3-A 22 4-A 19 11
NIPPLE	5 21		32 10		20 11
NOZZLE	29 1 30 18 31 16	ORING	32 7-A 32 10-A 23 27	PISTON	13 1 13 1-A 14 1
NOZZLE, INJ. ASSY	22 1	O-RING/P 8	18 9	PISTON(OV/100)	15 3
NUT	5 28	O-RING/P15	28 16	PISTON/OV	15 1-A
	9 34 11 17 23 26 23 31 29 19	PACKING	2 5 9 20 18 14 18 14-A 28 5	PISTON/OV0. 50 PISTON/RELIEF VALVE	15 3-A 16 1 16 3 15 1 9 29
	30 17 31 18 33 20 34 2 34 23	PAN, OIL COMP PIECE, THRUST PIN	28 13 7 1 23 17 17 2 17 2-A	PISTON/VALVE/RELIEF PLATE	9 29-A 9 29-B 32 34 34 8 35 8
	34 25 35 2 35 23 35 25 2 4	PIN, ADAPTER PIN, CONTROL LINK PIN, GROOVE	32 9 32 13 25 2 23 20 9 26	PLATE (CONTROLLEVER) PLATE, CONTROL VALVE PLATE, FRONT PLATE, THRUST PLATE, THRUST INJPUMP	23 29-A 23 29 9 35 12 4 23 13
NUT, CAP					
NUT, CAP/M 8 NUT, FLANGE NUT, RETAINING	9 19 13 7 29 16 30 15	PIN, PISTON PIN, STARTING SPRING PIN, TUBE	13 3 14 3 5 26 5 15	PLATE/ADJUST PLATE/FRONT	26 2 26 2-A 9 35-A 9 35-B
NUT/CAP	2 4-A	PIN/ARM	9 22	PLATE/REAR COMP	8 1
NUT/FLANGE NUT/M08	13 7-A 9 12 9 40 11 19 19 14	PIN/IDLEGear PIN/STRAIGHT	5 6 5 16 5 17 18 5 18 5-A	PLATE/T=1. 80 PLATE/T=1. 85 PLATE/T=1. 90 PLATE/T=1. 95	8 1-A 32 18 32 19 32 20 32 21
	19 19 20 14 20 19 26 6 9 18	PIN/TUBE PINION, STARTER PIPE, INJ PIPE, OIL	5 15-A 33 12 22 3 22 4 18 12	PLATE/T=2. 00 PLATE/T=2. 05 PLATE/T=2. 10 PLATE/T=2. 15 PLATE/T=2. 20	32 22 32 23 32 24 32 25 32 26
NUT/M10 NUT/M8					
NUT/NOZZLERETAINING OILPUMP ASSY OILSEAL	33 23 31 15 18 1-A 5 14-A 28 10-A	PIPE, PUMP HOUSING PIPE, WATER DRAIN PIPE, WATER OUTLET	19 23 20 23 5 22 19 28 20 28	PLATE/T=2. 25 PLATE/T=2. 30 PLATE/T=2. 35 PLATE/T=2. 40 PLATE/T=2. 45	32 27 32 28 32 29 32 30 32 31

Alphabetical Index

6003-097-130-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
PLATE/T=2. 50	32 32	RINGGEAR	17 6-A	SHIM/0. 10	29 5
PLATE/WATER PUMP	19 9	ROCKERARM	11 9		30 4
	20 9	ROCKERSHAFT ASSY	11 8-A		31 2
PLUG	5 5	ROD CONTROL	32 33	SHIM/0. 20	29 6
	9 3	ROD, CONNECTING	13 5		30 5
	9 24	ROD, PUSH	11 7		31 3
	11 11	RORA	33 13	SHIM/0. 30	29 7
PLUG, GLOW	27 3	ROTOR ASSY	34 4-A		30 6
PLUG/20	7 2	ROTOR ASSY	34 4		31 4
PLUG/PT1/2	1 3		35 4	SHIM/0. 40	29 8
	1 3-A	ROTOR/OUTER	18 4		30 7
PLUG/SCREW	9 24-A	ROTOR/WATERPUMP	19 6		31 5
PLUNGER ASSY	32 2		20 6	SHIM/0. 50	29 9
POINTER	8 2	SCREW	32 11		30 8
PULLEY	17 8		32 35		31 6
	34 1		33 17	SHIM/0. 52	29 10
	35 1	SCREW ADJUST	11 16		30 9
PULLEY, WATER PUMP	21 2	SCREW/WATER PUMP	19 10		31 7
	21 2-A		20 10	SHIM/0. 54	29 11
PUMP, INJ ASSY	23 1	SCREW/WS	33 19		30 10
PUMP, OIL ASSY	18 1	SEAL SET/WATER PUMP	19 5		31 8
REGULATOR ASSY	34 26		20 5	SHIM/0. 56	29 12
	35 26	SEAL, BEARING CAP	5 8		30 11
RELAY, SOLENOID	27 9		28 8		31 9
REPAIR/ENGINE SET	28 1	SEAL, BEARING CAP/7	5 9	SHIM/0. 58	29 13
RETAINER	33 14		28 9		30 12
RING SNAP	32 14	SEAL, CYL COVER	2 3		31 10
RING (PISTON) SET	13 2		28 4	SHIM/0. 80	29 14
RING (PISTON/OV) SET	15 4	SEAL, OIL	1 4		30 13
RING (PISTON/OV50) SET	15 2		5 14		31 11
RING, 0/G25	7 3		9 5	SHIM/INJECTION P/0. 2	23 3
RING, SNAP	13 4		28 2	SHIM/INJECTION P/0. 3	23 4
	14 4		28 10	SHIM/INJECTION P/0. 4	23 5
RING, SNAP/ 4 E	9 23		28 12	SHIM/INJECTION P/0. 5	23 6
	23 21	SEAL/WATER PUMPPULLE	19 7	SHIM/INJECTIONPUMP	23 3-A
	25 3		20 7		23 4-A
RING, SNAP/12 C	9 31	SEAT, SPRING	32 16		23 5-A
RING, SNAP/16 C	11 15		32 17		23 6-A
RING/PISTON SET	13 2-A	SEAT, VALVE SPRING	11 4	SHIM/INJECTTON P/0. 1	23 2
	13 2-B	SHAFT, CAM	12 1	SLEEVE, CONTROL	32 36
	14 2	SHAFT, CAM/INJ. PUMP	23 8	SLEEVE, FRANGE	32 8
RING/PISTON/OV SET	15 2-A	SHAFT, CRANK	17 1	SOLENOID	27 5
	15 4-A	SHAFT, ROCKER	11 8	SPACER	29 15
	16 2	SHAFT, ROCKER ARMASSY	11 10		30 14
	16 4	SHAFT/ROCKERARM ASSY	11 10-A		31 14

Alphabetical Index

6003-097-130-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
SPACER, FAN/39	21 3	THERMOSTAT	19 27		
SPACER, WATER PUMP	19 15		20 27		
	20 15	THRUSTPIECE	23 17-A		
SPRING	11 14	VALVE, DELIVERY	32 3		
	33 16	VALVE, EXHAUST	11 2		
	34 18	VALVE, INTAKE	11 1		
	35 18	VALVE/EXHAUST	11 2-A		
SPRING, BRUSH	33 10		11 2-B		
SPRING, DELIVERYVALVE	32 4		11 2-C		
SPRING, GOVERNOR	23 23	VALVE/INTAKE	11 1-A		
SPRING, NOZZLE	29 4		11 1-B		
	30 3	VALVE/RELIEF ASSY	9 28		
	31 12		9 28-A		
SPRING, PLUNGER	32 15		9 28-B		
SPRING, RETURN	23 28	WASHER	17 9		
SPRING, SETTING	23 22		33 22		
SPRING, STARTING	23 34	WASHER / M6	23 32		
SPRING/RELIEF VALVE	9 30	WASHER, SP/M 6	23 33		
SPRING/STARTING	23 34-A	WASHER/08X14X01	9 16		
SPRING/VALVE	11 3		9 25		
	11 3-A		28 22		
SPRINGSEAT	29 3	WASHER/9X22X2	9 41		
	30 2		26 4		
	31 13	WATERPUMP ASSY	19 1		
STARTER ASSY	26 7-A		20 1		
STARTER KIT	26 7	YOKE/STARTER	33 1		
	33 2				
	33 6				
STOPPER, FULL-LOAD	9 17				
STRAINER	18 8				
STRAINER COMP	18 8-A				
STUD	1 8-A				
	5 19				
	19 17				
	20 17				
STUD, HEAD COVER	1 8				
STUD/M8X40	5 18				
SWITCH, THERMETER	27 2				
SWITCH/OILPRESSURE	27 1				
SWITCH/STARTER ASSY	33 8-A				
SWITCH/STARTER ASSY	33 8				
TAPPET	11 6				
	11 6-A				
	11 6-B				
	32 12				

Alphabetical Index

1608-097-100-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
ADAPTER (90°) ORIFICE	13 18	BEARING, RB/6005	11 7	BOLT, SEMS	47 22
ADAPTER (90° /PUMP)	13 20	BEARING, RB/6005SS	21 5		47 57
ADAPTER (FILTER/B)	13 30	BEARING, RB/6007	47 72	BOLT, SEMS (SP)	13 9
ADAPTER (HIGH PRESS)	13 31	BEARING, RB/6202SS	47 9		14 62
ADAPTER (LOW PRESS)	10 33	BEARING, RB/6203SS	23 19		24 19
ADAPTER (STRAIGHT)	10 23	BEARING, RB/6204	11 9		32 8
ADAPTER/L/G3/8 ASSY	13 31-B	BEARING, RB/6205	11 10		33 8
ARM (40)	47 41	BEARING, RB/6205SS	26 5	BOLT, SEMS (S) M8X16	5 4
ARM (HOOK)	14 48	BEARING, RB/6207	16 10		6 11
ARM (HST/F) COMP	14 24	BEARING, RB/6304	11 13		7 10
ARM (HST/REVERSE)	14 32	BEARING, RB/6305	11 12		10 16
ARM (LIFT)	28 1	BEARING, RB/7004	25 6		17 3
ARM (PEDAL)	18 5	BEARING, RB/7202	25 7		22 8
ARM, PITMAN	23 18	BELT/VB038	21 2		30 9
ARM, TENTION COMP	47 14	BELT/VC-31	47 23		31 9
ARM/BRAKE COMP	17 7	BLACKET/ENGINE/LH	1 1	BOLT/8X20	4 5
	18 1	BOLT	9 18	BOLT/M 8X100	10 22-A
ARM/CONTROL ASSY	28 7	BOLT (S)/M10X45	12 68	BOLT/M 8X105	10 22
ARM/Drag COMP	25 17	BOLT (S/N6X16)	30 11	BOLT/M 8X20	9 13
ARM/HOOD	30 37		31 11	BOLT/M 8X25	9 13-A
	31 37		36 14	BOLT/M 8X35	14 4
ARM/KNUCKLE/LH COMP	23 1	BOLT (CONNECTER/PF1/2	13 4	BOLT/M 8X50	14 50
ARM/KNUCKLE/RH COMP	23 2	BOLT (S) M10X25	18 7		47 42
ARM/PTO ASSY	20 1		21 15	BOLT/M 8X60	13 15
AXLE/FRONT ASSY	22 9		47 52	BOLT/M 8X95	10 18
BALLBEARING	12 26		48 3		10 18-A
	12 27	BOLT (S) M8X45	51 12	BOLT/M06X28	6 9
BAND	37 8	BOLT (S) 7	10 38		7 8
	38 14	BOLT (SP) /M6X16	5 6	BOLT/M06X32	6 14
BAND, HOSE	37 10		8 4		7 13
	38 16		21 12	BOLT/M10X1. 25X20	1 3
BAND/202	37 9		30 7		2 3
	38 15		31 7		6 19
	49 12		36 10-A		7 20
BAR/PTO	21 11	BOLT, BATTERY	6 5	BOLT/M10X1. 25X25	16 4
	21 11-A		7 4	BOLT/M10X20	4 3
	21 11-B	BOLT, KMOB	34 12		10 37
BATTERY (44B19L) ASSY	7 1	BOLT, SEMS	5 25		47 8
BATTERY/38B20L ASSY	6 1		6 18		47 50
BEARING, NR/TA3030Z	10 2		7 19	BOLT/M10X25	21 21
	10 9		10 19		24 6
BEARING, RB/6004	25 11		10 20		27 3
	47 63		22 14		27 5
	47 71		25 2	BOLT/M10X30	10 34
BEARING, RB/6004S	25 12		30 36	BOLT/M12X60	50 2

Alphabetical Index

1608-097-100-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
BOLT/M6X25	4 8	BRACKET/ENGINE/RH	2 2-A	CLAMP, HARNESS	1 5
BOLT/M8X45	9 3	BREATHER, TANK CAP	35 7		2 5
BOLT/S	9 16	BULB	36 3		24 18
	10 26	BULB, LAMP/12V21W	49 4	CLAMP, MAIN HARNESS	30 34
	13 5	BUSH	12 30		31 34
	13 12	BUSH(12X14X20)	47 54	CLAMP/WIRE/09-11	5 20
	13 13	BUSH, COLUMN	24 9	CLAMP/WIRE/10-12	5 12
	14 43	BUSH/10X12X10	24 2		5 16
	18 20	BUSH/15X17X11	20 2		5 19
	21 19	BUSH/15X17X16	28 8		5 22
	25 4	BUSH/25X28X25	22 10		5 28
	29 4	CABLE	6 12	CLAMP/WIRE/10-15	3 20
	31 36		7 11	CLAMP/WIRE/11-13	5 13
	36 10	CABLE, EARTH	6 8		5 17
	36 11		7 7		5 23
	47 7	CABLE, WIRE	6 17	CLAMP/WIRE/32-40	3 12
	47 56		7 18	CLAMP/WIRE/36-44	3 13-A
	47 61	CABLE/ACCELERATOR	8 1	CLAMP/WIRE/38-46	3 13
	49 16	CABLE/PTO ASSY	20 9	CLAMP/WIRE/47-55	4 14
BOLT/SP	1 15	CAP	3 2	CLAMP/WORM/14-24	10 29
	2 15		36 6	CLEANER, AIR ASSY	4 6
	3 8	CAP, BATTERY	6 2	CLIP (B)	30 18
	3 19	CAP, FUSE BOX	37 4		30 23
	4 11		38 4		31 18
	6 7	CAP, SHAFT (A) COMP	21 18		31 23
	7 6	CAP, TANK	35 6		35 17
	21 12-A	CAP, TIRE VALVE	19 3	CLIP/HOSE/10. 4-11. 1	10 31
	21 17		26 3	CLIP/HOSE/8. 1-8. 7	5 29
	21 17-A		46 3	COLLAR	12 25
	22 6	CAP/WHEEL	21 18-A	COLLAR(12X16X12)	14 17
	24 11		26 8	COLLAR(21X35X02)	47 64
	24 11-A	CARTRIDGE ASSY	13 35-A	COLLAR, 26X32X14	26 7
	24 17	CARTRIDGE/80 ASSY	13 35	COLLAR, WHEEL THRUST	16 14
	25 16	CASE	12 15		16 18
	36 11-A	CASE (PTO/FRONT)	47 53	COLLAR/17X27X02	51 6
BOLT/STUD/SEAL	10 7	CASE (PTO/RAER)	47 58	COLLAR/18X30X05	47 68
BONDEDSEAL	12 66	CASE, DIFF	16 1	COLLAR/21X25X08	25 14
BOOT	34 4	CASE/STEERING	25 1	COLLAR/25X35X02	11 2
	37 15	CASE/TRANSMISSION LH	10 1	COLLAR/26X32X41	21 4
	38 21	CASE/TRANSMISSION RH	10 8	COLLAR/26X32X53	26 6
BRACKET, ENGINE/LH	2 1	CASE/TRANSMISSION/RH	10 8-A	COLLAR/26X35X03	16 13
BRACKET, ENGINE/RH	2 2	CHARGE PUMP ASSY	12 10		16 17
BRACKET, PTO/F	21 14	CHASSIS COMP	22 1	COLLAR/31X38X06	23 21
BRACKET/ENGINE/LH	2 1-A		22 1-A	COLLAR/31X41X03	16 12
BRACKET/ENGINE/RH	1 2	CLAMP	34 18		16 16

Alphabetical Index

1608-097-100-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
COLUMN, STEERING ASSY	24 8	FLANGEYOKE ASSY	9 7-A	HARNESS/MAIN ASSY	37 1
CONNECTOR	3 16		9 7-B		37 1-A
COUPLING	9 1	FUSE/32V03A	37 2	HARNESS/MAIN/S ASSY	38 1
COVER	12 38		38 2		38 1-A
	29 2	FUSE/32V10A	37 3	HITCH/REAR SET	48 1
COVER (BELT)	36 5		38 3	HOLDER (FUEL FILTER)	5 3
COVER (BRAKE)	47 21	GASKET	12 62	HOLDER, BATTERY	6 4
COVER, F/PTO COMP	17 1		35 8		7 3
COVER/44X10	21 16	GASKET, MUFFLER	4 2	HOLDER/JE/9-9	3 9
	23 3	GAUGE, FUEL	35 9		4 4
COVER/BODY	51 10	GEAR (HELICAL/T72)	25 10	HOLDER/SWITCH	34 2
COVER/COUPLING	9 2	GEAR (T12-40)	11 11		34 2-A
COVER/FRONT/C	30 20	GEAR (T16)	47 65	HOOD/A COMP	30 1
	31 20	GEAR, BEVEL/12	16 6		31 1
COVER/FRONT/LH	30 16	GEAR, BEVEL/T12-45SET	11 1	HOOD/B	30 35
COVER/FRONT/MESH	30 16-A	GEAR/SPUR 15	11 8		31 35
	31 16	GEAR/T40	16 2	HOOK, RADIATOR PANEL	3 23
	30 14	GREASENIPPLE	9 10	HOSE 1300	5 8
	31 14	GRIP, B	28 13	HOSE ASSY	13 17
COVER/FRONT/PTO COMP	21 16-A	GRIP, BRAKE	18 24	HOSE (620)	13 17-A
COVER/FRONT/RH	30 21	GRIP/04X12X50	18 24-A	HOSE, RADIATOR/LW	3 11
	30 21-A	GRIP/PTO	20 13-A	HOSE, RADIATOR/UP	3 10
	31 21	GRIP/THROTTLE	8 5-A	HOSE, VINYL	3 5
COVER/LOWER ASSY	30 25		8 5-B	HOSE/06X10X365	5 18
	31 25	GROMMET	6 16	HOSE/06X12X115	5 21
COVER/REAR	22 3		7 17	HOSE/07X13X120	5 26
COVER/SPOOL	51 2		24 7	HOSE/1970	5 9
COVER/SWITCH	49 6		32 2	HOSE/210	3 15
CUSHION, PEDAL/RUBBER	1 9		33 2	HOSE/225	5 14
	2 9		36 12	HOSE/270	3 14
CYLINDER ASSY	13 21		37 7	HOSE/320	10 30
CYLINDERBLOCK ASSY	12 2		38 13	HOSE/360	10 27
DIODE/3.0A	38 5	GROMMET/10X18X50	21 13	HOSE/AIR CLEANER	4 12
DRIVESCREW	12 41	GROMMET/10X30X5	32 3	HOSE/HYDRAULIC/350	13 33
DRUM, BRAKE	17 4		33 3	HOSE/HYDRO/610 ASSY	13 17-B
DUST/SEAL	13 25		35 11	HST ASSY	12 1
ELBOW ASSY	13 31-A	GROMMET/150	37 6	HUB, PTO FRONT	22 13
ELEMENT	4 7		38 12	HUB, SEAL/INPUT	11 4
FAN (HST)	9 15	GUIDE/LH ENGINE	1 12	HUB, STEERING COLUMN	24 10
FENDER COMP	32 1		2 12	INSULATOR	1 6
	33 1	GUIDE/RH ENGINE	1 13		2 6
FILTER ASSY	13 34		2 13	INSULATOR/10X30X03	35 2
FILTER, FUEL	5 1	HANGER, SUPPORT	30 8	INSULATOR/22	22 2
FILTER, SUCTION (HST)	13 6		31 8	INSULATOR/HOOD	30 13
FLANGE/CONTROL COMP	25 15	HARNESS/GENERATOR	38 7		31 13

Alphabetical Index

1608-097-100-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
JOINT UNIVERSAL ASSY	9 6	LABEL/FUSE/I	44 6	LEVER, AXLE	8 2
JOINT, BALL	23 27	LABEL/MAINTENANCE	39 9	LEVER, PTO	20 12
JOINT, BALL/LH	23 10	LABEL/NOISE/LPA/90	39 7	LEVER/UNLOAD COMP	15 1
JOINT, BALL/RH	23 11	LABEL/NOISE/LWA/105	39 7-A	LIFT/270 COMP	27 1
JOINT, CAP LING	9 17		43 2	LINING/13X50X3	8 9
JOINT/HST/F COMP	9 7	LABEL/OPERATION/D	40 2	LINING/50	15 5
JOINT/HST/R COMP	9 8	LABEL/OPERATION/E	42 2		30 6
JOINT/UNIVERSAL ASSY	9 6-A	LABEL/OPERATION/F	41 2		31 6
JOINTT-TYPE	5 27	LABEL/OPERATION/I	44 1	LINK COMP	27 6
JOURNAL KIT	9 9	LABEL/PARKING	39 16		27 6-A
JOURNALCROSSE ASSY	9 9-A	LABEL/PARKING/D	40 3	LINK, FUSIBLE	6 13
KEY ASSY	36 8	LABEL/PARKING/E	42 3		7 12
KNOB	8 5	LABEL/PARKING/F	41 3		38 8
	20 13	LABEL/PARKING/I	44 3	LINK/A	27 11
	47 34	LABEL/PTO	47 75	LOCK (NEUTRAL)	14 12
KNOB, SET/12	22 4	LABEL/SW/HEAD LAMP	49 11	MARK, FUEL	42 5
LABEL (LIFT)	39 8	LABEL/W/FAN	40 8	MARK, FUEL/FR	41 5
LABEL (FUSE/D)	40 4		41 8	MAT (LH)	35 15
LABEL (FUSE/E)	42 4		42 8	MAT/RH	35 16
	43 8		42 8-A	METAL, BRAKE	10 13
LABEL (FUSE/F)	41 4		43 4	METAL, LIFTARM	27 2
LABEL, CAUTION/D	40 1	LABEL/W/FAN/F	41 8-A	METAL, LIFTARM/R COMP	27 4
LABEL, CAUTION/E	42 1	LABEL/W/FAN/T	44 8	METAL/PTO	47 5
LABEL, CAUTION/F	41 1	LABEL/W/RADIATOR	40 6	METER, HOUR ASSY	49 14
LABEL, FUEL/D	40 5		41 6	METER/HOUR SET	49 13
LABEL/BATTERY	43 10		42 6	MUFFLER	4 1
	43 10-A		42 6-A	NEEDLE (GAGE)	47 67
LABEL/CAUTION	43 11		43 7	NEEDLEBEARING	12 28
LABEL/CAUTION/BATTER	39 13	LABEL/W/RADIATOR/F	41 6-A	NET, LOWER COVER/LH	30 26
LABEL/CAUTION/I	44 2	LABEL/W/RADIATOR/T	44 5		31 26
LABEL/CE	39 6	LABEL/W/STARTER	43 6	NET, LOWER COVER/RH	30 27
LABEL/D/BATTERY	40 7	LABEL/WARNING/BELT	39 11		31 27
	41 7		43 1	NET/100X388	30 10
	42 7		43 1-A		31 10
LABEL/D/BATTERY/F	41 7-A		43 5	NIPPLE, GREASE	18 2
LABEL/D/BATTERY/T	44 7	LABEL/WARNING/HOT	39 12		22 11
LABEL/D/STARTER	40 9		43 3		47 4
	41 9	LABEL/WARNING/SLOPE	39 10	NIPPLE, GREASE/B-M6F	14 25
	42 9	LAMP, HEAD ASSY	49 2		14 33
	42 9-A	LAMP, MONITOR	36 2		22 12
LABEL/D/STARTER/F	41 9-A	LAMP/HEAD SET	49 1	NUT	1 7
	41 9-B	LEAD	49 3		2 7
LABEL/D/STARTER/T	44 9	LENS	36 13		3 25
LABEL/FUEL	43 9	LEVER (PTO)	47 24		7 15
LABEL/FUEL/I	44 4	LEVER (HST LIFT)	28 11		8 7

Alphabetical Index

1608-097-100-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
NUT	12 70	NUT/M12X1. 25	23 8	O-RING/P8	12 65
	14 5		23 28	ORNAMENT/153	39 3
	14 11		25 18	ORNAMENT/153/NEO	39 14
	14 31	NUT/M16	21 10	ORNAMENT/F	39 4
	14 41	NUT/M20	27 13	ORNAMENT/HYDRO	39 5
	14 52	NUT/M5	27 13-A	ORNAMENT/ISEKI/NEO	39 15
	14 55		32 10	ORNAMENT/LH	39 1
	18 13		32 10-A	ORNAMENT/RH	39 2
	23 12		33 10	PACKING	3 18
	23 22		33 10-A		4 9
	23 26	NUT/M6	5 7	PAD	18 6
	24 14	NUT/M8	49 17	PAD (HST)	14 44
	30 29		9 14	PAD, STEERING WHEEL	24 13
	31 29		18 14	PAD/BRAKE	18 6-A
	34 5		34 17	PANEL/INSTRUMEN SET	36 1
NUT, RING/M28X1. 0	37 14	NUT/WASHER	6 22	PANEL/INSTRUMENT	36 9
	38 20		13 16	PANEL/RADIATOR	3 21
	47 44		17 8	PEDAL (HST)	14 42
	47 46		24 20	PIN	12 5
	36 7		28 12		12 11
NUT, SPEED/P4	30 28		30 39	PIN (10X18) PIN (10X70) PIN (14X54)	12 29
	31 28		31 39		12 42
NUT, SPEED/P6	30 15		32 7		16 3
	31 15		33 7		14 60
NUT/A/M12	49 7		47 35		13 26
NUT/B/M12	49 10	OIL/FILTER ASSY OILSEAL ORIFICE ORIFICEBOLT/2. 2	13 34-A	PIN (18X52)	47 66
NUT/M 6	1 10		12 59	PIN(NEUTRAL)	14 6
	2 10		12 60	PIN, DIFF PINION	16 8
	6 6		12 46	PIN, KNOCK	10 6
	7 5		13 19	PIN, PTO	47 74
NUT/M06	34 6	O-RING	12 13	PIN, SNAP/8	32 6
	38 9		12 63		33 6
	6 10		12 64	PIN, SPLIT/2. 5X15	8 11
	6 15	O-RING/G30	11 5		35 5
	7 9	O-RING/G45	10 15		47 38
NUT/M10	7 14	O-RING/G55 O-RING/P 6 O-RING/P14 O-RING/P15	11 6	PIN, SPLIT/2. 5X20	23 13
	3 24		51 11		23 24
	19 5		51 9		24 16
	23 16		13 32	PIN, SPLIT/3 X15	14 23
	23 17		47 3		14 30
NUT/M10 7T P=1. 25	27 8	O-RING/P18	13 2		14 40
	34 14		13 11		14 57
	47 12	O-RING/P22	13 3		18 10
	47 19	O-RING/P24	13 7		20 11
NUT/M12	50 3	O-RING/P26	13 8		28 16

Alphabetical Index

1608-097-100-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
PIN, SPLIT/3 X20	14 9	PLATE (L/22X100)	14 28	PTO/REAR SET	47 1
	14 14		14 38	PULLEY (VC135)	47 18
	14 19	PLATE (L/32X178)	14 54	PULLEY, TENSION	47 16
	14 59	PLATE (PARKING) COMP	18 23	PULLEY, V/2B105	21 20
	15 3	PLATE (RETURN)	47 48	PULLEY/FT80X47	20 5
PIN, SPLIT/3 X25	18 22	PLATE (UX27X71)	17 2	PULLEY/VC100	47 11
	18 26	PLATE, AXLE	8 3	PULLY/V2B173	21 1
	28 6	PLATE, BATTERY	6 3	PUMP, FUEL	5 5
	34 11	PLATE, FILLER COMP	7 2	RADIATOR ASSY	3 1
	13 28		10 25	REFLECTOR ASSY	32 9-A
	14 47	PLATE, I/22X240	29 3	REFLECTOR ASSY	33 9-A
	20 15	PLATE, I/22X475	29 1		32 9
	23 9	PLATE, I/25X486	28 4		33 9
	23 30	PLATE, LOCK	18 19	RELAY/4P	37 11
	25 21	PLATE, STEERING	25 3		38 17
PIN, SPLIT/3X30	27 10	PLATE, STOPPER	9 5	RETAINERHOLDER	12 4
	27 15	PLATE, SWITCH	37 20-A	RETAINERPLATE	12 3
	28 10		38 26-A	RIM, WHEEL	19 1
	47 26		47 30-A	RIM, WHEEL FRONT	26 2
	14 36	PLATE, TRANON	14 1	RIM/WHEEL COMP	26 2-A
PIN, SPLIT/4 X30	28 3	PLATE/170X215	47 51	RING, CIRCLIP	47 10
	13 29		48 2	RING, PTO	47 73
PIN, SPRING/5 X25 W	47 69	PLATE/CASE	10 36	RING, SNAP	51 3
PIN, SPRING/5 X32 W	23 6	PLATE/FUELPUMP	5 24	RING, SNAP/12 C	47 15
PIN, SPRING/6 X25 W	14 2	PLATE/I/19X85 COMP	5 2	RING, SNAP/15 C	20 3
PIN/08X26	28 14	PLATE/IRX13X35	37 20		20 6
PIN/10X382	34 10		38 26		47 17
PIN/15X108	27 7		47 30		47 40
PIN/15X32	27 12	PLATE/L/15X55	49 15	RING, SNAP/16 C	16 9
PIN/15X47	17 6	PLSTE (I/22X134) COMP	14 21	RING, SNAP/17 C	17 5
PIN/8X36	32 5	PLUG	3 17	RING, SNAP/20 C	9 12
	33 5		12 31	RING, SNAP/20C	12 54
	35 14		12 40	RING, SNAP/25 C	11 3
PIN/SNAP	35 13		12 43	RING, SNAP/30 C	21 6
PIN/SPRING	12 55		12 45		12 14
PINION, BEVEL/11	16 7	PLUG, DRAIN (1/4)	12 49	RING, SNAP/40 C	12 56
PIPE/BOOST	13 10		10 24		12 53
PIPE/SUCTION	13 1		10 32		23 20
PISTON	13 22		47 60		10 3
PLATE	12 51		12 16		10 10
PLATE (BRAKE LOCK)	51 13	POST/STEERING ASSY	24 1	RING, SNAP/47 C	25 8
	18 17	PROTECTOR	5 10		25 13
PLATE (HOOK) COMP	14 16	PROTECTOR, FRONT	5 11		21 7
PLATE (I/20X122)	14 61		5 15		12 52
PLATE (L/16X101)	47 6		3 4		12 67

Alphabetical Index

1608-097-100-10

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
ROD PACKING	13 24	SEAL, OIL/TC35558	47 59	SPRING (HE085)	14 15
ROD (HST/F) COMP	14 27	SEAL, OIL/TC4, 14247	51 7	SPRING (HT035)	18 4
ROD (HST/REVERSE)	14 37	SEAL, OIL/VC20426	25 9	SPRING, BRAKE SHOE	17 10
ROD (M10X85)	14 53	SEAL/15X20X120	24 3	SPRING, DISK	8 6
ROD (NEUTRAL)	14 7	SEAL/15X20X170	30 30	SPRING, ROD COVER	14 20
ROD (REAR PTO)	47 36		31 30	SPRING, TENSION/46	47 49
ROD/D=8. 90-8. 94	23 14	SEAL/20X10X690	30 2	SPRING, TENSION/86	15 4
ROD/Drag	23 25		31 2		18 16
ROD/M08X140	18 8	SEAL/20X15X530	24 4	SPRING/D=6	34 15
ROD/M08X250	18 11	SEAL/30X30X50	24 5	SPRING/HC042	51 5
ROD/TIE/M10X193	23 15	SEALKIT	12 57	SPRING/HE014	20 7
RUBBER, CUSHION (A)	34 9	SEAT ASSY	34 1	SPRING/HE083	20 8
SCREW	31 17	SEATSWITCH ASSY	34 3	SPRING/HT013	18 18
	31 22	SHAFT COMP	47 39		18 27
	37 12	SHAFT (HOOK)	14 45	SPRINGHOLDER	12 7
SCREW M3X20	38 18	SHAFT (PTO) COMP	47 70		12 48
	37 17	SHAFT, JOINT/PTO	47 2	SPRINGPIN	12 37
	38 23	SHAFT/M	12 21	STAY, FENDER/LH	22 5
	47 31	SHAFT/P	12 20	STAY, FENDER/RH	22 7
SCREW SEMS M6X12	51 14	SHAFT/PTO/INPUT	47 62	STAY/LEVER ASSY	47 27
SCREW, SEMS	51 8	SHAFT/PTO/MID	21 3	STAY/LEVER COMP	47 28
SCREW/M6X25	31 32	SHAFT/STEERING COMP	25 5	STAY/SEAT COMP	34 8
SCREW/M8X11	30 38	SHAFT/WHEEL/LH COMP	16 11		34 8
	31 38		16 11-A	STEELBALL	12 32
SCREW/SP	30 17	SHAFT/WHEEL/RH COMP	16 15	STEP COMP	35 10
SCREW/SP/M06X20	30 22		16 15-A		35 10
	30 31	SHAFTYOKE ASSY	9 8-A	STOPPER	1 14
	30 32	SHIM (BRAKE METAL)	10 17		2 14
	31 31		10 17-A		14 49
	30 31-A	SHOE/BRAKE/NON ASBES	17 9	STOPPER, PISTON	13 23
SEAL (10X05X130)	3 22	SHORT COUPLER/REAR/P	37 5	STOPPER/SPRING	51 4
SEAL (10X05X27)	3 7		38 6	SURCLIP/HOLE	9 11
SEAL (10X10X340)	3 6	SHRUOD, FAN	3 3	SWITCH (STARTER) ASSY	36 4
SEAL (20X10X130)	30 4	SLANTBOARD/P	12 17	SWITCH, HEAD LAMP	49 5
	31 4	SNAPRING	12 9	SWITCH, MERIT	37 16
SEAL, CLEANER	4 13	SOCKET-HEADBOLT	12 39		38 22
SEAL, OIL	10 5	SPANNER/L-TYPE	45 1		47 29
	10 12	SPRING	12 6	SWITCH/PUSH SET	37 13
	12 12		12 35		38 19
	12 58		12 36	TANK, FUEL	35 1
SEAL, OIL/TC20357	12 61		12 47	THRUST	23 4
	10 14		12 50	THRUST PLATE	12 22
	47 55		18 15	TIRE, TURF/16-8	26 1
SEAL, OIL/TC30428	10 4		47 47	TIRE, TURF/23-12	19 2
	10 11	SPRING (HC135)	10 28	TIRE/23-12	46 1

Alphabetical Index

1608-097-100-10

Description	Fig. Key		Description	Fig. Key		Description	Fig. Key	
TRIGGER, TENSION	47	45	WASHER, PL/M 8	31	19	WASHER, SP/M16	21	9
TRIM/1X06X570	30	3		31	24	WASHER/06X16X01	30	33
	31	3		32	4		30	33-A
TRIM/1X6X360	30	5		33	4		31	33
	30	12		35	3	WASHER/11X22X3	23	23
TRUNNIONPIN	31	5	WASHER, PL/M14	35	12	WASHER/11X35X02	34	13
	31	12		47	37	WASHER/13X18X01	49	8
	12	23		47	43	WASHER/15X24X2	20	4
	12	24		13	27	WASHER/6X14X3	36	15
TUBE/23-12	46	2		14	46	WASHER/9X32X2	34	16
TURNBUCKLE/M8	18	12	WASHER, PL/M18 WASHER, PULLEY	27	9	WASHER/M10	3	26
UNLOADINGVALVE	12	33		27	14		6	21
VALVE	4	10		28	9		7	22
	12	44		23	5		8	8
VALVE SET	51	1		23	7		14	8
VALVE RELIEF	12	34	WASHER, SP/M 3 WASHER, SP/M 5 WASHER, SP/M 6	37	18		14	58
VALVE, COUNTROL	13	14		38	24		15	2
VALVE/RIM	19	4		47	32		18	21
	26	4		32	11		18	25
	46	4		1	11		20	14
VALVEPLATE	12	18		2	11	WASHER/M20	24	15
	12	19		14	26		14	35
WASHER	12	8		14	34		28	2
	21	8		18	3	WASHER/M3	37	19
	47	25		34	7		38	25
WASHER / M6	49	9	WASHER, SP/M 8	38	11	WEIGHT/15 SET WHEEL, STEERING ASSY WRENCH/BOX/10X12	47	33
	8	10		1	8		50	1
	38	10		2	8		24	12
WASHER /M12	14	10		7	16		45	2
	14	13		9	4			
WASHER(13X34X05) WASHER, BINDING SHAFT	14	18	WASHER, SP/M10	9	19			
	25	19		10	21			
	28	5		1	4			
	23	7-A		2	4			
	35	4		6	20			
WASHER, PL/M 8	14	22		7	21			
	14	29		10	35			
	14	39		12	69			
	14	51		16	5			
	14	56		19	6			
	18	9	WASHER, SP/M12	21	22			
	20	10		47	13			
	28	15		47	20			
	30	19		23	29			
	30	24		25	20			