

Directions for use of Parts Catalogue


1. Applicable model of machines

All component and option parts used for SSM60, 72 Mower are listed in this parts catalogue.

NOTES: SSM60-SZ330E4F FOR SZ330
SSM72-SZ330E4F FOR SZ330

2. Explanation for head paragraph

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL						I T C	C O L	G R P	REMARKS
				SSM40M	SSM40F	SSM40G	SRM40M	SRM40F	SRM40G				
1	8505-211-001-20	CASE/UPPER	*										
1A	8505-201-001-00	CASE/UPPER	*										
2	8505-211-002-10	CASE/LOWER	*										
3	VS23-100-001-00	PIN	*										
4	V211-260-002-00	BOLT, SEKS	*										



The diagram shows a curved blade with nine callout numbers in circles: 1, 2, 3, 4, 5, 6, 7, 8, and 9. Lines connect these numbers to the corresponding rows in the table above: 1 to CASE/UPPER, 2 to CASE/LOWER, 3 to PIN, 4 to BOLT, SEKS, and 5 to the first empty row. Numbers 6, 7, 8, and 9 point to various locations on the blade's surface.

- ① KEY shows the location of parts diagramed in the illustration.
- ② Parts numbers begin with `V` and `W` are standard parts of the market.
- ③ `LH` and `RH` on the parts name are described against the moving direction of the machine or are described on the condition how to install parts on the machines.
- ④ SPC : The following symbol classifies parts to be used for machines.
 `\*` means standard parts.
 `T` shows that the parts can be installed as optional parts.
 `R` shows that the parts can be used as applicable parts to replace originally equipped parts.

- ⑤ Upper column : QTY shows the number of parts to be used for one unit of machine.

`M` is indicated for parts supplied by a meter long.

`l` is indicated for parts supplied by liter.

`AR` is indicated for parts need to be adjusted or regulated.

Lower column : serial number

—229 means serial number up to 229.

230— means serial number 230 and after.

- ⑥ ITC : Interchangeability

`1`...OLD ← NEW

New parts can be used in place of the old parts.

`2`...OLD → NEW

Old parts can be used in place of the new parts.

`3`...OLD →← NEW

Old parts and new parts can not be replaced each other.

- ⑦ COL : Color code

Color is signified with color code number for colored parts.

Please see the color list shown in the next page.

- ⑧ GRP : Parts shown in this column can be replaced by SET parts.

Example : Parts marked ① can be replaced by parts marked ②, and ③ for ④, so the rest follow in the same alphabetical order.

- ⑨ Remarks

* Other maker's part code number is shown in this column.

* When Fig. No. is shown in the Remark column of SET parts or ASSY parts, each of their component parts are listed in said Fig. No.

3. Color :

The following colors are used color parts.

COLOR CODE	COLOR	SPRAY TYPE PARTS CODE	PAINTS 4K DRUM PARTS CODE	PAINTS 16K DRUM PARTS CODE
4 L	NEO BLUE	1300-985-001-10	1300-985-003-00	_____
7 F	MIRROR BLACK	1300-954-001-10	1300-954-003-00	1300-954-004-00

NOTE : Color code is signified only for the parts assigned by the maker as color parts.

4. Serial Numbers :

For chassies serial number is shown on the LABEL.

Please see




5. Parts Order

- 1) Parts numbers listed in the parts catalogue are all registered in “ISEKI on-line computer” .
- 2) When you order parts, please make sure of correct numbers.
- 3) When substitute parts is available, the part number ordered will be automatically turned to a new part number.
- 4) Please be sure to use “ISEKI GENUINE PARTS” .

Any other similar parts other than ISEKI parts when used may cause a trouble that makes us unable to repair or guarantee the warrant.

[illegible]



Contents

SSM60,72

JOINT(UNIVERSAL)SYSTEM..... Fig. 1

COVER(JOINT)SYSTEM..... Fig. 2

CASE(BEVEL)SYSTEM(SSM72)..... Fig. 3

CASE(BEVEL)SYSTEM(SSM60)..... Fig. 4

PULLEY SYSTEM..... Fig. 5

BELT SYSTEM(SSM60)..... Fig. 6

BELT SYSTEM(SSM72)..... Fig. 7

METAL SYSTEM..... Fig. 8

BLADE SYSTEM(SSM60)..... Fig. 9

BLADE SYSTEM(SSM72)..... Fig. 10

DECK(MOWER)SYSTEM(SSM72)..... Fig. 11

DECK(MOWER)SYSTEM(SSM60)..... Fig. 12

COVER(DISCHARGE)SYSTEM(SSM72)..... Fig. 13

COVER(DISCHARGE)SYSTEM(SSM60)..... Fig. 14

COVER(BELT)SYSTEM(SSM72)..... Fig. 15

COVER(BELT)SYSTEM(SSM60)..... Fig. 16

WHEEL(GAUGE)SYSTEM(SSM72)..... Fig. 17

WHEEL(GAUGE)SYSTEM(SSM60)..... Fig. 18

LABEL..... Fig. 19

OPTIONAL PARTS

CASE(BEVEL/25-21)ASSY(SSM72)(REPAIR)..... Fig. 20

CASE(BEVEL)ASSY(SSM60)(REPAIR)..... Fig. 21


F(SZ)KIT(SSM60)(REPAIR)..... Fig. 22


F(SZ)KIT(SSM72)(REPAIR)..... Fig. 23

COMPONENT PARTS

COMPONENT PARTS

FOR 8654-101-950-00 ON Fig.1 Fig. 24

[illegible]

[illegible]




[illegible]


FIG. 5 PULLEY SYSTEM




8654-202D-0100

[illegible]

[illegible]

[illegible]

[illegible]




[illegible]


FIG. 13 COVER(DISCHARGE)SYSTEM(SSM72)




8655-406B-0100

[illegible]

[illegible]


[illegible]



8654-501J-0100

[illegible]


FIG. 19 LABEL



8654-901P-0100


[illegible]

FIG. 21 CASE(BEVEL)ASSY(SSM60)(REPAIR)



8654-201W-0100

[illegible]

[illegible]

Numerical Index

8654-097-390-00

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
1434-211-004-00	5	3	8595-201-015-00	4	13	8654-101-232-00	24	11
1560-214-003-00	3	13		20	13	8654-101-233-00	24	5
	4	17		21	14		24	12
	20	14		3	14	8654-101-950-00	1	1
	21	18	8595-201-016-00	4	14		22	2
1564-275-007-00	17	4		20	15		23	2
	18	4		21	15	8654-101-961-00	24	2
1593-901-015-00	19	7		3	15	8654-101-962-00	24	6
1594-218-001-00	3	7	8595-201-017-00	4	15	8654-101-971-00	24	9
	4	7		20	16	8654-101-972-00	24	13
	20	8		21	16	8654-150-091-00	2	3
	21	8		3	16		22	7
1594-221-001-00	8	4	8595-201-021-00	4	18		23	7
	8	15		20	17	8654-150-910-00	2	1
2500-901-014-30	19	4		21	19		22	5
2500-901-027-00	19	1		3	17		23	5
3100-703-230-10	5	11	8595-201-022-00	4	19	8654-201-042-00	3	21
3621-211-003-00	5	13		20	18		4	21
3673-162-055-00	17	20		21	20	8654-201-043-00	3	22
3737-341-006-00	5	16		3	9		4	22
3737-341-007-00	5	17	8595-201-025-00	4	9	8654-201-045-10	3	11
3746-111-011-00	5	6		20	10		20	12
3805-701-018-00	13	3		21	10	8654-201-072-10	4	11
	14	3		4	10		21	12
7821-102-008-00	24	7	8595-201-250-10	21	11	8654-201-360-00	20	1
	24	14		9	2	8654-201-410-10	3	10
7821-102-220-00	24	8		10	2		20	11
	24	15		9	3	8654-201-750-10	21	1
7955-201-026-00	3	2	8595-306-006-00	10	3	8654-202-016-00	5	2
	4	2		9	4		5	5
	20	3		10	4	8654-202-091-00	5	1
	21	3		17	22		5	4
8595-201-011-00	3	1	8595-501-001-20	18	17	8654-202-900-00	5	9
	4	1		17	23	8654-203-091-00	6	1
	20	2		18	18	8654-301-004-00	8	7
	21	2		19	6		8	18
8595-201-012-00	3	3	8595-901-005-00	19	2	8654-301-071-00	8	12
	4	3	8595-901-006-00	19	3	8654-301-085-00	8	3
	20	4	8595-901-007-00	5	10	8654-306-006-10	9	1
	21	4	8597-202-501-00	3	24	8654-403-091-00	11	2
8595-201-013-00	3	6	8597-301-002-00	4	24		12	2
	4	6	8654-101-221-00	24	1	8654-403-950-00	12	1
	20	7		24	3	8654-406-001-00	13	2
	21	7		24	10		14	2
8595-201-015-00	3	12		24	4	8654-406-091-00	13	6

Numerical Index

8654-097-390-00

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
8654-406-091-00	14	6	8657-407-470-00	22	11	V360-260-012-00	18	19
8654-406-092-00	13	7		23	11	V362-260-008-00	2	2
	14	7	8657-501-501-00	17	2		15	2
8654-406-910-00	14	1		18	2		15	5
8654-407-092-10	15	6	8657-501-530-00	17	9		15	8
	16	5		18	9		16	2
	22	14	8658-101-673-00	24	16		16	4
	23	14	8658-101-674-00	24	17		16	7
8654-407-097-00	22	12	8658-301-001-00	8	9		22	6
8654-407-098-00	22	9		8	20		23	6
	23	9	8663-501-001-10	17	12	V401-160-010-00	3	26
8654-407-970-00	16	1		18	11		4	27
8654-407-980-00	16	3	8663-501-240-00	17	16	V401-160-012-00	13	5
8654-407-990-00	15	7		18	16		14	5
	16	6	V210-360-601-20	22	13	V401-160-016-00	5	7
	22	15		23	13		17	15
	23	15	V211-260-801-60	3	4		18	15
8654-501-260-10	17	19		4	4	V401-160-020-00	9	5
8654-501-280-10	17	17		20	5		10	5
8654-501-283-00	17	10		21	5	V411-260-010-00	3	28
	17	18	V211-261-002-50	8	2		4	28
	18	10		8	13	V411-260-014-00	3	25
8654-501-910-00	17	1	V211-360-801-60	2	4		4	25
	18	1		15	9		13	8
8654-501-930-00	17	3		16	8		14	8
	18	3		22	8	V411-260-020-00	9	6
8654-501-940-00	17	7		22	16		10	6
	18	7		23	8	V411-260-022-00	17	11
8654-501-950-00	17	8		23	16		18	12
	18	8	V211-560-801-60	17	21	V500-163-002-50	13	9
8654-901-002-00	19	5	V211-661-002-00	3	23		14	9
8654-901-061-00	19	9		4	23	V580-140-804-00	1	2
8654-901-091-00	19	8	V211-661-002-50	22	10		22	3
8654-950-400-10	22	1		23	10		23	3
8655-203-091-00	7	1	V304-260-008-00	5	18	V600-110-600-60	3	18
8655-306-003-10	10	1	V304-260-010-00	3	27		4	16
8655-403-950-00	11	1		4	26		20	19
8655-406-910-00	13	1	V304-260-012-00	13	4		21	17
8655-407-095-00	15	4		14	4	V600-110-690-80	8	5
8655-407-097-00	23	12	V304-460-016-00	5	8		8	16
8655-407-950-00	15	1		17	14	V704-140-016-00	5	14
8655-407-960-00	15	3		18	14	V704-140-020-00	5	12
8655-950-400-10	23	1	V334-260-012-00	11	3	V704-140-025-00	17	5
8657-301-004-00	8	1		12	3		18	5
8657-301-008-00	8	22	V360-260-012-00	17	24	V705-140-052-00	8	6

Numerical Index

8654-097-390-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
V705-140-052-00	8 17				
V707-140-055-00	3 19				
	4 12				
	20 20				
	21 13				
V707-140-062-00	3 8				
	4 8				
	8 10				
	8 21				
	20 9				
	21 9				
V721-103-108-00	3 5				
	4 5				
	20 6				
	21 6				
V744-130-551-20	3 20				
	4 20				
	20 21				
	21 21				
V744-135-520-80	8 8				
	8 19				
V760-150-000-00	5 15				
	8 11				
	17 6				
	17 13				
	18 6				
	18 13				
V761-150-000-00	8 14				

Alphabetical Index

8654-097-390-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
ARM/TENSION ASSY	5 9	BUSH/16X18X15	5 10	GEAR/BEVEL/25-2 SET	3 10
BEARING	8 5	BUSH/22X25X25	17 10		20 11
	8 16		17 18	GREASE NIPPLE	17 20
BEARING, RB 6006	3 18		18 10	GREASENIPPLE	24 4
	4 16	BUSH/26X30X20	17 2		24 11
	20 19		18 2	JOINT/UNIVERSAL SET	1 1
	21 17	CASE/BEVEL	3 1		22 2
BEARING/BALL 6205SH2	8 4		4 1		23 2
	8 15		20 2	JOURNALCROSSE ASSY	24 3
BEARING/BALL 6305SH2	3 7		21 2		24 10
	4 7	CASE/BEVEL ASSY	21 1	KEY/06X06X28	5 2
	20 8	CASE/BEVEL/25-2 ASSY	20 1		5 5
	21 8	CHAIN ASSY	24 8	LABEL/CE	19 1
BEARING/BALL/6304SH2	3 13		24 15	LABEL/DANGER	19 4
	4 17	COLLAR/26X36X3	5 3	LABEL/DANGER/DISCHAR	19 6
	20 14	COLLAR/BRADE	8 9	LABEL/DANGER/JOINT/G	24 17
	21 18		8 20	LABEL/GAUGEWHEEL/SZ	19 8
BELT/VC119	6 1	COLLER/26X34X15	8 22	LABEL/MAINTENANCE	19 7
BELT/VC134	7 1	COVER/B/L/SZ/F COMP	15 1	LABEL/PTO	19 5
BLADE/60X528/C	9 1		16 1	LABEL/WARNING/BELT	19 2
BLADE/60X630/C	10 1	COVER/B/R/SZ/F COMP	15 3	LABEL/WARNING/HOT	19 3
BL0T/M10X25	3 24		16 3	METAL/CENTER	8 12
	4 24	COVER/CASE	3 3	METAL/SIDE	8 1
BOLT 7T(SP)	22 10		4 3	NIPPLE, GREASE	5 15
	23 10		20 4		8 11
BOLT(S) M10X25	8 2		21 4		17 6
	8 13	COVER/DISCHARGE COMP	13 1		17 13
BOLT, SEMS	17 21		14 1		18 6
	22 13	COVER/UNIVERSAL/SZ	15 6		18 13
	23 13		16 5	NIPPLE/GREASE	8 14
BOLT, SEMS (SP)	2 4		22 14	NONSLIPSHEET/60	19 9
	15 9		23 14	NUT	3 27
	16 8	DECK/MOWER/60/Z/F	12 1		4 26
	22 8	DECK/MOWER/72/SZ/F	11 1		5 18
	22 16	F/SZKIT	22 1		11 3
	23 8		23 1		12 3
	23 16	FITTINGYOKE	24 1	NUT/M12	13 4
BOLT, SEMS (S) M8X16	3 4	FORK/WHEEL/FRON ASSY	17 1		14 4
	4 4		18 1	NUT/M16	5 8
	20 5	FORK/WHEEL/REAR/LH	17 7		17 14
	21 5		18 7		18 14
BOLT/M10X20	3 23	FORK/WHEEL/REAR/RH	17 8	NUT/M20X1.5	9 4
	4 23		18 8		10 4
BOLT/M12X1.25X45	11 2	GEAR/BEVEL/25-1 SET	4 10	NUT/WASHER	2 2
	12 2		21 11		15 2

Alphabetical Index

8654-097-390-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
NUT/WASHER	15 5	PLATE/L/95X36 COMP	22 15	SEAL/OIL	20 10
	15 8		23 15		21 10
	16 2		2 3		3 6
	16 4	PLATE/U/120X100	22 7	SHAFT/INPUT	4 6
	16 7		23 7		20 7
	17 24		3 2		21 7
	18 19	PLUG, DRAIN (1/4)	4 2	SHAFT/OUTPUT	3 11
	22 6		20 3		4 11
	23 6		21 3		20 12
O-RING/G80	3 5	PULLEY, TENSION/100	5 11		21 12
	4 5		5 1	SHAFT/SIDE	8 3
	20 6		5 4	SHAFTYOKE	24 2
PIN, SPLIT/3 X25	21 6	QSYOKE ASSY	24 16	SHIM/0.1	3 14
	13 9	RING, SNAP/16 C	5 14		3 16
	14 9	RING, SNAP/20C	5 12		4 14
PIN, SPRING/8 X40 W	1 2	RING, SNAP/25 C	17 5		4 18
	22 3		18 5		20 15
	23 3		8 6		20 17
PIN/08X60 COMP	17 16	RING/SLIDE	8 17		21 15
	18 16		24 7		21 19
PIN/12X117	17 23	RING/SNAP	24 14	SHIM/0.2	3 15
	18 18		3 8		3 17
PIN/15X245	13 7		3 19		4 15
	14 7		4 8		4 19
PIN/22X106	17 12		4 12		20 16
	18 11		8 10		20 18
PIN/GAUGE COMP	17 3		8 21		21 16
	18 3		20 9		21 20
PIN/ROLLER/REAR COMP	17 19		20 20	SHIM/1.2	9 3
PLATE COMP	2 1		21 9		10 3
	22 5		21 13	SLEEVEYOKE	24 9
	23 5	ROD, CHAIN TENSION	5 17	SPRING, CHAIN TENSION	5 16
PLATE/F00K	22 12	ROLLER ASSY	17 17	SPRING/HT024	13 6
	23 12	SAFETYGUARD/IN	24 6		14 6
PLATE/F00K COMP	22 11	SAFETYGUARD/OUT	24 13	STOPPER/COVER	13 2
	23 11	SEAL, OIL/TC305512	3 20		14 2
PLATE/I/25X680	15 4		4 20	SURCLIP/HOLE	24 5
PLATE/L/32X41	22 9		20 21		24 12
	23 9		21 21	WASHER	5 6
	3 21	SEAL, OIL/TC35528	8 8		5 13
PLATE/L/75X106	3 22		8 19	WASHER(13X34X05)	13 3
	4 21	SEAL/OIL	3 9		14 3
	4 22		4 9	WASHER, PL/M14	3 25
PLATE/L/95X36 COMP	15 7		8 7		4 25
	16 6		8 18		13 8

Alphabetical Index

8654-097-390-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
WASHER, PL/M14	14 8				
WASHER, PL/M22	17 11				
	18 12				
WASHER, SP/M10	3 26				
	4 27				
WASHER, SP/M12	13 5				
	14 5				
WASHER, SP/M16	5 7				
	17 15				
	18 15				
WASHER, SP/M20	9 5				
	10 5				
WASHER/20X60X06	9 2				
	10 2				
WASHER/27X40X2	17 4				
	18 4				
WASHER/45X55X01	3 12				
	4 13				
	20 13				
	21 14				
WASHER/M10	3 28				
	4 28				
WASHER/M20	9 6				
	10 6				
WHEEL/GAUGE ASSY	17 9				
	18 9				
WHEEL/GAUGE/FRONT	17 22				
	18 17				