

RECOMMENDED LIST FOR TG5330 AND TG5390 ENGINE

SEQ	FIG #	KEY #	PART CODE	DESCRIPTION	Q'TY /UNIT	Q'TY	MODEL
1	1	4	6212-569-002-00	OIL SEAL/VALVE	6	12	
2	1	6	6211-141-057-10	GASKET/CYLINDERHEAD	1	1	
3	2	6	6211-173-005-00	SEAL,CYL.HEAD COVER	1	1	
4	3	2	6214-115-003-10	GASKET,INLET MANIFOLD	1	1	
5	4	2	6214-145-004-20	GASKET,EXH.MANIFOLD	1	1	
6	5	2	6214-145-009-00	GASKET	1	1	for TG5390
7	5	6	6214-435-026-00	PIPE/INLET	1	1	for TG5390
8	5	7	6209-360-112-00	HOSE/RUBBER	1	1	for TG5390
9	5	9	6209-360-114-00	HOSE/RUBBER	1	1	for TG5390
10	11	1	6212-551-020-10	VALVE/INTAKE	3	3	for TG5330
11	12	1	6212-551-019-00	VALVE/INTAKE	3	3	for TG5390
12	11	2	6212-552-008-00	VALVE/EXHAUST	3	6	
13	11	3	6212-561-003-00	SPRING/VALVE	6	12	
14	11	4	6212-563-001-00	SEAT,VALVE SPRING	6	12	
15	11	5	6212-565-001-00	CUTTER,VALVE	12	36	
16	16	1	6213-100-004-30	OILPUMP ASSY	1	1	for TG5330
17	17	1	6213-100-010-00	OILPUMP ASSY	1	1	for TG5390
18	16	12	6213-240-002-10	CARTRIDGE/OIL FILTER	1	50	for TG5330
19	17	9	6213-240-005-10	CARTRIDGE/OIL FILTER	1	50	for TG5390
20	17	1	6213-610-005-40	WATERPUMP ASSY	1	1	for TG5330
21	18	1	6213-610-011-10	WATERPUMP ASSY	1	1	for TG5390
22	17	8	6213-613-002-10	GASKET/WATER PUMP	1	1	
23	17	27	6513-770-022-10	THERMOSTAT	1	1	
24	17	29	V723-102-005-50	O-RING	1	1	for TG5330
25	18	29	V721-113-105-00	O-RING	1	1	for TG5390
26	18	5	6213-671-029-00	BELT/V R5 A38.5	1	3	for TG5330
27	19	5	6213-671-031-00	BELT/V R5 A39.5	1	3	for TG5390
28	19	1	6215-300-045-00	INJECTIONNOZZLE ASSY	3	2	for TG5330
29	20	1	6215-300-037-00	INJECTIONNOZZLE ASSY	3	2	for TG5390
30	19	3	6215-315-006-00	HEATSHILD/NOZZLE	3	3	
31	23	1	6281-200-020-00	GENERATOR ASSY	1	1	for TG5330
32	24	1	6281-200-021-00	GENERATOR ASSY	1	1	for TG5390
33	23	7	6281-100-007-20	STARTER ASSY	1	1	
34	24	1	6281-971-003-00	SWITCH/OILPRESSURE	1	1	
35	24	2	6282-450-006-00	THERMOMETER	1	1	
36	24	3	6281-410-023-00	GLOWPLUG	3	9	
37	24	5	6281-910-011-00	SOLENOID	1	1	
38	24	6	6209-630-002-10	GASKET	1	1	
39	26	16	6215-311-036-00	NOZZLE ASSY	3	4	for TG5330
40	27	16	6215-311-005-00	NOZZLE ASSY	3	4	for TG5390

TG5330 AND TG5390 CHASSIS

SEQ	FIG #	KEY #	PART CODE	DESCRIPTION	Q'ty /UNIT	Q'ty	MODEL	REMARKS
1	1	3	1650-102-004-00	NET	1	1		
2	1	9	1650-102-001-00	HOSE/RADIATOR/OUTLET	1	1		
3	1	10	1729-102-002-00	HOSE/RADIATOR/INLET	1	1		
4	3	2	1650-104-210-00	COVER ASSY	1	1		
5	3	4	1650-104-203-00	ELEMENT ASSY	1	20		
6	3	13	1743-104-001-00	HOSE/INLET	1	1	for TG5390	
7	5	4	1742-111-220-00	CAP/TANK/NONLEA ASSY	1	10		
8	5	8	P103-112-003-20	HOSE/700	1	1		
9	5	9	1729-111-270-00	GAUGE/FUEL ASSY	1	3		
10	5	19	1614-105-200-00	FILTER ASSY	1	1		
11	5	27	1672-105-211-00	ELEMENT	1	20		
12	5	31,42	1729-111-300-00	HOSE/FUEL/900 ASSY	2	2		
13	5	34,36,40	1716-105-001-00	HOSE/08X13X300	3	3		
14	5	38	1703-105-210-00	PUMP/FUEL ASSY	1	1		
15	5	47	1729-111-006-00	FILTER/FUEL	1	5		
16	6	4	1404-117-008-00	SPRING,HC022	1	1		
17	6	12	1742-116-220-00	CABLE/ACCELERATOASSY	1	5		
18	6	16	1742-116-230-00	CABLE/PEDAL	1	5		
19	6	26	2143-744-001-00	SPRING/HE060	1	1		
20	7	2	1742-120-210-00	DISK/CLUTCH/240 COMP	1	1		
21	7	4	1744-120-001-00	SLEEVE	1	1		
22	7	5	1742-120-002-00	BEARING.RELEASE	1	1		
23	8	14	1650-135-002-00	SPRING/HE095	1	1		
24	10	14	1337-708-007-00	COVER,METAL	1	2	for Q	
25	10	16	1614-120-005-00	HOSE/400	1	1	for Q	
26	11	14	1337-708-007-00	COVER,METAL	2		for S	SEQ24,FIG10,KEY14
27	11	16	1614-120-005-00	HOSE/400	1		for S	SEQ25,FIG10,KEY16
28	12	4	V600-410-620-70	BEARING/BALL	1	1	for Q	
29	12	5	1742-203-002-00	COLLAR/36X43X10	1	1	for Q	
30	12	6	V600-410-600-70	BEARING/BALL	1	1	for Q	
31	12	8	V744-135-500-80	SEAL,OIL/TC355008	1	3	for Q	
32	12	12,30	1729-214-049-00	BEARING/BALL	3	8	for Q	
33	12	14	V600-410-620-50	BEARING/BALL	1	1	for Q	
34	12	17	1742-203-005-00	HUB/25X50X65	1	1	for Q	
35	12	21	1716-222-013-00	BEARING/NEEDLE	1	1	for Q	
36	12	25	1740-208-058-00	BEARING/NEEDLE	1	1	for Q	
37	12	31	V600-410-600-40	BEARING/BALL	1	1	for Q	
38	13	4	V600-410-620-70	BEARING/BALL	1		for S	SEQ28,FIG12,KEY4
39	13	5	1742-203-002-00	COLLAR/36X43X10	1		for S	SEQ29,FIG12,KEY5
40	13	6	V600-410-600-70	BEARING/BALL	1		for S	SEQ30,FIG12,KEY6
41	13	8	V744-135-500-80	SEAL,OIL/TC355008	1		for S	SEQ31,FIG12,KEY8
42	13	12,28	1729-214-049-00	BEARING/BALL	3		for S	SEQ32,FIG12,KEY12,30
43	13	14	V600-410-620-50	BEARING/BALL	1		for S	SEQ33,FIG12,KEY14
44	13	16	1729-203-004-00	BEARING/NEEDLE	1	1	for S	
45	13	18	1742-203-232-00	SLEEVE	1	3	for S	
46	13	24	1729-216-006-00	BEARING/NEEDLE	1	1	for S	
47	13	26	V600-410-630-40	BEARING/BALL	1	1	for S	
48	13	29	V600-410-600-40	BEARING/BALL	1		for S	SEQ37,FIG12,KEY31
49	14	4	V744-125-400-70	SEAL,OIL/TC25407	1	3		
50	14	7,15	1729-214-049-00	BEARING/BALL	2			SEQ32,FIG12,KEY12,30
51	15	9	1729-216-006-00	BEARING/NEEDLE	1			SEQ46,FIG13,KEY24
52	15	11,21	1742-203-232-00	SLEEVE	2			SEQ45,FIG13,KEY18
53	15	17	1729-214-025-00	BEARING/NEEDLE	1	1		
54	15	19	1729-214-025-00	BEARING/NEEDLE	1	1		

TG5330 AND TG5390 CHASSIS

SEQ	FIG #	KEY #	PART CODE	DESCRIPTION	Q'ty /UNIT	Q'ty	MODEL	REMARKS
55	15	27	1729-203-004-00	BEARING/NEEDLE	1	1		
56	15	31	1716-127-011-00	BEARING/NEEDLE	1	1		
57	16	7	1742-216-003-00	HUB/25X40X58	1	1		
58	16	10	1709-301-001-00	BEARING/NEEDLE	2	2		
59	17	2	1742-218-002-10	GEAR/SPUR/36-31	1	1		
60	17	7	1746-218-001-00	GEAR/SPUR/26	1	1		
61	17	11	V744-120-470-70	SEAL,OIL	1	2		
62	18	11	1632-273-200-00	SEAL,OIL	1	2		
63	20	4	1425-433-018-00	CAP,BLANK/72	1	5		
64	21	2	1742-253-002-00	FORK/SHIFT/REVERSE	1	1	for S	
65	22	3	1742-254-002-00	FORK/SHIFT/1ST	1	1	for S	
66	22	4	1742-254-003-00	FORK/SHIFT/3RD	1	1	for S	
67	23	3	1746-254-003-00	FORK/SHIFT/1ST	1	1	for Q	
68	23	4	1746-254-004-00	FORK/SHIFT/3RD	1	1	for Q	
69	23	22	V742-112-250-50	SEAL,OIL/VC12255	2	2	for Q	
70	24	2	1742-256-002-00	FORK/SHIFT/SUB	1	1		
71	26	2	1742-259-002-00	FORK/SHIFT/PTO	1	1		
72	27	3	1650-263-230-10	JOINT/UNIVERSAL SET	1	1	for S	
73	27	4	1650-263-221-00	JOINT/UNIVERSAL	2	2	for S	
74	29	9	1560-280-004-40	BOOT	1	2		
75	35	1	1742-301-200-00	GEAR/08X42 SET	1	1		
76	36	21	1729-306-004-00	GEAR/HERICAL/54	2	2		
77	36	24	1650-306-200-00	SEAL,OIL ASSY	2	2		
78	36	26	V670-200-009-00	NUT,ADAPTER/AN09	2	2		
79	36	27	V671-400-009-00	WASHER	2	2		
80	39	1	1729-310-201-10	PLATE/PRESSURE/LH	1	1		
81	39	2,6	1729-310-202-00	PLATE/SEPARATER	4	4		
82	39	3,7	1729-310-203-00	PLATE/FRICTION	4	4		
83	39	5	1729-310-211-10	PLATE/PRESSURE/RH	1	1		
84	39	13	V744-122-350-80	SEAL,OIL/TC22358	2	2		
85	46	1	1723-407-300-10	CONTROLLER/STEERING	1	1		
86	46	2	1723-407-200-10	CYLINDER ASSY	1	1		
87	46	9	V744-120-400-70	SEAL/OIL	1	1		
88	46	14	1742-407-200-00	HOSE/700 ASSY	1	1		
89	46	15	1742-407-210-00	HOSE/750 ASSY	1	1		
90	48	1	1733-431-001-10	SHAFT/4WD/511	1	1		
91	48	4	1654-431-200-00	TUBE/450 COMP	1	1		
92	48	5	1742-431-200-00	PIPE/4WD/REAR COMP	1	1		
93	49	1	1650-432-200-00	GEAR/10-30	1	1		
94	49	3	1650-432-001-00	COLLAR/45X52X17	1	1		
95	49	7	1427-432-016-00	SEAL,OIL/21	1	3		
96	50	2	V721-103-107-50	O-RING/G75	1	3		
97	50	6	1614-433-002-00	SEAL/OIL	1	2		
98	51	17	1650-434-004-00	GEAR/BEVEL/11	2	2		
99	51	20	1650-434-005-00	GEAR/BEVEL/17	2	2		
100	51	22	1729-434-005-00	SEAL/OIL ASSY	2	4		
101	51	28,33	1650-434-015-00	PLUG/SEAL/72X08	2	2		
102	51	43	1560-434-012-30	SEAL,OIL	2	4		
103	53	4	1729-501-008-10	GASKET/CASE/CYLINDER	1	1		
104	53	14	1716-501-006-00	HOSE/BREATHER	1	1		
105	53	19	3676-356-001-00	CAP/OIL(30)	1	1		
106	53	26	V744-145-600-90	SEAL,OIL/TC45609	2	4		
107	53	30	V720-115-707-50	O-RING(1B)P75	1	1		
108	56	5	1643-515-202-10	CARTRIDGE/20	1	10	for S	

TG5330 AND TG5390 CHASSIS

SEQ	FIG #	KEY #	PART CODE	DESCRIPTION	Q'ty /UNIT	Q'ty	MODEL	REMARKS
109	56	6	1643-515-203-00	PACKING	1	1	for S	
110	56	13	1742-508-007-00	HOSE/80	1	1	for S	
111	56	21	1742-508-300-00	PUMP/GEAR/13.2 ASSY	1	1	for S	
112	56	33	K200-114-000-00	VALVE ASSY	1	1	for S	
113	56	40	K250-057-000-00	VALVE/RELIEF ASSY	1	1	for S	
114	56	47	K211-073-000-00	VALVE/CONTROL ASSY	1	1	for S	
115	56	51	K250-016-000-00	VALVE,RELIEF ASSY	1	1	for S	
116	57	5	1643-515-202-10	CARTRIDGE/20	1		for Q	SEQ108,FIG56,KEY5
117	57	6	1643-515-203-00	PACKING	1		for Q	SEQ109,FIG56,KEY6
118	57	13	1742-508-007-00	HOSE/80	1		for Q	SEQ110,FIG56,KEY13
119	57	21	1742-508-300-00	PUMP/GEAR/13.2 ASSY	1		for Q	SEQ111,FIG56,KEY21
120	57	34	K250-057-000-00	VALVE/RELIEF ASSY	1		for Q	SEQ113,FIG56,KEY40
121	57	43	K211-073-000-00	VALVE/CONTROL ASSY	1		for Q	SEQ114,FIG56,KEY47
122	57	47	K250-016-000-00	VALVE,RELIEF ASSY	1		for Q	SEQ115,FIG56,KEY51
123	59	1	K135-015-000-00	PUMP GEAR ASSY	1	1	for S	
124	59	16	1742-509-003-00	HOSE/RETURN	1	1	for S	
125	61	1	K135-018-000-00	PUMP GEAR ASSY	1	1	for Q	
126	61	8	K256-004-000-00	REDUCE VALVE ASSY	1	1	for Q	
127	61	9	1650-508-002-00	FILTER/LINE/12X18X15	1	1	for Q	
128	61	22	1742-509-003-00	HOSE/RETURN	1		for Q	SEQ124,FIG59,KEY16
129	61	40	K200-115-000-00	VALVE/LINER ASSY	1	1	for Q	
130	61	41	K200-100-300-00	VALVE/PRV/B ASSY	1	1	for Q	
131	61	42	K200-097-200-00	VALVE/PRV/G ASSY	1	1	for Q	
132	61	49	1729-509-001-00	FILTER/PORT/09	2	2	for Q	
133	86	6	1729-650-210-10	CABLE/BATTERY ASSY	1	3	for S	
134	86	38	1725-681-200-00	RELAY/35A ASSY	1	1	for S	
135	88	6	1729-650-210-10	CABLE/BATTERY ASSY	1		for Q	SEQ133,FIG86,KEY6
136	88	23	1674-652-200-00	LAMP/HEAD ASSY	2	2	for Q	
137	88	38	1725-681-200-00	RELAY/35A ASSY	1		for Q	SEQ134,FIG86,KEY38
138	89	1	1746-652-300-00	SWITCH/ROTARY/E ASSY	1	1	for S	
139	89	7	3821-262-204-00	FUSE/BLADE/32V20A	3	10	for S	
140	89	8	3821-262-203-00	FUSE/BLADE/32V15A	4	7	for S	
141	89	9	3821-262-202-00	FUSE/BLADE/32V10A	8	10	for S	
142	89	10	3824-247-202-00	FUSE/BLADE/32V05A	6	8	for S	
143	89	13	1650-650-222-00	FUSE/SLOWBLOW	2	5	for S	
144	89	14	1650-650-243-00	FUSE/SLOWBLOW	1	5	for S	
145	89	22,24	1690-658-370-00	RELAY/4P ASSY	2	3	for S	
146	89	26	1690-652-200-00	SWITCH ASSY	1	1	for S	
147	89	32	1640-664-320-00	SWITCH/PTO ASSY	1	2	for S	
148	89	33	1742-652-260-00	SWITCH/ALTERNAT ASSY	1	1	for S	
149	89	34	3801-272-302-00	BULB/LAMP/12V1W	1	1	for S	
150	89	37	1740-680-550-00	SWITCH/HAZARD ASSY	1	2	for S	
151	89	38	1544-623-001-00	SWITCH ASSY	1	3	for S	
152	89	43	1746-652-230-00	SWITCH ASSY	1	1	for S	
153	89	45	1518-621-320-00	SWITCH STOP	1	5	for S	
154	89	49	1650-652-900-00	CABLE/META ASSY	1	1	for S	
155	90	1	1746-652-300-00	SWITCH/ROTARY/E ASSY	1		for Q	SEQ138,FIG89,KEY1
156	90	6	1560-666-212-00	DIODE	1	1	for Q	
157	90	7	3821-262-204-00	FUSE/BLADE/32V20A	3		for Q	SEQ139,FIG89,KEY7
158	90	8	3821-262-203-00	FUSE/BLADE/32V15A	5		for Q	SEQ140,FIG89,KEY8
159	90	9	3821-262-202-00	FUSE/BLADE/32V10A	8		for Q	SEQ141,FIG89,KEY9
160	90	10	3824-247-202-00	FUSE/BLADE/32V05A	7		for Q	SEQ142,FIG89,KEY10
161	90	13	1650-650-222-00	FUSE/SLOWBLOW	2		for Q	SEQ143,FIG89,KEY13
162	90	14	1650-650-243-00	FUSE/SLOWBLOW	1		for Q	SEQ144,FIG89,KEY14

TG5330 AND TG5390 CHASSIS

SE Q	FIG #	KEY #	PART CODE	DESCRIPTION	Q'ty /UNIT	Q'ty	MODEL	REMARKS
163	90	15	1652-654-212-00	DIODE	1	1	for Q	
164	90	23	1690-652-210-00	RELAY ASSY	1	1	for Q	
165	90	25	1690-658-370-00	RELAY/4P ASSY	1		for Q	SEQ145,FIG89,KEY22,24
166	90	27	1729-652-290-00	SWITCH/TWIN ASSY	1	1	for Q	
167	90	28	3807-836-400-00	ACTUATOR ASSY	2	2	for Q	
168	90	33	1640-664-320-00	SWITCH/PTO ASSY	1		for Q	SEQ147,FIG89,KEY32
169	90	34	1742-652-260-00	SWITCH/ALTERNAT ASSY	1		for Q	SEQ148,FIG89,KEY33
170	90	35	3801-272-302-00	BULB/LAMP/12V1W	1		for Q	SEQ149,FIG89,KEY34
171	90	38	1740-680-550-00	SWITCH/HAZARD ASSY	1		for Q	SEQ150,FIG89,KEY37
172	90	39	1544-623-001-00	SWITCH ASSY	1		for Q	SEQ151,FIG89,KEY38
173	90	44	1746-652-230-00	SWITCH ASSY	1		for Q	SEQ152,FIG89,KEY43
174	90	46	1729-656-210-00	SWITCH ASSY	1	1	for Q	
175	90	47	1518-621-320-00	SWITCH STOP	1		for Q	SEQ153,FIG89,KEY45
176	93	4	1746-654-200-10	LAMP/REAR/LH SET	1	1		
177	93	8,14	1564-654-213-00	BULB,LAMP/12V21W	2	2		
178	93	9,15	1566-656-211-00	BULB/12V21-5W	2	2		
179	93	10	1746-654-210-10	LAMP/REAR/RH SET	1	1		
180	93	18	1674-654-270-00	LAMP/NUMBERPLATE SET	1	1		
181	93	25	1674-654-200-10	LAMP/FRONT SET	2	2		
182	94	16	3650-270-214-00	BULB	8	4	for S	
183	94	18	1614-670-281-00	BULB/LAMP/12V/1.7W	4	2	for S	
184	95	6	1729-656-205-00	LAMP ASSY	1	1	for Q	
185	95	7	1729-656-206-00	LAMP ASSY	14	14	for Q	
186	95	12	1729-656-207-00	LAMP ASSY	1	1	for Q	
187	97	14	1740-680-520-00	SWITCH/SENSOR ASSY	1	1	for Q	
188	97	18	1716-680-330-00	SWITCH/LEVER ASSY	1	5	for Q	
189	97	26	1518-621-470-00	SWITCH,SAFETY ASSY	1	3	for Q	