

TG5470 CHASSIS

SEQ	FIG	KEY	PART CODE	DESCRIPTION	Q'ty	Q'ty	MODEL	REMARKS
1	1	5	1700-102-230-10	NET/12/474X517 COMP	1	1		
2	1	9	1734-102-001-00	HOSE/RADIATOR/OUTLET	1	1		
3	1	10	1734-102-002-00	HOSE/RADIATOR/INLET	1	1		
4	4	2	1656-104-210-00	COVER ASSY	1	1		
5	4	4	1656-104-202-00	ELEMENT ASSY	1	20		
6	5	4	1729-111-280-00	CAP/TANK ASSY	1	5		
7	5	8	P103-112-003-20	HOSE/700	1	1		
8	5	9	1734-111-270-00	GAUGE/FUEL ASSY	1	3		
9	5	20	1650-111-220-00	FILTER/FUEL ASSY	1	20		
10	5	28	1513-102-329-00	ELEMENT	1	20		
11	5	37	1744-111-220-00	HOSE/FUEL/600 ASSY	1	1		
12	5	40	1716-105-001-00	HOSE/08X13X300	1	1		
13	5	44	1608-105-240-20	HOSE/06X10X365	1	1		
14	5	46	1729-111-300-00	HOSE/FUEL/900 ASSY	1	1		
15	5	50	1729-111-006-00	FILTER/FUEL	1	5		
16	6	4	1404-117-008-00	SPRING,PRESS/22	1	3	for H	
17	6	12	1744-116-200-00	CABLE/ACCELERATOASSY	1	5	for H	
18	7	4	1404-117-008-00	SPRING,PRESS/22	1		except H	SEQ16
19	7	12	1744-116-200-00	CABLE/ACCELERATOASSY	1		except H	SEQ17
20	6	16	1656-116-210-10	CABLE/PEDAL ASSY	1	5	except H	
21	6	26	2143-744-001-00	SPRING/HE060	1	3	except H	
22	8	2	1744-120-200-00	DISK/CLUTCH/240 COMP	1	1	except H	
23	8	4	1744-120-001-00	SLEEVE	1	1	except H	
24	8	5	1742-120-002-00	BEARING.RELEASE	1	1	except H	
25	9	14	1650-135-002-00	SPRING/HE095	1	5		
26	12	14	1337-708-007-00	COVER,METAL	1	2	for Q	
27	12	16	3664-310-005-10	HOSE/08X13X420	1	1	for Q	
28	13	14	1337-708-007-00	COVER,METAL	2		for S	SEQ26
29	13	16	3664-310-005-10	HOSE/08X13X420	1		for S	SEQ27
30	15	4	1734-203-012-00	BEARING/BALL	1	1	for Q	
31	15	5	1742-203-002-00	COLLAR/36X43X10	1	1	for Q	
32	15	6	V600-410-600-70	BEARING/BALL	1	1	for Q	
33	15	8	V744-135-500-80	SEAL,OIL/TC355008	1	5	for Q	
34	15	12,31	1594-218-001-00	BEARING/BALL 6305SH2	2	3	for Q	
35	15	13	1729-214-049-00	BEARING/BALL	1	1	for Q	
36	15	15	V600-410-620-50	BEARING/BALL	1	1	for Q	
37	15	18	1742-203-005-10	HUB/25X50X65	1	1	for Q	
38	15	22	1716-222-013-00	BEARING/NEEDLE	1	1	for Q	
39	15	26	1740-208-058-00	BEARING/NEEDLE	1	1	for Q	
40	15	32	V600-410-600-40	BEARING/BALL	1	1	for Q	
41	16	4	1734-203-012-00	BEARING/BALL	1		for S	SEQ30
42	16	5	1742-203-002-00	COLLAR/36X43X10	1		for S	SEQ31
43	16	6	V600-410-600-70	BEARING/BALL	1		for S	SEQ32
44	16	8	V744-135-500-80	SEAL,OIL/TC355008	1		for S	SEQ33
45	16	12,29	1594-218-001-00	BEARING/BALL 6305SH2	2		for S	SEQ34
46	16	13	1729-214-049-00	BEARING/BALL	1		for S	SEQ35
47	16	15	V600-410-620-50	BEARING/BALL	1		for S	SEQ36
48	16	17	1726-244-062-00	BEARING/NEEDLE	1	1	for S	
49	16	25	1729-203-017-00	BEARING/NEEDLE	1	1	for S	
50	16	27	V600-410-630-40	BEARING/BALL	1	1	for S	
51	18	4	V744-125-380-70	SEAL,OIL/TC25387	1	3	except H	
52	18	7	1696-203-004-00	BEARING/BALL	1	1	except H	
53	18	15	1729-214-049-00	BEARING/BALL	1		except H	SEQ35
54	19	2	V600-410-630-60	BEARIGN/BALL	1	1	for H	
55	19	2	V600-410-620-50	BEARING/BALL	1		for H	SEQ36
56	19	16	V600-410-600-60	BEARING/BALL	1	1	for H	
57	21	9	1729-216-006-00	BEARING/NEEDLE	1	1	except H	
58	21	11,21	1742-203-232-00	SLEEVE	2	2	except H	
59	21	17,19	1729-214-025-00	BEARING/NEEDLE	2	2	except H	
60	21	27	1729-203-004-00	BEARING/NEEDLE	1	1	except H	

TG5470 CHASSIS

SEQ	FIG	KEY	PART CODE	DESCRIPTION	Q'ty	Q'ty	MODEL	REMARKS
61	21	31	1716-127-011-00	BEARING/NEEDLE	1	1	except H	
62	22	7	V600-410-620-50	BEARING/BALL	1		for H	SEQ36
63	22	9	1716-127-011-00	BEARING/NEEDLE	1		for H	SEQ61
64	22	19	V607-110-620-70	BEARING,RB/6207N	1	3	for H	
65	23	7	1742-216-003-00	HUB/25X40X58	1	1	except H	
66	23	10	1709-301-001-00	BEARING/NEEDLE	2	2	except H	
67	24	4	1729-216-006-00	BEARING/NEEDLE	1		for H	SEQ57
68	24	6	1743-216-054-00	HUB/23X46X58	2	2	for H	
69	25	2	1744-218-002-00	GEAR/SPUR/33-31	1	1		
70	25	7	1746-218-001-00	GEAR/SPUR/26	1	1		
71	25	11	V744-125-470-80	SEAL,OIL/TC25478	1	5		
72	26	11	1632-273-200-00	SEAL,OIL	1	5		
73	28	10	V607-110-620-50	BEARING,RB/6205NR	2	2		
74	28	23	1426-258-200-10	SEAL ASSY	1	5		
75	29	3	V744-135-500-80	SEAL,OIL/TC355008	1			SEQ33
76	30	2	1744-253-002-00	FORK/SHIFT/REVERSE	1	1	for S	
77	31	3	1742-254-002-00	FORK/SHIFT/1ST	1	1	for S	
78	31	4	1742-254-003-00	FORK/SHIFT/3RD	1	1	for S	
79	32	3	1746-254-003-00	FORK/SHIFT/1ST	1	1	for Q	
80	32	4	1746-254-004-00	FORK/SHIFT/3RD	1	1	for Q	
81	32	22	V742-112-250-50	SEAL,OIL/VC12255	2	2	for Q	
82	33	2	1742-256-002-00	FORK/SHIFT/SUB	1	1		
83	35	2	1742-259-002-00	FORK/SHIFT/PTO	1	1		
84	36	3	1744-263-200-00	JOINT/UNIVERSAL SET	1	1	for S	
85	36	4	1650-263-221-00	JOINT/UNIVERSAL	2	2	for S	
86	38	9	1560-280-004-40	BOOT	1	3	for S	
87	44	1	1744-301-200-00	GEAR/07X37 SET	1	1		
88	45	24	1734-306-006-00	GEAR/HERICAL/63	2	2		
89	45	29	1564-307-200-20	SEAL/OIL/UNITIGHTS	2	6		
90	48	1	1729-310-201-10	PLATE/PRESSURE/LH	1	1	except H	
91	48	2,6	1729-310-202-00	PLATE/SEPARATER	4	4	except H	
92	48	3,7	1729-310-203-00	PLATE/FRICTION	4	4	except H	
93	48	5	1729-310-211-10	PLATE/PRESSURE/RH	1	1	except H	
94	48	13	V744-122-350-80	SEAL,OIL/TC22358	2	4	except H	
95	49	1	1729-310-201-10	PLATE/PRESSURE/LH	1		for H	SEQ90
96	49	2,6	1729-310-202-00	PLATE/SEPARATER	4		for H	SEQ91
97	49	3,7	1729-310-203-00	PLATE/FRICTION	4		for H	SEQ92
98	49	5	1729-310-211-10	PLATE/PRESSURE/RH	1		for H	SEQ93
99	49	13	V744-122-350-80	SEAL,OIL/TC22358	2		for H	SEQ94
100	58	1	1646-407-670-00	CONTROLLER/STEERING	1	1		
101	58	2	K167-007-000-00	CYLINDER ASSY	1	1		
102	58	16	V744-120-400-70	SEAL/OIL	1	3		
103	58	20	1734-407-200-20	HOSE/325 ASSY	1	1		
104	58	22	1734-407-210-20	HOSE/425 ASSY	1	1		
105	61	1	1734-431-001-00	SHAFT/4WD/511	1	1		
106	61	6	1564-431-200-30	TUBE/450 COMP	1	1		
107	62	1	1744-432-200-00	GEAR/07X31 SET	1	1		
108	62	4	V744-125-400-70	SEAL,OIL/TC25407	1	5		
109	62	5	1488-411-011-00	COLLAR/55X60X16	1	1		
110	62	6	1727-432-001-00	COLLAR/57X62X4	1	1		
111	64	10	V742-165-850-90	SEAL,OIL/VC65859	1	3		
112	64	14	V742-155-700-60	SEAL/OIL/VC55706	1	3		
113	66	3	1656-434-001-00	GEAR/BEVEL/13	2	2		
114	66	11	1656-434-002-00	GEAR/BEVEL/17	2	2		
115	66	20	1564-434-004-10	SEAL/OIL	2	10		
116	66	27	1650-434-015-00	PLUG/SEAL/72X08	2	6		
117	66	33	1425-433-031-00	SEAL,OIL	2	10		
118	66	44	1564-434-013-10	SEAL,OIL	2	10		
119	68	4	1729-501-008-10	GASKET/CASE/CYLINDER	1	1		
120	68	14	1716-501-006-00	HOSE/BREATHER	1	1		

TG5470 CHASSIS

SEQ	FIG	KEY	PART CODE	DESCRIPTION	Q'ty	Q'ty	MODEL	REMARKS
121	69	19	3676-356-001-00	CAP/OIL(30)	1	1		
122	69	27	V744-145-600-90	SEAL,OIL/TC45609	2	4		
123	69	31	V720-115-404-50	O-RING(1B)P75	1	1		
124	71	5	1643-515-202-10	CARTRIDGE/20	1	20	for S	
125	71	6	1643-515-203-00	PACKING	1	3	for S	
126	71	13	1742-508-007-00	HOSE/80	1	1	for S	
127	71	21	1727-515-210-00	PUMP/GEAR ASSY	1	1	for S	
128	71	34	K200-114-000-10	VALVE ASSY	1	1	for S	
129	71	41	K250-057-000-00	VALVE/RELIEF ASSY	1	1	for S	
130	71	49	K211-073-000-00	VALVE/CONTROL ASSY	1	1	for S	
131	71	53	K250-016-000-00	VALVE,RELIEF ASSY	1	2	for S	
132	72	5	1643-515-202-10	CARTRIDGE/20	1		for Q	SEQ124
133	72	6	1643-515-203-00	PACKING	1		for Q	SEQ125
134	72	13	1742-508-007-00	HOSE/80	1		for Q	SEQ126
135	72	21	1727-515-210-00	PUMP/GEAR ASSY	1		for Q	SEQ127
136	72	35	K250-057-000-00	VALVE/RELIEF ASSY	1		for Q	SEQ129
137	72	45	K211-073-000-00	VALVE/CONTROL ASSY	1		for Q	SEQ130
138	72	49	K250-016-000-00	VALVE,RELIEF ASSY	1		for Q	SEQ131
139	73	5	1643-515-202-10	CARTRIDGE/20	1		for H	SEQ124
140	73	6	1643-515-203-00	PACKING	1		for H	SEQ125
141	73	13	1742-508-007-00	HOSE/80	1		for H	SEQ126
142	73	21	1727-515-210-00	PUMP/GEAR ASSY	1		for H	SEQ127
143	73	34	K200-114-000-10	VALVE ASSY	1		for H	SEQ128
144	73	41	K250-057-000-00	VALVE/RELIEF ASSY	1		for H	SEQ129
145	73	49	K211-073-000-00	VALVE/CONTROL ASSY	1		for H	SEQ130
146	73	53	K250-016-000-00	VALVE,RELIEF ASSY	1		for H	SEQ131
147	75	1	K135-015-000-00	PUMP GEAR ASSY	1	1	for S	
148	75	17	1744-509-004-00	HOSE/RETURN	1	1	for S	
149	77	1	K135-018-000-00	PUMP GEAR ASSY	1	3	for Q	
150	77	9	K256-004-000-00	REDUCE VALVE ASSY	1	1	for Q	
151	77	10	1650-508-002-00	FILTER/LINE/12X18X15	1	1	for Q	
152	77	23	1744-509-004-00	HOSE/RETURN	1		for Q	SEQ148
153	77	39	K200-115-000-00	VALVE/LINER ASSY	1	1	for Q	
154	77	40	K200-100-300-00	VALVE/PRV/B ASSY	1	1	for Q	
155	77	41	K200-097-200-00	VALVE/PRV/G ASSY	1	1	for Q	
156	77	48	1729-509-001-00	FILTER/PORT/09	2	1	for Q	
157	78	1	K135-018-000-00	PUMP GEAR ASSY	1		for H	SEQ149
158	78	18	K250-049-000-00	VLAVE/RELIEF	1	1	for H	
159	78	31,36	1734-508-320-10	HOSE/310 ASSY	2	2	for H	
160	78	52	1646-516-690-00	FILTER/CHARGE ASSY	1	1	for H	
161	78	53	1646-516-692-00	CARTRIDGE ASSY	1	5	for H	
162	116	10,22	1743-642-600-00	CABLE/CRUISE/A ASSY	3	9	for H	
163	116	40	1743-642-610-00	CABLE/CRUISE/B ASSY	1	1	for H	
164	116	49	1743-642-690-00	CABLE/PEDAL/HST ASSY	1	3	for H	
165	117	6	1734-650-210-00	CABLE/BATTERY ASSY	1	3		
166	117	36	1725-681-200-00	RELAY/35A ASSY	1	1		
167	119	1	1746-652-300-00	SWITCH/ROTARY/E ASSY	1	1	for H	
168	119	6	1560-666-212-00	DIODE	2	2	for H	
169	119	7	3821-262-204-00	FUSE/BLADE/32V20A	4	10	for H	
170	119	8	3821-262-203-00	FUSE/BLADE/32V15A	5	5	for H	
171	119	9	3821-262-202-00	FUSE/BLADE/32V10A	7	10	for H	
172	119	10	3824-247-202-00	FUSE/BLADE/32V05A	7	5	for H	
173	119	13	1650-650-222-00	FUSE/SLOWBLOW	2	20	for H	
174	119	14	1650-650-243-00	FUSE/SLOWBLOW	1	5	for H	
175	119	15	1729-652-232-00	FUSE/SLOWBLOW	1	3	for H	
176	119	23,27	1690-658-370-00	RELAY/4P ASSY	2	3	for H	
177	119	31	1742-652-300-00	SWITCH/PTO ASSY	1	2	for H	
178	119	32	1742-652-260-00	SWITCH/ALTERNAT ASSY	1	1	for H	
179	119	36	1729-656-210-00	SWITCH ASSY	1	1	for H	
180	119	37	1740-680-550-00	SWITCH/HAZARD ASSY	1	2	for H	

TG5470 CHASSIS

SEQ	FIG	KEY	PART CODE	DESCRIPTION	Q'ty	Q'ty	MODEL	REMARKS
181	119	38	1544-623-001-00	SWITCH ASSY	1	3	for H	
182	119	43	1746-652-230-00	SWITCH ASSY	1	1	for H	
183	119	45	1518-621-320-00	SWITCH STOP	1	5	for H	
184	120	1	1746-652-300-00	SWITCH/ROTARY/E ASSY	1		for S	SEQ167
185	120	6	1560-666-212-00	DIODE	2		for S	SEQ168
186	120	7	3821-262-204-00	FUSE/BLADE/32V20A	3		for S	SEQ169
187	120	8	3821-262-203-00	FUSE/BLADE/32V15A	4		for S	SEQ170
188	120	9	3821-262-202-00	FUSE/BLADE/32V10A	8		for S	SEQ171
189	120	10	3824-247-202-00	FUSE/BLADE/32V05A	6		for S	SEQ172
190	120	13	1650-650-222-00	FUSE/SLOWBLOW	2		for S	SEQ173
191	120	14	1650-650-243-00	FUSE/SLOWBLOW	1		for S	SEQ174
192	120	22,24	1690-658-370-00	RELAY/4P ASSY	2		for S	SEQ176
193	120	26	1690-652-200-00	SWITCH ASSY	1	1	for S	
194	120	32	1742-652-300-00	SWITCH/PTO ASSY	1		for S	SEQ177
195	120	33	1742-652-260-00	SWITCH/ALTERNAT ASSY	1		for S	SEQ178
196	120	37	1740-680-550-00	SWITCH/HAZARD ASSY	1		for S	SEQ180
197	120	38	1544-623-001-00	SWITCH ASSY	1	3	for S	
198	120	43	1746-652-230-00	SWITCH ASSY	1		for S	SEQ182
199	120	45	1518-621-320-00	SWITCH STOP	1		for S	SEQ183
200	120	49	1656-652-290-00	CABLE/META ASSY	1	3	for S	
201	121	1	1746-652-300-00	SWITCH/ROTARY/E ASSY	1		for Q	SEQ167
202	121	6	1560-666-212-00	DIODE	1		for Q	SEQ168
203	121	7	3821-262-204-00	FUSE/BLADE/32V20A	3		for Q	SEQ169
204	121	8	3821-262-203-00	FUSE/BLADE/32V15A	5		for Q	SEQ170
205	121	9	3821-262-202-00	FUSE/BLADE/32V10A	8		for Q	SEQ171
206	121	10	3824-247-202-00	FUSE/BLADE/32V05A	7		for Q	SEQ172
207	121	13	1650-650-222-00	FUSE/SLOWBLOW	2		for Q	SEQ173
208	121	14	1650-650-243-00	FUSE/SLOWBLOW	1		for Q	SEQ174
209	121	16	1729-652-232-00	FUSE/SLOWBLOW	1		for Q	SEQ175
210	121	26,28	1690-658-370-00	RELAY/4P ASSY	2		for Q	SEQ176
211	121	30	1729-652-290-00	SWITCH/TWIN ASSY	1	1	for Q	
212	121	36	1742-652-300-00	SWITCH/PTO ASSY	1		for Q	SEQ177
213	121	37	1742-652-260-00	SWITCH/ALTERNAT ASSY	1		for Q	SEQ178
214	121	41	1740-680-550-00	SWITCH/HAZARD ASSY	1		for Q	SEQ180
215	121	42	1544-623-001-00	SWITCH ASSY	1		for Q	SEQ197
216	121	47	1746-652-230-00	SWITCH ASSY	1		for Q	SEQ182
217	121	49	1729-656-210-00	SWITCH ASSY	1		for Q	SEQ179
218	121	50	1518-621-320-00	SWITCH STOP	1		for Q	SEQ183
219	126	4	1746-654-200-10	LAMP/REAR/LH SET	1	1		
220	126	9,15	1566-656-211-00	BULB/LAMP/12V5W	2	5		
221	126	10	1746-654-210-10	LAMP/REAR/RH SET	1	1		
222	126	18	1674-654-270-00	LAMP/NUMBERPLATE SET	1	1		
223	126	25	1674-654-200-10	LAMP/FRONT SET	2	2		
224	127	16	3650-270-214-00	BULB	8	10	for S	
225	127	18	1614-670-281-00	BULB/LAMP/12V/1.7W	4	4	for S	
226	128	6	1729-656-205-00	LAMP ASSY	1	1	except H for S	
227	128	7	1729-656-206-00	LAMP ASSY	14	14	except H for S	
228	128	12	1729-656-207-00	LAMP ASSY	1	1	except H for S	
229	129	3	1729-658-202-00	FUSE/BLADE/32V7.5A	2	2	for CY	
230	129	4	3821-262-203-00	FUSE/BLADE/32V15A	5		for CY	SEQ170
231	129	5	3821-262-202-00	FUSE/BLADE/32V10A	4		for CY	SEQ171
232	129	6	3824-247-202-00	FUSE/BLADE/32V05A	3		for CY	SEQ172
233	129	13	1690-658-370-00	RELAY/4P ASSY	3		for CY	SEQ176
234	129	14	1593-623-530-00	RELAY,5P ASSY	1	5	for CY	
235	129	27	1650-658-320-10	BLADE/WIPER/450 ASSY	1	2	for CY	
236	129	35	1518-621-540-00	SWITCH,WIPER ASSY	1	2	for CY	
237	129	42	1518-621-532-00	VALVE,CHECK	1	1	for CY	
238	129	43	1696-658-340-00	LAMP/WORKING ASSY	2	2	for CY	
239	129	51	3612-631-001-00	LAMP/WINKER B	2	4	for CY	
240	129	63	1729-658-230-00	LAMP/ROOM ASSY	1	1	for CY	

TG5470 CHASSIS

SEQ	FIG	KEY	PART CODE	DESCRIPTION	Q'ty	Q'ty	MODEL	REMARKS
241	129	66	1729-658-234-00	BULB/LAMP/12V5W	1	1	for CY	
242	131	9	1740-680-520-00	SWITCH/SENSOR ASSY	1	1	for H	
243	133	14	1740-680-520-00	SWITCH/SENSOR ASSY	1		for Q	SEQ242
244	133	20	1716-680-330-00	SWITCH/LEVER ASSY	1	5	for Q	
245	133	28	1518-621-470-00	SWITCH,SAFETY ASSY	1	3	for Q	
246	134	13	1740-680-520-00	SWITCH/SENSOR ASSY	1		for H	SEQ242
247	134	19	1716-680-330-00	SWITCH/LEVER ASSY	1		for H	SEQ244
248	134	27,33	1518-621-470-00	SWITCH,SAFETY ASSY	2		for H	SEQ245

TG5470 ENGINE

SEQ	FIG #	KEY #	PART CODE	DESCRIPTION	Q'TY /UNIT	Q'TY
1	1	4	6212-569-002-00	SEAL,OIL	8	16
2	1	7	6211-141-047-00	GASKET/CYLINDERHEAD	1	1
3	2	8	6211-173-007-20	SEAL,CYL.HEAD COVER	1	1
4	3	2	6214-115-008-00	GASKET,INLET MANIFOLD	1	1
5	4	2	6214-145-007-00	GASKET,EXH.MANIFOLD	1	1
6	11	1	6212-551-012-10	VALVE/INTAKE	4	8
7	11	2	6212-552-008-00	VALVE/EXHAUST	4	8
8	11	3	6212-561-003-00	SPRING/VALVE	8	16
9	11	4	6212-563-001-00	SEAT,VALVE SPRING	8	16
10	11	5	6212-565-001-00	CUTTER,VALVE	16	48
11	16	1	6213-100-004-30	OILPUMP ASSY	1	1
12	16	11	6213-240-005-10	CARTRIDGE/OIL FILTER	1	50
13	17	1	6213-610-009-40	WATERPUMP ASSY	1	1
14	17	8	6213-613-004-00	GASKET/WATER PUMP	1	1
15	17	28	6213-770-002-00	THERMOSTAT	1	1
16	17	30	V723-102-006-30	O-RING	1	1
17	18	5	6213-671-033-00	BELT/VR5A41.0	1	10
18	19	1	6215-300-045-00	INJECTIONNOZZLE ASSY	4	4
19	19	3	6215-315-006-00	HEATSHILD/NOZZLE	4	4
20	23	1	6281-200-004-00	GENERATOR ASSY	1	1
21	23	7	6281-100-010-30	STARTER ASSY	1	1
22	24	1	6281-971-003-00	SWITCH/OILPRESSURE	1	1
23	24	2	6282-450-007-00	THERMOMETER	1	1
24	24	4	6281-410-023-00	GLOWPLUG	4	12
25	24	6	6281-910-011-00	SOLENOID	1	1
26	24	7	6209-630-002-10	GASKET	1	1
27	26	16	6215-311-036-00	NOZZLE ASSY	4	20