

- ① KEY shows the location of parts diagramed in the illustration.
- ② Parts numbers begin with `V` and `W` are standard parts of the market.
- ③ `LH` and `RH` on the parts name are described against the moving direction of the machine or are described on the condition how to install parts on the machines.
- ④ SPC : The following symbol classifies parts to be used for machines.
 - `\*` means standard parts.
 - `T` shows that the parts can be installed as optional parts.
 - `R` shows that the parts can be used as applicable parts to replace originally equipped parts.
- ⑤ Upper column : QTY shows the number of parts to be used for one unit of machine.

`M` is indicated for parts supplied by a meter long.

`1` is indicated for parts supplied by liter.

`AR` is indicated for parts need to be adjusted or regulated.

Lower column : serial number

—229 means serial number up to 229.

230— means serial number 230 and after.

⑥ ITC : Interchangeability

`1`...OLD ← NEW

New parts can be used in place of the old parts.

`2`...OLD → NEW

Old parts can be used in place of the new parts.

`3`...OLD →← NEW

Old parts and new parts can not be replaced each other.

⑦ COL : Color code

Color is signified with color code number for colored parts.

Please see the color list shown in the next page.

⑧ GRP : Parts shown in this column can be replaced by SET parts.

Example : Parts marked ① can be replaced by parts marked ②, and
④ for ③, so the rest follow in the same alphabetical
order.

⑨ Remarks

* Other maker's part code number is shown in this column.

* When Fig. No. is shown in the Remark column of SET parts or ASSY parts,
each of their component parts are listed in said Fig. No.

3. Color :

The following colors are used color parts.

COLOR CODE	COLOR	SPRAY TYPE PARTS CODE	PAINTS 4K DRUM PARTS CODE	PAINTS 16K DRUM PARTS CODE
7 F	MIRROR BLACK	1300-954-001-10	1300-954-003-00	1300-954-004-00

NOTE : Color code is signified only for the parts assigned by the maker as color parts.

4. Serial Numbers :

For chassies serial number is shown on the LABEL.

Please see



5. Parts Order


- 1) Parts numbers listed in the parts catalogue are all registered in “ISEKI on-line computer” .
- 2) When you order parts, please make sure of correct numbers.
- 3) When substitute parts is available, the part number ordered will be automatically turned to a new part number.
- 4) Please be sure to use “ISEKI GENUINE PARTS” .

Any other similar parts other than ISEKI parts when used may cause a trouble that makes us unable to repair or guarantee the warrant.


*** Structure Table of Model ***

FIG.	M O D E L	S S S S									
		S S M S									
		M E M E M E									
		4 4 5 4 5 4 6 4									
		8 F 4 F 4 F 0 F									
		T T T T									
		X X X X									
		G G G G									
		2 2 2 2									
		3 3 3 3									
		F F F F									
1		* *	* *								
2		* *	* *								
3			*								
4				*							
5					*						
6		*									
7			*								
8		*									
9			*								
10				*							
11		*	*								
12		*									
13			*								
14			*								
15			*								
16		* *									
17			*								
18			*								
19		*									
20			*								
21			*								
22		*									
23		*									
24			*								
25		*									
26			*								
27			*								
28		*									
29			*								
30			*								
31			*								
32		*									
33			*								
34		*	*	*							
35		*	*	*	*						
36		*	*								
37			*								
38		*									
39		R									
40			R R								
41		R									
42		R									
43			R								
44				R							
45			R								

(SSM48, 54, 60 (TXG23F))



(SMM54TXG23F)



Contents

SSM48,54,60,SMM54

JOINT(UNIVERSAL)SYSTEM..... Fig. 1

COVER(JOINT)SYSTEM..... Fig. 2

CASE(BEVEL)SYSTEM(SSM54)..... Fig. 3

CASE(BEVEL)SYSTEM(SMM54)..... Fig. 4

CASE(BEVEL)SYSTEM(SSM60)..... Fig. 5

CASE(BEVEL)SYSTEM(SSM48)..... Fig. 6

PULLEY SYSTEM(SMM54)..... Fig. 7

PULLEY SYSTEM(SSM48)..... Fig. 8

PULLEY SYSTEM(SSM54)..... Fig. 9

PULLEY SYSTEM(SSM60)..... Fig. 10

BELT SYSTEM(SSM54)(SMM54)..... Fig. 11

BELT SYSTEM(SSM48)..... Fig. 12

BELT SYSTEM(SSM60)..... Fig. 13

METAL SYSTEM(SMM54)..... Fig. 14

METAL SYSTEM(SSM60)..... Fig. 15

METAL SYSTEM(SSM48)(SSM54)..... Fig. 16

SETTING PARTS(BLADE)SYSTEM(SMM54)..... Fig. 17

BLADE SYSTEM(SSM60)..... Fig. 18

BLADE SYSTEM(SSM48)..... Fig. 19

BLADE SYSTEM(SSM54)..... Fig. 20

DECK(MOWER)SYSTEM(SMM54)..... Fig. 21

DECK(MOWER)SYSTEM(SSM54)..... Fig. 22

DECK(MOWER)SYSTEM(SSM48)..... Fig. 23

DECK(MOWER)SYSTEM(SSM60)..... Fig. 24

COVER(DISCHARGE)SYSTEM(SSM48)..... Fig. 25

COVER(DISCHARGE)SYSTEM(SSM54)..... Fig. 26

COVER(DISCHARGE)SYSTEM(SSM60)..... Fig. 27

COVER(BELT)SYSTEM(SSM48).....	Fig. 28
COVER(BELT)SYSTEM(SSM54).....	Fig. 29
COVER(BELT)SYSTEM(SMM54).....	Fig. 30
COVER(BELT)SYSTEM(SSM60).....	Fig. 31
WHEEL(GAUGE)SYSTEM(SMM54).....	Fig. 32
WHEEL(GAUGE)SYSTEM(SSM48).....	Fig. 33
WHEEL(GAUGE)SYSTEM(SSM54)(SSM60).....	Fig. 34
LINK(LIFT)SYSTEM.....	Fig. 35
LABEL(SSM54)(SSM60).....	Fig. 36
LABEL(SMM54).....	Fig. 37
LABEL(SSM48).....	Fig. 38


OPTIONAL PARTS


CASE(BEVEL/28-17)ASSY(SSM48)(REPAIR).....	Fig. 39
CASE(BEVEL)ASSY(SMM54)(SSM60)(REPAIR).....	Fig. 40
CASE(BEVEL)ASSY(SSM54)(REPAIR).....	Fig. 41
F(TXG)KIT(SSM48)(REPAIR).....	Fig. 42
F(TXG)KIT(SSM54)(REPAIR).....	Fig. 43
F(TXG)KIT(SSM60)(REPAIR).....	Fig. 44
F(TXG)KIT(SMM54)(REPAIR).....	Fig. 45

COMPONENT PARTS

COMPONENT PARTS

FOR 8595-101-710-00 ON Fig.1.....	Fig. 46
-----------------------------------	---------

[illegible]

[illegible]



[illegible]


FIG. 7 PULLEY SYSTEM(SMM54)



8658-202 -0100


[illegible]


FIG. 8 PULLEY SYSTEM(SSM48)





8595-202A-0100


[illegible]


[illegible]


[illegible]


[illegible]


[illegible]


[illegible]


[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]



[illegible]

FIG. 25 COVER(DISCHARGE)SYSTEM(SSM48)




8595-406 -0100

[illegible]


[illegible]


FIG. 28 COVER(BELT)SYSTEM(SSM48)





8595-407G-0100


[illegible]


[illegible]


[illegible]


[illegible]

[illegible]

[illegible]



[illegible]

[illegible]




[illegible]


FIG. 41 CASE(BEVEL)ASSY(SSM54)(REPAIR)




8657-201X-0100

[illegible]



[illegible]

[illegible]

Numerical Index

8595-097-190-00

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
1427-317-003-00	32	9	2500-901-014-30	38	4	8593-014-200-10	7	11
	33	6	2500-901-027-00	36	1		8	11
	34	9		37	1		9	11
1434-211-004-00	7	3		38	1		10	11
	8	3	3621-211-003-00	7	14	8595-101-710-00	1	1
	9	3		8	14		42	2
1560-214-003-00	10	3		9	14		43	2
	3	17		10	14		44	2
	4	13	3664-416-072-00	32	21		45	2
	5	17	3680-155-005-00	2	4	8595-101-721-00	46	6
	6	13		42	8	8595-101-731-00	46	9
	39	14		43	8	8595-101-732-00	46	13
1560-601-028-00	40	18		44	8	8595-150-071-00	2	3
	41	18		45	8		42	7
	21	3	3737-341-006-00	7	16		43	7
	22	3		8	16		44	7
	23	3		9	16		45	7
	24	3		10	16	8595-150-710-00	2	1
	35	3	3737-341-007-00	7	17		42	5
	35	7		8	17		43	5
1564-275-007-00	32	4		9	17		44	5
	34	4		10	17		45	5
1593-901-015-00	36	8	3746-111-011-00	7	6	8595-201-011-00	3	1
	37	6		8	6		4	1
	38	8		9	6		5	1
1594-218-001-00	42	18		10	6		6	1
	3	7	3768-112-001-00	25	4		39	2
	4	7		26	4		40	2
	5	7	3805-210-021-10	2	5		41	2
	6	7		42	9	8595-201-012-00	3	3
	39	8		43	9		4	3
1594-221-001-00	40	8		44	9		5	3
	41	8		45	9		6	3
	14	4	3805-701-018-00	27	5		39	4
	14	17	7821-102-008-00	46	7		40	4
	15	4		46	14		41	4
	15	17	7821-102-220-00	46	8	8595-201-013-00	3	6
2149-602-012-00	16	4		46	15		4	6
	16	17	7955-201-026-00	3	2		5	6
	28	4		4	2		6	6
	29	4		5	2		39	7
	30	4		6	2		40	7
	31	4		39	3		41	7
2500-901-014-30	36	4		40	3	8595-201-015-00	3	13
	37	4		41	3		4	12

Numerical Index

8595-097-190-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
8595-201-015-00	5 13	8595-201-250-10	5 10	8595-501-001-20	34 15
	6 12		40 11	8595-505-002-00	32 8
	39 13		6 10		33 5
	40 14		39 11		34 8
	41 14		39 1	8595-505-051-30	32 16
8595-201-016-00	3 14	8595-203-003-00	12 1		33 1
	4 14		16 3		34 16
	5 14		17 1	8595-608-082-10	21 2
	6 14		18 2		22 2
	39 15		19 2		23 2
8595-201-017-00	40 15	8595-306-005-10	20 2		24 2
	41 15		17 4		35 2
	3 15		18 3		35 6
	4 15		19 3	8595-901-005-00	36 6
	5 15		20 3		38 6
8595-201-021-00	6 15	8595-306-006-00	17 2	8595-901-006-00	36 2
	39 16		18 4		37 2
	40 16		19 4		38 2
	41 16		20 4		42 19
	3 18		19 1	8595-901-007-00	36 3
8595-201-022-00	4 16	8595-306-055-10	23 1		37 3
	5 18		25 1		38 3
	6 16		28 6		42 20
	39 17		29 6		45 18
	40 19		30 6	8595-901-008-10	36 7
8595-201-023-00	41 19	8595-402-410-00	31 6		38 7
	3 19		42 14		42 21
	4 17		43 15	8595-950-200-10	42 1
	5 19		44 15	8597-202-500-00	8 9
	6 17		45 15	8597-202-501-00	7 10
8595-201-024-00	39 18	8595-406-220-00	28 1		8 10
	40 20		42 12		9 10
	41 20		28 3		10 10
	6 21		42 13	8597-301-002-00	3 24
	6 22		28 7		4 24
8595-201-025-00	3 9	8595-407-046-10	29 7		5 24
	4 9		30 7	8654-101-221-00	46 1
	5 9		31 7	8654-101-230-00	46 3
	6 9		42 15		46 10
	39 10		43 16	8654-101-232-00	46 4
8595-201-041-00	40 10	8595-407-450-00	44 16		46 11
	41 10		45 16	8654-101-233-00	46 5
	6 11		32 15		46 12
	39 12		32 18	8654-201-042-00	5 21
	4 10		33 3	8654-201-043-00	5 22

Numerical Index

8595-097-190-00

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
8654-201-072-10	4	11	8657-201-710-00	41	11	8657-501-540-10	34	7
	5	11	8657-201-750-00	41	1	8657-608-710-10	35	1
	40	12	8657-202-001-00	8	1	8657-608-720-00	35	5
8654-201-750-10	40	1		8	4	8657-950-400-10	43	1
8654-202-016-00	7	2	8657-202-003-20	7	1	8658-101-674-00	46	17
	7	5		7	4	8658-201-042-02	4	21
	8	2		9	1	8658-201-043-02	4	22
	8	5		9	4	8658-202-200-00	7	9
	9	2		10	1	8658-301-001-00	14	9
	9	5		10	4		14	22
	10	2	8657-202-220-10	9	9		15	9
	10	5	8657-203-001-00	11	1		15	22
8654-203-081-00	13	1	8657-301-004-00	14	1	8658-306-003-00	17	5
8654-203-810-00	10	9		15	1	8658-402-710-00	21	1
8654-301-004-00	14	7		16	1	8658-407-450-00	30	1
	14	20	8657-301-005-00	14	12	8658-407-460-00	30	3
	15	7		15	12	8658-901-031-00	37	7
	15	20		16	12	8658-950-400-10	45	1
	16	7	8657-301-007-00	16	9	8659-501-310-00	32	22
	16	20		16	22	8659-501-320-00	32	23
8654-301-081-10	14	3	8657-301-008-00	14	24	8663-101-211-00	46	2
8654-301-085-00	15	3		15	24	P115-810-011-00	25	2
8654-306-006-10	18	1		16	24		26	2
8654-403-770-00	24	1	8657-301-009-00	14	15		27	2
8654-406-001-00	27	4		15	15	V201-260-803-00	25	5
8654-406-550-00	27	1		16	15		26	5
8654-407-048-00	44	12	8657-306-005-00	20	1	V201-261-205-50	32	24
8654-407-480-00	44	13	8657-402-750-00	22	1	V210-360-601-20	43	14
8654-407-720-00	31	1	8657-406-210-00	26	1		45	14
8654-407-730-00	31	3	8657-407-047-00	43	13	V211-260-801-60	3	4
8654-501-041-00	32	19		45	13		4	4
8654-501-283-00	32	11	8657-407-450-00	29	1		5	4
	33	8	8657-407-460-00	29	3		6	4
	34	11	8657-407-470-00	43	12		39	5
8654-501-770-00	34	3		45	12		40	5
8654-901-002-00	36	5	8657-501-500-10	32	1		41	5
	37	5		34	1	V211-261-002-50	14	2
	38	5	8657-501-501-00	32	2		14	13
8654-950-500-10	44	1		34	2		15	2
8657-101-501-00	46	16	8657-501-520-10	32	6		15	13
8657-201-072-00	3	21	8657-501-530-00	32	10		16	2
8657-201-073-00	3	22		33	7		16	13
8657-201-074-00	3	11		34	10	V211-360-801-60	2	7
	41	12	8657-501-540-10	32	7		28	9
8657-201-710-00	3	10		33	4		29	9

Numerical Index

8595-097-190-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
V211-360-801-60	30 9	V362-260-008-00	29 2	V580-140-504-00	32 3
	31 9		29 5		32 12
	42 11		29 8		33 9
	42 17		30 2		34 12
	43 11		30 5		35 4
	43 17		30 8		35 8
	44 11		31 2	V580-140-804-00	1 2
	44 17		31 5		42 3
	45 11		31 8		43 3
	45 17		32 20		44 3
V211-661-002-00	3 23	V363-260-008-00	42 10		45 3
	4 23		42 16	V600-110-600-60	3 16
	5 23		43 10		4 18
	6 23		44 10		5 16
V211-661-005-00	2 2		45 10		6 18
	42 6		25 3	V600-110-690-80	39 19
	43 6		26 3		40 17
	44 6		27 3		41 17
V304-260-008-00	45 6	V401-160-010-00	3 27		14 5
	7 18		4 26		14 18
	8 18	V401-160-012-00	5 27		15 5
	9 18		27 7		15 18
	10 18		32 25		16 5
	25 6	V401-160-016-00	7 7		16 18
	26 6		8 7	V704-140-016-00	7 13
V304-260-010-00	3 26	V401-160-020-00	9 7		8 13
	4 27		10 7		9 13
	5 26		17 3	V704-140-017-00	10 13
	14 16		18 5		7 12
	15 16		19 5		8 12
	16 16		20 5		9 12
	27 6		3 28		10 12
V304-260-012-00	7 8	V411-260-010-00	4 28	V704-140-025-00	34 5
	8 8		5 28	V705-140-052-00	14 6
V304-460-016-00	9 8	V411-260-014-00	3 25		14 19
	10 8		4 25		15 6
	35 9		5 25		15 19
	44 14		18 6		16 6
V360-260-006-00	32 17	V411-260-020-00	32 13	V707-140-055-00	16 19
	33 2		33 10		3 12
	34 17		34 13		4 19
	2 6		21 4		5 12
V362-260-008-00	28 2	V580-140-504-00	22 4		6 19
	28 5		23 4		39 20
	28 8		24 4		40 13

Numerical Index

8595-097-190-00

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key
V707-140-055-00	41	13	V760-150-000-00	32	14		
V707-140-062-00	3	8		33	11		
	4	8		34	6		
	5	8		34	14		
	6	8					
	14	10					
	14	23					
	15	10					
	15	23					
	16	10					
	16	23					
	39	9					
	40	9					
	41	9					
V721-103-108-00	3	5					
	4	5					
	5	5					
	6	5					
	39	6					
	40	6					
	41	6					
V744-130-551-20	3	20					
	4	20					
	5	20					
	6	20					
	39	21					
	40	21					
	41	21					
V744-135-520-80	14	8					
	14	21					
	15	8					
	15	21					
	16	8					
	16	21					
V760-150-000-00	7	15					
	8	15					
	9	15					
	10	15					
	14	11					
	14	14					
	15	11					
	15	14					
	16	11					
	16	14					
	32	5					

Alphabetical Index

8595-097-190-00

Description		Fig. Key		Description	Fig. Key		Description	Fig. Key	
ARM/FRONT	COMP	35	1	BLADE/60X472/D	20	1	BRACKET/CASE/LH	3	21
ARM/GAUGE/LH	COMP	32	22	BLADE/60X528/C	18	1		4	21
ARM/GAUGE/RH	COMP	32	23	BL0T/M10X25	3	24	BRACKET/CASE/RH	3	22
ARM/TENSION	ASSY	7	9		4	24		4	22
		8	9		5	24	BUSH/16X18X15	7	10
		9	9	BOLT(S) M10X25	14	2		8	10
		10	9		14	13		9	10
AS YOKE	ASSY	46	16		15	2		10	10
BEARING		14	5		15	13	BUSH/22X25X25	32	11
		14	18		16	2		33	8
		15	5		16	13		34	11
		15	18	BOLT, SEMS	43	14	BUSH/26X30X20	32	2
		16	5		45	14		34	2
		16	18	BOLT, SEMS (SP)	2	7	CAP/32	28	4
BEARING, RB 6006		3	16		28	9		29	4
		4	18		29	9		30	4
		5	16		30	9		31	4
		6	18		31	9	CAP/COVER	44	12
		39	19		42	11	CAP/COVER COMP	44	13
		40	17		42	17	CASE/BEVEL	3	1
		41	17		43	11		4	1
BEARING/BALL 6205SH2		14	4		43	17		5	1
		14	17		44	11		6	1
		15	4		44	17		39	2
		15	17		45	11		40	2
		16	4		45	17		41	2
		16	17	BOLT, SEMS (S) M8X16	3	4	CASE/BEVEL ASSY	40	1
BEARING/BALL 6305SH2		3	7		4	4		41	1
		4	7		5	4	CASE/BEVEL/28-1 ASSY	39	1
		5	7		6	4	CHAIN ASSY	46	8
		6	7		39	5		46	15
		39	8		40	5	CLIP, PIN	32	9
		40	8		41	5		33	6
		41	8	BOLT/M 8X30	25	5		34	9
BEARING/BALL/6304SH2		3	17		26	5	COLLAR/26X36X3	7	3
		4	13	BOLT/M10X20	3	23		8	3
		5	17		4	23		9	3
		6	13		5	23		10	3
		39	14		6	23	COLLAR/BRADE	14	9
		40	18	BOLT/M12X55	32	24		14	22
		41	18	BOLT/SP	2	2		15	9
BELT/VB092		12	1		42	6		15	22
BELT/VB101		11	1		43	6		16	9
BELT/VB113		13	1		44	6		16	22
BLADE/50X428/E		19	1		45	6	COLLER/26X34X15	14	24

Alphabetical Index

8595-097-190-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
COLLER/26X34X15	15 24	GEAR/BEVEL/25-1 SET	4 10	LABEL/MAINTENANCE	42 18
	16 24		5 10		36 5
COVER/B/L/TXG/F COMP	28 1	GEAR/BEVEL/27-1 SET	40 11	LABEL/PTO	37 5
	29 1		3 10		38 5
	30 1	GEAR/BEVEL/28-1 SET	41 11	LABEL/WARNING/BELT	36 2
	31 1		6 10		37 2
	42 12	GREASENIPPLE	39 11		38 2
	28 3		46 4		42 19
COVER/B/R/TXG/F COMP	29 3	INSULATOR	46 11	LABEL/WARNING/HOT	36 3
	30 3		2 5		37 3
	31 3		42 9		38 3
	42 13		43 9		42 20
COVER/CASE	3 3		44 9		45 18
	4 3		45 9	METAL/CENTER	14 12
	5 3	JOINT/UNIVERSAL SET	1 1		15 12
	6 3		42 2		16 12
	39 4		43 2		14 1
	40 4		44 2	METAL/SIDE	15 1
	41 4		45 2		16 1
COVER/DISCHARGE COMP	25 1	JOURNALCROSSE ASSY	46 3	NIPPLE, GREASE	7 15
	26 1		46 10		8 15
	27 1	KEY/06X06X28	7 2		9 15
	28 6		7 5		10 15
COVER/UNIVERSAL/TXG	29 6		8 2		14 11
	30 6		8 5		14 14
	31 6		9 2		15 11
	42 14		9 5		15 14
	43 15		10 2		16 11
	44 15		10 5		16 14
	45 15	LABEL/CE	36 1		32 5
DECK/MOWER/48/TXG	23 1		37 1		32 14
DECK/MOWER/54/TXG	21 1	LABEL/CUTTING	38 1		33 11
	22 1		37 7		34 6
DECK/MOWER/60/TXG	24 1	LABEL/DANGER	36 4		34 14
	F/TXGKIT		37 4	NUT	3 26
	43 1		38 4		4 27
	44 1	LABEL/DANGER/DISCHAR	36 6		5 26
	45 1		38 6		7 18
FITTINGYOKE	46 1	LABEL/DANGER/JOINT/G	46 17		8 18
FORK/M22 COMP	35 5	LABEL/GAUGEWHEEL	36 7		9 18
FORK/WHEEL ASSY	32 1		38 7		10 18
	34 1		42 21		14 16
FORK/WHEEL/R COMP	32 7	LABEL/MAINTENANCE	36 8		15 16
	33 4		37 6		16 16
	34 7		38 8		25 6

Alphabetical Index

8595-097-190-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
NUT	26 6	PIN, SPRING/5 X40 W	22 4	PLATE/COVER/MOWER	45 7
	35 9		23 4	PLATE/FOOK COMP	43 12
NUT/M12	27 6		24 4		45 12
NUT/M16	7 8		32 3	PLATE/L/155X36 COMP	28 7
	8 8		32 12		29 7
	9 8		33 9		30 7
	10 8		34 12		31 7
NUT/M20X1.5	17 2		35 4		42 15
	18 4		35 8		43 16
	19 4	PIN, SPRING/8 X40 W	1 2		44 16
	20 4		42 3		45 16
NUT/M6	44 14		43 3	PLATE/L/60X65	6 22
NUT/WASHER	2 6		44 3	PLATE/L/75X106	5 21
	25 3		45 3		5 22
	26 3	PIN/08X44	32 8	PLATE/L/75X65	6 21
	27 3		33 5	PLATE/U/42X07	43 13
	28 2		34 8		45 13
	28 5	PIN/12X117	32 16	PLUG, DRAIN (1/4)	3 2
	28 8		33 1		4 2
	29 2		34 16		5 2
	29 5	PIN/12X133	32 19		6 2
	29 8	PIN/16X96	21 2		39 3
	30 2		22 2		40 3
	30 5		23 2		41 3
	30 8		24 2	PROTECTOR/040	2 4
	31 2		35 2		42 8
	31 5		35 6		43 8
	31 8	PIN/GAUGE COMP	32 6		44 8
	32 17		34 3		45 8
	32 20	PIN/PARALLEL	17 5	PULLEY COMP	7 11
	33 2	PIPE/GREASE	14 15		8 11
	34 17		15 15		9 11
	42 10		16 15		10 11
	42 16	PLATE/03X15X65	25 2	PULLEY/VB125	8 1
	43 10		26 2		8 4
	44 10		27 2	PULLEY/VB137	7 1
	45 10	PLATE/COVER/MID COMP	2 1		7 4
O-RING/G80	3 5		42 5		9 1
	4 5		43 5		9 4
	5 5		44 5		10 1
	6 5		45 5		10 4
	39 6	PLATE/COVER/MOWER	2 3	RING, SNAP/16 C	7 13
	40 6		42 7		8 13
	41 6		43 7		9 13
PIN, SPRING/5 X40 W	21 4		44 7		10 13

Alphabetical Index

8595-097-190-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
RING, SNAP/17 C	7 12	SEAL, OIL/TC305512	41 21	SHIM/0.1	6 16
	8 12	SEAL, OIL/TC35528	14 8		39 15
	9 12		14 21		39 17
	10 12		15 8		40 15
RING, SNAP/25 C	34 5		15 21		40 19
RING, SNAP/52 C	14 6		16 8		41 15
	14 19		16 21		41 19
	15 6	SEAL/OIL	3 9	SHIM/0.2	3 15
	15 19		4 9		3 19
	16 6		5 9		4 15
	16 19		6 9		4 17
RING/SLIDE	46 7		14 7		5 15
	46 14		14 20		5 19
RING/SNAP	3 8		15 7		6 15
	3 12		15 20		6 17
	4 8		16 7		39 16
	4 19		16 20		39 18
	5 8		39 10		40 16
	5 12		40 10		40 20
	6 8		41 10		41 16
	6 19	SHAFT/BRADE	16 3		41 20
	14 10	SHAFT/INPUT	3 6	SHIM/1.2	17 4
	14 23		4 6		18 3
	15 10		5 6		19 3
	15 23		6 6		20 3
	16 10		39 7	SLEEVEYOKE	46 9
	16 23		40 7	SPRING, CHAIN TENSION	7 16
	39 9		41 7		8 16
	39 20	SHAFT/OUTPUT	3 11		9 16
	40 9		4 11		10 16
	40 13		5 11	SPRING, CLUTCH RETURN	25 4
	41 9		6 11		26 4
	41 13		39 12	SPRING/HC042	21 3
ROD, CHAIN TENSION	7 17		40 12		22 3
	8 17		41 12		23 3
	9 17	SHAFT/SIDE	14 3		24 3
	10 17		15 3		35 3
SAFETYGUARD/IN	46 6	SHAFTYOKE	46 2		35 7
SAFETYGUARD/OUT	46 13	SHIM/0.1	3 14	STOPPER/COVER	27 4
SEAL, OIL/TC305512	3 20		3 18	SURCLIP/HOLE	46 5
	4 20		4 14		46 12
	5 20		4 16	WASHER	7 6
	6 20		5 14		7 14
	39 21		5 18		8 6
	40 21		6 14		8 14

Alphabetical Index

8595-097-190-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
WASHER	9 6	WHEEL/GAUGE/FRONT	32 15		
	9 14		32 18		
	10 6		33 3		
	10 14		34 15		
WASHER(13X34X05)	27 5				
WASHER, PL/M14	3 25				
	4 25				
	5 25				
WASHER, PL/M22	32 13				
	33 10				
	34 13				
WASHER, SP/M10	3 27				
	4 26				
	5 27				
WASHER, SP/M12	27 7				
	32 25				
WASHER, SP/M16	7 7				
	8 7				
	9 7				
	10 7				
WASHER, SP/M20	17 3				
	18 5				
	19 5				
	20 5				
WASHER/13X17X10	32 21				
WASHER/20X60X06	17 1				
	18 2				
	19 2				
	20 2				
WASHER/27X40X2	32 4				
	34 4				
WASHER/45X55X01	3 13				
	4 12				
	5 13				
	6 12				
	39 13				
	40 14				
	41 14				
WASHER/M10	3 28				
	4 28				
	5 28				
WASHER/M20	18 6				
WHEEL/GAUGE ASSY	32 10				
	33 7				
	34 10				