

Directions for use of Parts Catalogue

1. Applicable model of machines

All component and option parts used for SRM48, 54 Mower are listed in this parts catalogue.

NOTES:

SRM48-TXG23E4F..... FOR TXG237

SRM54-TXG23E4F..... FOR TXG237

Explanation for head paragraph

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL						I T C	C O L	G R P	REMARKS
				SSM48M	SSM48F	SSM48G	SRM48M	SRM48F	SRM48G				
1	8595-211-001-20	CASE/UPPER	*	1 -239			1						
1A	8657-201-081-00	CASE/UPPER	*	1 -230-			1						
2	8595-211-002-10	CASE/LOWER	*	1			1						
3	V523-100-801-80	PIN	*	2			2						
4	V211-260-803-00	BOLT, SEMS	*	6			6						
			*	2 -239			2						
			*	2 -230-			2						
			*	2			2						
			*	1			1						

- ① KEY shows the location of parts diagramed in the illustration.
- ② Parts numbers begin with `V` and `W` are standard parts of the market.
- ③ `LH` and `RH` on the parts name are described against the moving direction of the machine or are described on the condition how to install parts on the machines.
- ④ SPC : The following symbol classifies parts to be used for machines.
 - `\*` means standard parts.
 - `T` shows that the parts can be installed as optional parts.
 - `R` shows that the parts can be used as applicable parts to replace originally equipped parts.

- ⑤ Upper column : QTY shows the number of parts to be used for one unit of machine.

`M` is indicated for parts supplied by a meter long.

`l` is indicated for parts supplied by liter.

`AR` is indicated for parts need to be adjusted or regulated.

Lower column : serial number

—229 means serial number up to 229.

230— means serial number 230 and after.

- ⑥ ITC : Interchangeability

`1`...OLD ← NEW

New parts can be used in place of the old parts.

`2`...OLD → NEW

Old parts can be used in place of the new parts.

`3`...OLD →← NEW

Old parts and new parts can not be replaced each other.

- ⑦ COL : Color code

Color is signified with color code number for colored parts.

Please see the color list shown in the next page.

- ⑧ GRP : Parts shown in this column can be replaced by SET parts.

Example : Parts marked ① can be replaced by parts marked ②, and ③ for ④, so the rest follow in the same alphabetical order.

- ⑨ Remarks

* Other maker's part code number is shown in this column.

* When Fig. No. is shown in the Remark column of SET parts or ASSY parts, each of their component parts are listed in said Fig. No.

2. Color :

The following colors are used color parts.

COLOR CODE	COLOR	SPRAY TYPE PARTS CODE	PAINTS 4K DRUM PARTS CODE	PAINTS 16K DRUM PARTS CODE
7 F	MIRROR BLACK	1300-954-001-10	1300-954-003-00	1300-954-004-00

NOTE : Color code is signified only for the parts assigned by the maker as color parts

3. Serial Numbers :

For chassies serial number is shown on the LABEL.

Please see




4. Parts Order


- 1) When you order parts, please make sure of correct numbers.
 - 2) When substitute parts is available, the part number ordered will be automatically turned to a new part number.
 - 3) Please be sure to use “ISEKI GENUINE PARTS” .
- Any other similar parts other than ISEKI parts when used may cause a trouble that makes us unable to repair or guarantee the warrant.

[illegible]

(SRM48TXG23)



(SRM54TXG23)



Contents

SRM48,54

JOINT(UNIVERSAL) SYSTEM.....	Fig.101
COVER(JOINT) SYSTEM.....	Fig.102
CASE(BEVEL) SYSTEM(SRM54).....	Fig.201
CASE(BEVEL) SYSTEM(SRM48).....	Fig.202
PULLEY SYSTEM(SRM54).....	Fig.203
PULLEY SYSTEM(SRM48).....	Fig.204
BELT SYSTEM(SRM54).....	Fig.205
BELT SYSTEM(SRM48).....	Fig.206
METAL(SIDE) SYSTEM(SRM54).....	Fig.301
METAL(SIDE) SYSTEM(SRM48).....	Fig.302
BLADE SYSTEM(SRM54).....	Fig.303
BLADE SYSTEM(SRM48).....	Fig.304
DECK(MOWER) SYSTEM(SRM54).....	Fig.401
DECK(MOWER) SYSTEM(SRM48).....	Fig.402
GUIDE SYSTEM(SRM48).....	Fig.403
COVER(DISCHARGE) SYSTEM(SRM54).....	Fig.404
COVER(BELT) SYSTEM(SRM48).....	Fig.405
COVER(BELT) SYSTEM(SRM54).....	Fig.406
WHEEL(GAUGE) SYSTEM(SRM54).....	Fig.501
WHEEL(GAUGE) SYSTEM(SRM48).....	Fig.502
LINK(LIFT) SYSTEM.....	Fig.601
PROTECTOR SYSTEM.....	Fig.701
LABEL(SRM48).....	Fig.901
LABEL(GAUGE WHEEL)(SRM48).....	Fig.902
LABEL(SRM54).....	Fig.903
LABEL(CE).....	Fig.904

COMPONENT PARTS

COMPONENT PARTS

FOR 8595-101-710-00 ON Fig.101.....Fig.S01




[illegible]

FIG.102 COVER(JOINT) SYSTEM



8595-150 -0100


[illegible]


FIG.201 CASE(BEVEL) SYSTEM(SRM54)


8658-201C-0100

KEY	PART CODE	DESCRIPTION	S P C	TYPE OF MODEL		I T C	C O L	G R P	REMARKS
				SRM48 TXG23	SRM54 TXG23				
1	8595-201-011-00	CASE/BEVEL	*		1				
2	7955-201-026-00	PLUG,DRAIN (1/4)	*		2				
3	8595-201-012-00	COVER/CASE	*		1				
4	V211-260-801-60	BOLT,SEMS (S) M8X16	*		4				
5	V721-103-108-00	O-RING/G80	*		1				
6	8595-201-013-00	SHAFT/INPUT	*		1				
7	1594-218-001-00	BEARING/BALL 6305SH2	*		2				
8	V707-140-062-00	RING/SNAP	*		1				
9	8595-201-025-00	SEAL/OIL	*		1				
10	8595-201-250-10	GEAR/BEVEL/25-1 SET	*		1				
11	8654-201-072-10	SHAFT/OUTPUT	*		1				
12	8595-201-015-00	WASHER/45X55X01	*		1				
13	-----	BLANK	*						-----
13	1560-214-003-00	BEARING/BALL/6304SH2	*		1				
14	8595-201-016-00	SHIM/0.1	*		1				
15	8595-201-017-00	SHIM/0.2	*		1				
16	8595-201-021-00	SHIM/0.1	*		1				
17	8595-201-022-00	SHIM/0.2	*		1				
18	V600-110-600-60	BEARING,RB 6006	*		1				
19	V707-140-055-00	RING/SNAP	*		1				
20	V744-130-551-20	SEAL,OIL/TC305512	*		1				
21	8658-201-042-02	BRACKET/CASE/LH	*		1		7F		
22	8658-201-043-02	BRACKET/CASE/RH	*		1		7F		
23	V211-661-002-00	BOLT/M10X20	*		4				
24	8597-301-002-00	BLOT/M10X25	*		4				
25	V411-260-014-00	WASHER,PL/M14	*		4				
26	V401-160-010-00	WASHER,SP/M10	*		4				
27	V304-260-010-00	NUT	*		4				
28	V411-260-010-00	WASHER/M10	*		4				


[illegible]

[illegible]

[illegible]

[illegible]

[illegible]


[illegible]



21

21


FIG.402 DECK(MOWER) SYSTEM(SRM48)



8597-402E-0100


[illegible]

FIG.404 COVER(DISCHARGE) SYSTEM(SRM54)





8666-406 -0100


[illegible]


[illegible]

[illegible]


[illegible]

[illegible]

[illegible]

[illegible]

This technical drawing shows the underside of a boat hull. It features a central transom with a motor mount and a fuel tank. Two outboard motor mounts are positioned on the sides, each with a fuel line and a vent. The hull is reinforced with internal bracing and has several access points for maintenance. A vertical line with the number '1' at the bottom indicates a specific section or component.

[illegible]

Numerical Index

8597-095-120-00

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
1434-211-004-00	203	3	8595-150-710-00	102	1	8595-901-006-00	903	1
	204	3	8595-201-011-00	201	1	8595-901-007-00	901	2
1560-214-003-00	201	13		202	1		903	2
	202	17	8595-201-012-00	201	3	8595-901-008-10	902	1
1560-601-028-00	401	3		202	3	8597-201-001-00	202	22
	402	3	8595-201-013-00	201	6	8597-202-500-00	204	9
	601	3		202	6	8597-202-501-00	203	10
	601	7	8595-201-015-00	201	12		204	10
1564-275-007-00	501	4		202	13	8597-301-002-00	201	24
1593-901-015-00	901	5	8595-201-016-00	201	14	8597-306-002-00	304	1
	903	6		202	14	8597-402-710-00	402	1
1594-218-001-00	201	7	8595-201-017-00	201	15	8597-406-001-00	403	3
	202	7		202	15	8597-406-200-20	403	1
1594-221-001-00	301	4	8595-201-021-00	201	16	8597-406-210-00	403	5
	301	17		202	18	8597-407-710-00	405	1
	302	4	8595-201-022-00	201	17	8597-407-720-00	405	3
	302	17		202	19	8597-701-071-00	701	7
2149-602-012-00	405	4	8595-201-023-00	202	21	8597-701-072-00	701	3
	406	4	8595-201-025-00	201	9	8597-701-710-00	701	1
2500-901-014-30	901	3		202	9	8597-701-720-00	701	6
	903	3	8595-201-041-00	202	11	8654-101-221-00	S01	1
2500-901-027-00	904	1	8595-201-250-10	201	10	8654-101-230-00	S01	3
3621-211-003-00	203	14	8595-201-410-00	202	10		S01	10
	204	15	8595-203-003-00	206	1	8654-101-232-00	S01	4
3680-155-005-00	102	4	8595-301-031-00	302	3		S01	11
3737-341-006-00	203	16	8595-306-005-10	303	3	8654-101-233-00	S01	5
	204	17		304	3		S01	12
3737-341-007-00	203	17	8595-306-006-00	303	4	8654-201-072-10	201	11
	204	18		304	2	8654-202-016-00	203	2
3746-111-011-00	203	6	8595-306-007-00	303	5		203	5
	204	6		304	4		204	2
3805-210-021-10	102	5	8595-407-046-10	405	6		204	5
7821-102-008-00	S01	7		406	6	8654-301-004-00	301	7
	S01	14	8595-407-470-00	405	7		301	20
7821-102-220-00	S01	8		406	7		302	7
	S01	15	8595-501-001-20	501	14		302	20
7955-201-026-00	201	2		502	11	8654-301-081-10	301	3
	202	2	8595-505-051-30	501	15	8654-501-283-00	501	10
8593-014-200-10	203	11		502	12		502	5
	204	11	8595-608-082-10	401	2	8654-901-002-00	901	4
8595-101-710-00	101	1		402	2		903	4
8595-101-721-00	S01	6		601	2	8657-101-501-00	S01	16
8595-101-731-00	S01	9		601	6	8657-202-001-00	204	1
8595-101-732-00	S01	13	8595-901-005-00	903	5		204	4
8595-150-071-00	102	3	8595-901-006-00	901	1	8657-202-003-20	203	1

Numerical Index

8597-095-120-00

Part Code	Fig. Key		Part Code	Fig. Key		Part Code	Fig. Key	
8657-202-003-20	203	4	V211-260-801-60	202	4	V411-260-020-00	303	7
8657-203-001-00	205	1	V211-260-802-50	701	2	V411-260-022-00	501	12
8657-301-004-00	301	1	V211-261-002-50	301	2		502	7
	302	1		301	13	V580-140-504-00	401	4
8657-301-005-00	301	12		302	2		402	4
	302	12		302	13		501	3
8657-301-007-00	302	9	V211-360-801-60	102	7		501	11
	302	22		405	9		601	4
8657-301-008-00	301	24		406	9		601	8
	302	24	V211-661-002-00	201	23	V580-140-804-00	101	2
8657-301-009-00	301	15		202	23	V600-110-600-60	201	18
	302	15	V211-661-005-00	102	2		202	16
8657-501-360-00	502	1	V304-260-008-00	203	18	V600-110-690-80	301	5
8657-501-370-00	502	2		204	19		301	18
8657-501-500-10	501	1	V304-260-010-00	201	27		302	5
8657-501-501-00	501	2		301	16		302	18
8657-501-520-10	501	6		302	16	V704-140-016-00	203	13
8657-501-530-00	501	9	V304-460-016-00	203	8		204	13
	502	4		204	8	V704-140-017-00	203	12
8657-501-540-10	501	7		502	10		204	12
8657-608-710-10	601	1	V334-460-022-00	601	9	V705-140-052-00	301	6
8657-608-720-00	601	5	V360-260-012-00	501	16		301	19
8658-101-674-00	S01	17		502	13		302	6
8658-201-042-02	201	21	V362-260-008-00	102	6		302	19
8658-201-043-02	201	22		405	2	V707-140-055-00	201	19
8658-202-200-00	203	9		405	5		202	12
8658-301-001-00	301	9		405	8	V707-140-062-00	201	8
	301	22		406	2		202	8
8658-407-450-10	406	1		406	5		301	10
8658-407-460-10	406	3		406	8		301	23
8658-901-031-00	903	7		701	5		302	10
8659-501-310-00	501	17		701	8		302	23
8659-501-320-00	501	18	V363-260-008-00	403	2	V721-103-108-00	201	5
8663-101-211-00	S01	2		403	4		202	5
8663-501-001-10	502	6		404	3	V744-130-551-20	201	20
8663-501-240-00	501	8	V401-160-010-00	201	26		202	20
	502	3	V401-160-012-00	501	20	V744-135-520-80	301	8
8666-306-001-00	303	1	V401-160-016-00	203	7		301	21
8666-306-003-00	303	2		204	7		302	8
8666-402-710-00	401	1		502	9		302	21
8666-406-001-00	404	1	V401-160-020-00	303	6	V760-150-000-00	203	15
8666-406-002-00	404	2		304	5		204	16
8666-701-002-00	701	4	V411-260-010-00	201	28		301	11
V201-261-205-50	501	19	V411-260-014-00	201	25		301	14
V211-260-801-60	201	4	V411-260-016-00	204	14		302	11

Numerical Index

8597-095-120-00

Part Code	Fig. Key	Part Code	Fig. Key	Part Code	Fig. Key
V760-150-000-00	302 14 501 5 501 13 502 8				

Alphabetical Index

8597-095-120-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
ARM/FRONT COMP	601 1	BUSH/26X30X20	501 2	KEY/06X06X28	204 5
ARM/GAUGE/LH COMP	501 17	CAP/32	405 4	LABEL/CE	904 1
ARM/GAUGE/RH COMP	501 18		406 4	LABEL/CUTTING	903 7
ARM/TENSION ASSY	203 9	CASE/BEVEL	201 1	LABEL/DANGER	901 3
	204 9		202 1		903 3
AS YOKE ASSY	S01 16	CHAIN ASSY	S01 8	LABEL/DANGER/DISCHAR	903 5
BEARING	301 5		S01 15	LABEL/DANGER/JOINT/G	S01 17
	301 18	COLLAR/26X36X3	203 3	LABEL/GAUGEWHEEL	902 1
	302 5		204 3	LABEL/MAINTENANCE	901 5
	302 18	COLLAR/BRADE	301 9		903 6
BEARING, RB 6006	201 18		301 22	LABEL/PTO	901 4
	202 16		302 9		903 4
BEARING/BALL 6205SH2	301 4		302 22	LABEL/WARNING/BELT	901 1
	301 17	COLLER/26X34X15	301 24		903 1
	302 4		302 24	LABEL/WARNING/HOT	901 2
	302 17	COVER/B/L/TXG/F COMP	406 1		903 2
BEARING/BALL 6305SH2	201 7	COVER/B/R/TXG/F COMP	406 3	METAL/CENTER	301 12
	202 7	COVER/BELT/L/TX COMP	405 1		302 12
BEARING/BALL/6304SH2	201 13	COVER/BELT/R/TX COMP	405 3	METAL/SIDE	301 1
	202 17	COVER/CASE	201 3		302 1
BELT/VB092	206 1		202 3	NIPPLE, GREASE	203 15
BELT/VB101	205 1	COVER/DISCHARGE	404 1		204 16
BLADE/50X429/C	304 1	COVER/PROTECTOR	701 3		301 11
BLADE/60X480/M	303 1	COVER/UNIVERSAL/TXG	405 6		301 14
BLOT/M10X25	201 24		406 6		302 11
BOLT(S) M10X25	301 2	DECK/MOWER/48/TXG	402 1		302 14
	301 13	DECK/MOWER/54/TXG	401 1		501 5
	302 2	FITTINGYOKE	S01 1		501 13
	302 13	FORK/M22 COMP	601 5		502 8
BOLT, SEMS (SP)	102 7	FORK/WHEEL ASSY	501 1	NUT	201 27
	405 9	FORK/WHEEL/R COMP	501 7		203 18
	406 9	FORK/WHEEL/REAR/LH	502 1		204 19
BOLT, SEMS (S) M8X16	201 4	FORK/WHEEL/REAR/RH	502 2		301 16
	202 4	GEAR/BEVEL/25-1 SET	201 10		302 16
BOLT/M10X20	201 23	GEAR/BEVEL/28-1 SET	202 10		601 9
	202 23	GREASENIPPLE	S01 4	NUT/M16	203 8
BOLT/M12X55	501 19		S01 11		204 8
BOLT/S	701 2	GUIDE COMP	403 1		502 10
BOLT/SP	102 2	INSULATOR	102 5	NUT/M20X1.5	303 5
BRACKET/CASE/LH	201 21	JOINT/UNIVERSAL SET	101 1		304 4
BRACKET/CASE/RH	201 22	JOURNALCROSSE ASSY	S01 3	NUT/WASHER	102 6
BUSH/16X18X15	203 10		S01 10		403 2
	204 10	KEY/06X06X28	203 2		403 4
BUSH/22X25X25	501 10		203 5		404 3
	502 5		204 2		405 2

Alphabetical Index

8597-095-120-00

Description	Fig. Key	Description	Fig. Key	Description	Fig. Key
NUT/WASHER	405 5	PROTECTOR/040	102 4	SHAFT/OUTPUT	202 11
	405 8	PULLEY COMP	203 11	SHAFT/SIDE	301 3
	406 2	PULLEY/VB125	204 11	SHAFTYOKE	S01 2
	406 5		204 1	SHIM/0. 1	201 14
	406 8		204 4		201 16
	501 16		203 1		202 14
	502 13	PULLEY/VB137	203 4		202 18
	701 5	RING, SNAP/16 C	203 13	SHIM/0. 2	201 15
	701 8		204 13		201 17
O-RING/G80	201 5	RING, SNAP/17 C	203 12		202 15
	202 5		204 12		202 19
PIN, SPRING/5 X40 W	401 4	RING, SNAP/52 C	301 6	SHIM/1. 2	303 4
	402 4		301 19		304 2
	501 3		302 6	SLEEVEYOKE	S01 9
	501 11	RING/SLIDE	302 19	SPRING, CHAIN TENSION	203 16
	601 4		S01 7		204 17
	601 8		S01 14	SPRING/HCO42	401 3
PIN, SPRING/8 X40 W	101 2	RING/SNAP	201 8		402 3
PIN/08X60 COMP	501 8		201 19		601 3
	502 3		202 8		601 7
PIN/12X117	501 15		202 12	SURCLIP/HOLE	S01 5
	502 12		301 10		S01 12
PIN/16X96	401 2		301 23	WASHER	203 6
	402 2		302 10		203 14
	601 2		302 23		204 6
	601 6	ROD, CHAIN TENSION	203 17		204 15
PIN/22X106	502 6		204 18	WASHER / M16	204 14
PIN/GAUGE COMP	501 6	SAFETYGUARD/IN	S01 6	WASHER, PL/M14	201 25
PIPE/GREASE	301 15	SAFETYGUARD/OUT	S01 13	WASHER, PL/M22	501 12
	302 15	SEAL, OIL/TC305512	201 20		502 7
PLATE COMP	701 6		202 20	WASHER, SP/M10	201 26
PLATE/22X800	404 2	SEAL, OIL/TC35528	301 8	WASHER, SP/M12	501 20
PLATE/COVER/MID COMP	102 1		301 21	WASHER, SP/M16	203 7
PLATE/COVER/MOWER	102 3		302 8		204 7
PLATE/GUARD COMP	701 1		302 21		502 9
PLATE/I/25X184	701 7	SEAL/OIL	201 9	WASHER, SP/M20	303 6
PLATE/I/25X280	701 4		202 9		304 5
PLATE/I/25X64	403 5		301 7	WASHER/20X60X06	303 3
PLATE/L/155X36 COMP	405 7		301 20		304 3
	406 7		302 7	WASHER/20X70X06	303 2
PLATE/L/60X62	202 22		302 20	WASHER/27X40X2	501 4
PLATE/L/65XX55	403 3		302 3	WASHER/45X55X01	201 12
PLATE/L/75X65	202 21	SHAFT/INPUT	201 6		202 13
PLUG, DRAIN (1/4)	201 2		202 6	WASHER/M10	201 28
	202 2	SHAFT/OUTPUT	201 11	WASHER/M20	303 7

